

SECTION **LAN**
LAN SYSTEM

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CONTENTS

CAN	
PRECAUTIONS	4
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	4
Precautions for Battery Service	4
Precautions When Using CONSULT-II	4
CHECK POINTS FOR USING CONSULT-II	5
Precautions For Trouble Diagnosis	5
CAN SYSTEM	5
Precautions For Harness Repair	5
CAN SYSTEM	5
CAN COMMUNICATION	6
System Description	6
CAN Communication Unit	6
TYPE 1	6
TYPE 2/TYPE3	8
TYPE 4/TYPE5	9
TYPE 6/TYPE7	11
CAN SYSTEM (TYPE 1)	13
System Description	13
Component Parts and Harness Connector Location	13
Wiring Diagram — CAN —	14
Work Flow	16
CHECK SHEET	17
CHECK SHEET RESULTS (EXAMPLE)	19
Circuit Check Between TCM and Data Link Connector	30
Circuit Check Between Data Link Connector and Unified Meter and A/C Amp.	31
Circuit Check Between Unified Meter and A/C Amp. and BCM	32
Circuit Check Between BCM and ABS Actuator and Electric Unit (Control Unit)	32
ECM Circuit Check	33
TCM Circuit Check	33
Data Link Connector Circuit Check	34
Unified Meter and A/C Amp. Circuit Check	34
BCM Circuit Check	35
ABS Actuator and Electric Unit (Control Unit) Circuit Check	35
IPDM E/R Circuit Check	36
CAN Communication Circuit Check	37
IPDM E/R Ignition Relay Circuit Check	39
Component Inspection	39
ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION	39
CAN SYSTEM (TYPE 2)	40
System Description	40
Component Parts and Harness Connector Location	40
Wiring Diagram — CAN —	41
Work Flow	43
CHECK SHEET	44
CHECK SHEET RESULTS (EXAMPLE)	46
Circuit Check Between Data Link Connector and Unified Meter and A/C Amp.	51
Circuit Check Between Unified Meter and A/C Amp. and BCM	51
Circuit Check Between BCM and ABS Actuator and Electric Unit (Control Unit)	52
ECM Circuit Check	52
Data Link Connector Circuit Check	53
Unified Meter and A/C Amp. Circuit Check	53
BCM Circuit Check	54
ABS Actuator and Electric Unit (Control Unit) Circuit Check	54
IPDM E/R Circuit Check	55
CAN Communication Circuit Check	56
IPDM E/R Check	58
IPDM E/R Ignition Relay Circuit Check	58
Component Inspection	58
ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION	58
CAN SYSTEM (TYPE 3)	59
System Description	59
Component Parts and Harness Connector Location	59
Wiring Diagram — CAN —	60
Work Flow	62
CHECK SHEET	63
CHECK SHEET RESULTS (EXAMPLE)	65

Circuit Check Between Data Link Connector and Unified Meter and A/C Amp.	77	Circuit Check Between Unified Meter and A/C Amp. and BCM	129
Circuit Check Between Unified Meter and A/C Amp. and BCM	77	Circuit Check Between BCM and Low Tire Pressure Warning Control Unit	130
Circuit Check Between BCM and Low Tire Pressure Warning Control Unit	78	Circuit Check Between Low Tire Pressure Warning Control Unit and ABS Actuator and Electric Unit (Control Unit)	130
Circuit Check Between Low Tire Pressure Warning Control Unit and ABS Actuator and Electric Unit (Control Unit)	78	ECM Circuit Check	131
ECM Circuit Check	79	Data Link Connector Circuit Check	131
Data Link Connector Circuit Check	79	Unified Meter and A/C Amp. Circuit Check	132
Unified Meter and A/C Amp. Circuit Check	80	BCM Circuit Check	132
BCM Circuit Check	80	Low Tire Pressure Warning Control Unit Circuit Check	133
Low Tire Pressure Warning Control Unit Circuit Check	81	ABS Actuator and Electric Unit (Control Unit) Circuit Check	133
ABS Actuator and Electric Unit (Control Unit) Circuit Check	81	IPDM E/R Circuit Check	134
IPDM E/R Circuit Check	82	CAN Communication Circuit Check	135
CAN Communication Circuit Check	83	IPDM E/R Check	137
IPDM E/R Check	85	IPDM E/R Ignition Relay Circuit Check	137
IPDM E/R Ignition Relay Circuit Check	85	Component Inspection	138
Component Inspection	86	ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION	138
ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION	86	CAN SYSTEM (TYPE 6)	139
CAN SYSTEM (TYPE 4)	87	System Description	139
System Description	87	Component Parts and Harness Connector Location	139
Component Parts and Harness Connector Location	87	Wiring Diagram — CAN —	140
Wiring Diagram — CAN —	88	Work Flow	142
Work Flow	90	CHECK SHEET	143
CHECK SHEET	91	CHECK SHEET RESULTS (EXAMPLE)	145
CHECK SHEET RESULTS (EXAMPLE)	93	Circuit Check Between Data Link Connector and Unified Meter and A/C Amp.	151
Circuit Check Between Data Link Connector and Unified Meter and A/C Amp.	103	Circuit Check Between Unified Meter and A/C Amp. and BCM	151
Circuit Check Between Unified Meter and A/C Amp. and BCM	103	Circuit Check Between BCM and Steering Angle Sensor	152
Circuit Check Between BCM and ABS Actuator and Electric Unit (Control Unit)	103	Circuit Check Between Steering Angle Sensor and VDC/TCS/ABS Control Unit	152
ECM Circuit Check	104	ECM Circuit Check	153
Data Link Connector Circuit Check	105	Data Link Connector Circuit Check	153
Unified Meter and A/C Amp. Circuit Check	105	Unified Meter and A/C Amp. Circuit Check	154
BCM Circuit Check	106	BCM Circuit Check	154
ABS Actuator and Electric Unit (Control Unit) Circuit Check	106	Steering Angle Sensor Circuit Check	155
IPDM E/R Circuit Check	107	VDC/TCS/ABS Control Unit Circuit Check	155
CAN Communication Circuit Check	108	IPDM E/R Circuit Check	156
IPDM E/R Check	110	CAN Communication Circuit Check	157
IPDM E/R Ignition Relay Circuit Check	110	IPDM E/R Check	159
Component Inspection	110	IPDM E/R Ignition Relay Circuit Check	159
ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION	110	Component Inspection	160
CAN SYSTEM (TYPE 5)	111	ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION	160
System Description	111	CAN SYSTEM (TYPE 7)	161
Component Parts and Harness Connector Location	111	System Description	161
Wiring Diagram — CAN —	112	Component Parts and Harness Connector Location	161
Work Flow	114	Wiring Diagram — CAN —	162
CHECK SHEET	115	Work Flow	164
CHECK SHEET RESULTS (EXAMPLE)	117	CHECK SHEET	165
Circuit Check Between Data Link Connector and Unified Meter and A/C Amp.	129	CHECK SHEET RESULTS (EXAMPLE)	167
		Circuit Check Between Data Link Connector and Unified Meter and A/C Amp.	181

Circuit Check Between Unified Meter and A/C Amp. and BCM	181	Low Tire Pressure Warning Control Unit Circuit Check	185	A
Circuit Check Between BCM and Low Tire Pressure Warning Control Unit	182	Steering Angle Sensor Circuit Check	186	
Circuit Check Between Low Tire Pressure Warning Control Unit and Steering Angle Sensor	182	VDC/TCS/ABS Control Unit Circuit Check	186	B
Circuit Check Between Steering Angle Sensor and VDC/TCS/ABS Control Unit	183	IPDM E/R Circuit Check	187	
ECM Circuit Check	183	CAN Communication Circuit Check	188	C
Data Link Connector Circuit Check	184	IPDM E/R Check	190	
Unified Meter and A/C Amp. Circuit Check	184	IPDM E/R Ignition Relay Circuit Check	190	
BCM Circuit Check	185	Component Inspection	191	D
		ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION	191	

PRECAUTIONS

PF0:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

AKS0031A

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precautions for Battery Service

AKS003TZ

Before disconnecting the battery, lower both the driver and passenger windows. This will prevent any interference between the window edge and the vehicle when the door is opened/closed. During normal operation, the window slightly raises and lowers automatically to prevent any window to vehicle interference. The automatic window function will not work with the battery disconnected.


Precautions When Using CONSULT-II

AKS003M4

When connecting CONSULT-II to data link connector, connect them through CONSULT-II CONVERTER.

CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.



CHECK POINTS FOR USING CONSULT-II

1. Has CONSULT-II been used without connecting CONSULT-II CONVERTER on this vehicle?
 - If YES, GO TO 2.
 - If NO, GO TO 5.
2. Is there any indication other than indications relating to CAN communication system in the self-diagnosis results?
 - If YES, GO TO 3.
 - If NO, GO TO 4.
3. Based on self-diagnosis results unrelated to CAN communication, carry out the inspection.
4. Malfunctions may be detected in self-diagnosis depending on control units carrying out CAN communication. Therefore, erase the self-diagnosis results.
5. Diagnose CAN communication system. Refer to [LAN-6, "CAN Communication Unit"](#) .

Precautions For Trouble Diagnosis CAN SYSTEM


AKS000ZD

- Do not apply voltage of 7.0V or higher to the measurement terminals.
- Use the tester with its open terminal voltage being 7.0V or less.
- Be sure to turn ignition switch off and disconnect negative battery terminal before checking the circuit.


Precautions For Harness Repair CAN SYSTEM

AKS000ZE

- Solder the repaired parts, and wrap with tape. [Frays of twisted line must be within 110 mm (4.33 in)]



- Do not perform bypass wire connections for the repair parts. (The spliced wire will become separated and the characteristics of twisted line will be lost.)



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN COMMUNICATION

PFP:23710

System Description

AKS000ZF

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

AKS000ZG

Go to CAN system, when selecting your CAN system type from the following table.


Body type	Coupe							
Axle	2WD							
Engine	VQ35DE							
Transmission	A/T	M/T						
Brake control	TCS	ABS		TCS		VDC		
Low tire pressure warning system			×		×		×	
CAN system type	1	2	3	4	5	6	7	
CAN system trouble diagnosis	LAN-13	LAN-40	LAN-59	LAN-87	LAN-111	LAN-139	LAN-161	

×: Applicable

TYPE 1

System diagram

- Type1



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	Unified meter and A/C amp.	BCM	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T	R	R		R	
Engine torque signal	T	R			R	
Engine coolant temperature signal	T	R	R			
Accelerator pedal position signal	T	R			R	
Closed throttle position signal	T	R				
Wide open throttle position signal	T	R				
Battery voltage signal	T	R				
Stop lamp switch signal		R	T			
Fuel consumption monitor signal	T		R			
A/T self-diagnosis signal	R	T				

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Unified meter and A/C amp.	BCM	ABS actuator and electric unit (control unit)	IPDM E/R
A/T CHECK indicator lamp signal		T	R			
A/T position indicator signal		T	R		R	
Manual mode gear position signal		T	R			
ABS operation signal		R			T	
A/T shift schedule change demand signal		R			T	
A/C switch signal	R			T		
A/C compressor request signal	T					R
A/C compressor feedback signal	T		R			
Blower fan motor switch signal	R			T		
Cooling fan speed request signal	T					R
Position lights request signal			R	T		R
Low beam request signal				T		R
Low beam status signal	R					T
High beam request signal			R	T		R
High beam status signal	R					T
Vehicle speed signal			R		T	
	R	R	T	R		
Sleep request 1 signal			R	T		
Sleep request 2 signal				T		R
Wake up request 1 signal			R	T		
Door switch signal			R	T		R
Turn indicator signal			R	T		
Seat belt buckle switch signal			T	R		
Buzzer output signal			R	T		
Fuel level sensor signal	R		T			
Malfunction indicator lamp signal	T		R			
ASCD SET lamp signal	T		R			
ASCD operation signal	T	R				
ASCD CRUISE lamp signal	T		R			
ASCD OD cancel request signal	T	R				
Output shaft revolution signal	R	T				
Turbine revolution signal	R	T				
Front wiper request signal				T		R
Front wiper stop position signal				R		T
Rear window defogger switch signal				T		R
Rear window defogger control signal	R					T
Manual mode signal		R	T			
Not manual mode signal		R	T			
Manual mode shift up signal		R	T			
Manual mode shift down signal		R	T			
Manual mode indicator signal		T	R			
Hood switch signal				R		T

A
B
C
D
E
F
G
H
I
J
LAN

LAN

L
M

CAN COMMUNICATION


[CAN]

Signals	ECM	TCM	Unified meter and A/C amp.	BCM	ABS actuator and electric unit (control unit)	IPDM E/R
Theft warning horn request signal				T		R
Horn chirp signal				T		R
ABS warning lamp signal			R		T	
TCS OFF indicator lamp signal			R		T	
SLIP indicator lamp signal			R		T	
Brake warning lamp signal			R		T	


TYPE 2/TYPE3

System diagram

- Type2



- Type3



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Unified meter and A/C amp.	BCM	Low tire pressure warning control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T	R			R	
Engine coolant temperature signal	T	R				
Accelerator pedal position signal	T				R	
Fuel consumption monitor signal	T	R				
A/C switch signal	R		T			
A/C compressor request signal	T					R
A/C compressor feedback signal	T	R				
Blower fan motor switch signal	R		T			
Cooling fan speed request signal	T					R
Position lights request signal			R	T		R

CAN COMMUNICATION


[CAN]

Signals	ECM	Unified meter and A/C amp.	BCM	Low tire pressure warning control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Low beam request signal			T			R
Low beam status signal	R					T
High beam request signal		R	T			R
High beam status signal	R					T
Vehicle speed signal		R			T	
	R	T	R	R		
Sleep request 1 signal		R	T			
Sleep request 2 signal			T			R
Wake up request 1 signal		R	T			
Door switch signal		R	T			R
Turn indicator signal		R	T			
Seat belt buckle switch signal		T	R			
Buzzer output signal		R	T			
Fuel level sensor signal	R	T				
Malfunction indicator lamp signal	T	R				
ASCD SET lamp signal	T	R				
ASCD CRUISE lamp signal	T	R				
Front wiper request signal			T			R
Front wiper stop position signal			R			T
Rear window defogger switch signal			T			R
Rear window defogger control signal	R					T
Hood switch signal			R			T
Theft warning horn request signal			T			R
Horn chirp signal			T			R
Tire pressure signal		R		T		
ABS warning lamp signal		R			T	
Brake warning lamp signal		R			T	

A
B
C
D
E
F
G
H
I
J
LAN
L
M

TYPE 4/TYPES System diagram


- Type4



CAN COMMUNICATION

[CAN]

● Type5



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Unified meter and A/C amp.	BCM	Low tire pressure warning control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T	R			R	
Engine torque signal	T				R	
Engine coolant temperature signal	T	R				
Accelerator pedal position signal	T				R	
Fuel consumption monitor signal	T	R				
A/C switch signal	R		T			
A/C compressor request signal	T					R
A/C compressor feedback signal	T	R				
Blower fan motor switch signal	R		T			
Cooling fan speed request signal	T					R
Position lights request signal		R	T			R
Low beam request signal			T			R
Low beam status signal	R					T
High beam request signal		R	T			R
High beam status signal	R					T
Vehicle speed signal	R	R	R	R	T	
Sleep request 1 signal		R	T			
Sleep request 2 signal			T			R
Wake up request 1 signal		R	T			
Door switch signal		R	T			R
Turn indicator signal		R	T			
Seat belt buckle switch signal		T	R			
Buzzer output signal		R	T			
Fuel level sensor signal	R	T				
Malfunction indicator lamp signal	T	R				
ASCD SET lamp signal	T	R				
ASCD CRUISE lamp signal	T	R				
Front wiper request signal			T			R
Front wiper stop position signal			R			T
Rear window defogger switch signal			T			R

CAN COMMUNICATION


[CAN]

Signals	ECM	Unified meter and A/C amp.	BCM	Low tire pressure warning control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Rear window defogger control signal	R					T
Hood switch signal			R			T
Theft warning horn request signal			T			R
Horn chirp signal			T			R
Tire pressure signal		R		T		
ABS warning lamp signal		R			T	
TCS OFF indicator lamp signal		R			T	
SLIP indicator lamp signal		R			T	
Brake warning lamp signal		R			T	


TYPE 6/TYPE7

System diagram

- Type6



- Type7



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Unified meter and A/C amp.	BCM	Low tire pressure warning control unit	Steering angle sensor	VDC/TCS/ABS control unit	IPDM E/R
Engine speed signal	T	R				R	
Engine torque signal	T					R	
Engine coolant temperature signal	T	R					
Accelerator pedal position signal	T					R	
Fuel consumption monitor signal	T	R					
A/C switch signal	R		T				
A/C compressor request signal	T						R

CAN COMMUNICATION

[CAN]

Signals	ECM	Unified meter and A/C amp.	BCM	Low tire pressure warning control unit	Steering angle sensor	VDC/TCS/ABS control unit	IPDM E/R
A/C compressor feedback signal	T	R					
Blower fan motor switch signal	R		T				
Cooling fan speed request signal	T						R
Position lights request signal		R	T				R
Low beam request signal			T				R
Low beam status signal	R						T
High beam request signal		R	T				R
High beam status signal	R						T
Vehicle speed signal		R				T	
	R	T	R	R			
Sleep request 1 signal		R	T				
Sleep request 2 signal			T				R
Wake up request 1 signal		R	T				
Door switch signal		R	T				R
Turn indicator signal		R	T				
Seat belt buckle switch signal		T	R				
Buzzer output signal		R	T				
Fuel level sensor signal	R	T					
Malfunction indicator signal	T	R					
ASCD SET lamp signal	T	R					
ASCD CRUISE lamp signal	T	R					
Front wiper request signal			T				R
Front wiper stop position signal			R				T
Rear window defogger switch signal			T				R
Rear window defogger control signal	R						T
Hood switch signal			R				T
Theft warning horn request signal			T				R
Horn chirp signal			T				R
Steering angle sensor signal					T	R	
Tire pressure signal		R		T			
ABS warning lamp signal		R				T	
VDC OFF indicator lamp signal		R				T	
SLIP indicator lamp signal		R				T	
Brake warning lamp signal		R				T	

CAN SYSTEM (TYPE 1)

PFP:23710


System Description

AKS0035L

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

AKS0035M



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 1)



[CAN]

Wiring Diagram — CAN —


AKS0035N

LAN-CAN-01


▬ : DATA LINE



(M8)
W



(M48)
GY



(F6)
G

REFER TO THE FOLLOWING.

(F102) -SUPER MULTIPLE JUNCTION (SMJ)

(M3), (F101) -ELECTRICAL UNITS



TKWT0406E

CAN SYSTEM (TYPE 1)

[CAN]

LAN-CAN-02

▬ : DATA LINE



REFER TO THE FOLLOWING.

- (E108) -SUPER MULTIPLE JUNCTION (SMJ)
- (E51) -ELECTRICAL UNITS

TKWT0407E

Work Flow

- When there are no indications of "METER A/C AMP" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".

(Example)

	NISSAN CONSULT- II ENGINE START (NISSAN BASED VHCL) START (RENAULT BASED VHCL) SUB MODE LIGHT COPY	→	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th colspan="4">SELECT SYSTEM</th></tr> <tr><td colspan="4">ENGINE</td></tr> <tr><td colspan="4">A/T</td></tr> <tr><td colspan="4">ABS</td></tr> <tr><td colspan="4">AIR BAG</td></tr> <tr><td colspan="4">BCM</td></tr> <tr><td colspan="4">METER A/C AMP</td></tr> <tr><td colspan="4"> </td></tr> <tr><td colspan="4"> </td></tr> <tr><td colspan="2">BACK</td><td>LIGHT</td><td>COPY</td></tr> </table>	SELECT SYSTEM				ENGINE				A/T				ABS				AIR BAG				BCM				METER A/C AMP												BACK		LIGHT	COPY
SELECT SYSTEM																																											
ENGINE																																											
A/T																																											
ABS																																											
AIR BAG																																											
BCM																																											
METER A/C AMP																																											
BACK		LIGHT	COPY																																								

PKIA2093E

- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "METER A/C AMP", "BCM", and "ABS" displayed on CONSULT-II.

(Example)

	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th colspan="2">SELECT DIAG MODE</th></tr> <tr><td colspan="2">WORK SUPPORT</td></tr> <tr><td colspan="2">SELF-DIAG RESULTS</td></tr> <tr><td colspan="2">DATA MONITOR</td></tr> <tr><td colspan="2">DATA MONITOR (SPEC)</td></tr> <tr><td colspan="2">CAN DIAG SUPPORT MNTR</td></tr> <tr><td colspan="2">ACTIVE TEST</td></tr> <tr><td colspan="2"> </td></tr> <tr><td colspan="2">Scroll Down</td></tr> <tr><td>BACK</td><td>LIGHT COPY</td></tr> </table>	SELECT DIAG MODE		WORK SUPPORT		SELF-DIAG RESULTS		DATA MONITOR		DATA MONITOR (SPEC)		CAN DIAG SUPPORT MNTR		ACTIVE TEST				Scroll Down		BACK	LIGHT COPY	→	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th colspan="2">SELF-DIAG RESULTS</th></tr> <tr><td colspan="2">DTC RESULTS TIME</td></tr> <tr><td>CAN COMM CIRCUIT [U1000]</td><td style="text-align: center;">0</td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td colspan="2">F.F.DATA</td></tr> <tr><td>ERASE</td><td>PRINT</td></tr> <tr><td>MODE BACK</td><td>LIGHT COPY</td></tr> </table>	SELF-DIAG RESULTS		DTC RESULTS TIME		CAN COMM CIRCUIT [U1000]	0					F.F.DATA		ERASE	PRINT	MODE BACK	LIGHT COPY
SELECT DIAG MODE																																							
WORK SUPPORT																																							
SELF-DIAG RESULTS																																							
DATA MONITOR																																							
DATA MONITOR (SPEC)																																							
CAN DIAG SUPPORT MNTR																																							
ACTIVE TEST																																							
Scroll Down																																							
BACK	LIGHT COPY																																						
SELF-DIAG RESULTS																																							
DTC RESULTS TIME																																							
CAN COMM CIRCUIT [U1000]	0																																						
F.F.DATA																																							
ERASE	PRINT																																						
MODE BACK	LIGHT COPY																																						

PKIA8260E

- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "METER A/C AMP", "BCM", and "ABS" displayed on CONSULT-II.

(Example)

	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th colspan="2">SELECT DIAG MODE</th></tr> <tr><td colspan="2">WORK SUPPORT</td></tr> <tr><td colspan="2">SELF-DIAG RESULTS</td></tr> <tr><td colspan="2">DATA MONITOR</td></tr> <tr><td colspan="2">DATA MONITOR (SPEC)</td></tr> <tr><td colspan="2">CAN DIAG SUPPORT MNTR</td></tr> <tr><td colspan="2">ACTIVE TEST</td></tr> <tr><td colspan="2"> </td></tr> <tr><td colspan="2">Scroll Down</td></tr> <tr><td>BACK</td><td>LIGHT COPY</td></tr> </table>	SELECT DIAG MODE		WORK SUPPORT		SELF-DIAG RESULTS		DATA MONITOR		DATA MONITOR (SPEC)		CAN DIAG SUPPORT MNTR		ACTIVE TEST				Scroll Down		BACK	LIGHT COPY	→	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th colspan="2">CAN DIAG SUPPORT MNTR</th></tr> <tr><th colspan="2">ENGINE</th></tr> <tr><td> </td><td>PRSENT</td></tr> <tr><td>INITIAL DIAG</td><td>OK</td></tr> <tr><td>TRANSMIT DIAG</td><td>OK</td></tr> <tr><td>TCM</td><td>OK</td></tr> <tr><td>VDC/TCS/ABS</td><td>OK</td></tr> <tr><td>METER/M&A</td><td>OK</td></tr> <tr><td>ICC</td><td>UNKWVN</td></tr> <tr><td>BCM/SEC</td><td>OK</td></tr> <tr><td>IPDM E/R</td><td>OK</td></tr> <tr><td>AWD/4WD/e4WD</td><td>UNKWVN</td></tr> <tr><td>PRINT</td><td>Scroll Down</td></tr> <tr><td>MODE BACK</td><td>LIGHT COPY</td></tr> </table>	CAN DIAG SUPPORT MNTR		ENGINE			PRSENT	INITIAL DIAG	OK	TRANSMIT DIAG	OK	TCM	OK	VDC/TCS/ABS	OK	METER/M&A	OK	ICC	UNKWVN	BCM/SEC	OK	IPDM E/R	OK	AWD/4WD/e4WD	UNKWVN	PRINT	Scroll Down	MODE BACK	LIGHT COPY
SELECT DIAG MODE																																																			
WORK SUPPORT																																																			
SELF-DIAG RESULTS																																																			
DATA MONITOR																																																			
DATA MONITOR (SPEC)																																																			
CAN DIAG SUPPORT MNTR																																																			
ACTIVE TEST																																																			
Scroll Down																																																			
BACK	LIGHT COPY																																																		
CAN DIAG SUPPORT MNTR																																																			
ENGINE																																																			
	PRSENT																																																		
INITIAL DIAG	OK																																																		
TRANSMIT DIAG	OK																																																		
TCM	OK																																																		
VDC/TCS/ABS	OK																																																		
METER/M&A	OK																																																		
ICC	UNKWVN																																																		
BCM/SEC	OK																																																		
IPDM E/R	OK																																																		
AWD/4WD/e4WD	UNKWVN																																																		
PRINT	Scroll Down																																																		
MODE BACK	LIGHT COPY																																																		

PKIA8343E

- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-17, "CHECK SHEET"](#) .

- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks "v" onto the items with "No indication", "NG", or "UNKWVN" in the check sheet table. Refer to [LAN-17, "CHECK SHEET"](#) .

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual. So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

- According to the check sheet results (example), start inspection. Refer to [LAN-19, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

CAN SYSTEM (TYPE 1)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

A
B
C
D
E
F
G
H
I
J
LAN
L
M

LAN

CAN SYSTEM (TYPE 1)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
METER A/C AMP
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
METER A/C AMP
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

PKIA8678E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and data link connector. Refer to [LAN-30, "Circuit Check Between TCM and Data Link Connector"](#)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	UNKWN ✓	—
METER A/C AMP	No indication	—	UNKWN	UNKWN ✓	UNKWN ✓	—	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	—	—

PKIA8679E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 1)

[CAN]


Case 2

Check harness between data link connector and unified meter and A/C amp. Refer to [LAN-31, "Circuit Check Between Data Link Connector and Unified Meter and A/C Amp."](#)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	UNKWN ✓	—
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	—	—

PKIA8680E

/// : Malfunctioning part



PKIA2008E

CAN SYSTEM (TYPE 1)


[CAN]

Case 3

Check harness between unified meter and A/C amp. and BCM. Refer to [LAN-32, "Circuit Check Between Unified Meter and A/C Amp. and BCM"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—

PKIA8681E



LAN

CAN SYSTEM (TYPE 1)

[CAN]


Case 4

Check harness between BCM and ABS actuator and electric unit (control unit). Refer to [LAN-32, "Circuit Check Between BCM and ABS Actuator and Electric Unit \(Control Unit\)"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN ✓	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN ✓	—
BCM	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN ✓
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	—	—

PKIA8682E

//// : Malfunctioning part



PKIA2010E

CAN SYSTEM (TYPE 1)


[CAN]

Case 5

Check ECM circuit. Refer to [LAN-33, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	UNKWN	—	UNKWN	—
METER A/C AMP	No indication	—	UNKWN	UNKWN ✓	UNKWN	—	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN	—	—	—	—

PKIA8683E



LAN

CAN SYSTEM (TYPE 1)

[CAN]


Case 6

Check TCM circuit. Refer to [LAN-33, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—

PKIA8684E

▨ : Malfunctioning part



PKIA2012E

CAN SYSTEM (TYPE 1)


[CAN]

Case 7

Check data link connector circuit. Refer to [LAN-34, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—

PKIA8685E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 1)

[CAN]


Case 8

Check unified meter and A/C amp. circuit. Refer to LAN-34, "Unified Meter and A/C Amp. Circuit Check" .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	UNKWN	—
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—

PKIA8686E

//// : Malfunctioning part



PKIA2014E

CAN SYSTEM (TYPE 1)


[CAN]

Case 9

Check BCM circuit. Refer to [LAN-35, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—

PKIA8687E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 1)

[CAN]


Case 10

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-35, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN ✓	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN ✓	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN ✓	—
BCM	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
ABS	—	NG	UNKWN ✓	UNKWN	UNKWN	—	—	—	—

PKIA8688E

//// : Malfunctioning part



PKIA2016E

CAN SYSTEM (TYPE 1)


[CAN]

Case 11

Check IPDM E/R circuit. Refer to [LAN-36. "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN ✓
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—

PKIA8689E



Case 12

Check CAN communication circuit. Refer to [LAN-37. "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	—	UNKWN ✓	—
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	—
BCM	—	NG	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	—	—	UNKWN ✓
ABS	—	NG	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	—	—

PKIA8690E

A
B
C
D
E
F
G
H
I
J
LAN
L
M

Case 13

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-39, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UN KN W	UNKWN	UNKWN	UN KN W	UNKWN
A/T	-	NG	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-
METER A/C AMP	No indication	-	UNKWN	UNKWN	UN KN W	-	UNKWN	UN KN W	-
BCM	-	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-

PKIA8692E

Case 14

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-39, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	-	NG	UNKWN	UN KN W	-	UN KN W	-	UNKWN	-
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	-
BCM	-	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UN KN W	UNKWN	-	-	-	-

PKIA8691E

Circuit Check Between TCM and Data Link Connector

AKS0035P

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connector for damage, bend and loose connection (connector-side and harness-side).
 - Harness connector F102
 - Harness connector M72

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F102.
2. Check continuity between A/T assembly harness connector F6 terminals 3 (L), 8 (R) and harness connector F102 terminals 26H (L), 27H (R).

3 (L) – 26H (L) : Continuity should exist.
8 (R) – 27H (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M72 terminals 26H (L), 27H (R) and data link connector M8 terminals 6 (L), 14 (R).

26H (L) – 6 (L) : Continuity should exist.
27H (R) – 14 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-16, "Work Flow"](#) .
 NG >> Repair harness.



Circuit Check Between Data Link Connector and Unified Meter and A/C Amp.

AKS0035Q


1. CHECK HARNESS FOR OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector and unified meter and A/C amp. connector.
4. Check continuity between data link connector M8 terminals 6 (L), 14 (R) and unified meter and A/C amp. harness connector M48 terminals 1 (L), 11 (R).

6 (L) – 1 (L) : Continuity should exist.
14 (R) – 11 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-16, "Work Flow"](#) .
 NG >> Repair harness.



A
B
C
D
E
F
G
H
I
J

LAN

L
M

Circuit Check Between Unified Meter and A/C Amp. and BCM

1. CHECK HARNESS FOR OPEN CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following connectors.
 - ECM connector
 - Unified meter and A/C amp. connector
 - BCM connector
4. Check continuity between unified meter and A/C amp. harness connector M48 terminals 1 (L), 11 (R) and BCM harness connector M3 terminals 70 (L), 71 (R).

1 (L) – 70 (L) : Continuity should exist.

11 (R) – 71 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-16, "Work Flow"](#).
- NG >> Repair harness.



Circuit Check Between BCM and ABS Actuator and Electric Unit (Control Unit)

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connector for damage, bend and loose connection (connector-side and harness-side).
 - Harness connector M15
 - Harness connector E108

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect BCM connector and harness connector M15.
2. Check continuity between BCM harness connector M3 terminals 70 (L), 71 (R) and harness connector M15 terminals 2G (L), 7G (R).

70 (L) – 2G (L) : Continuity should exist.

71 (R) – 7G (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E108 terminals 2G (L), 7G (R) and ABS actuator and electric unit (control unit) harness connector E51 terminals 20 (L), 23 (R).

2G (L) – 20 (L) : Continuity should exist.
7G (R) – 23 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-16, "Work Flow"](#) .
 NG >> Repair harness.



AKS0035T

ECM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connector for damage, bend and loose connection (control module-side and harness-side).
 - ECM connector
 - Harness connector F102
 - Harness connector M72

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector F101 terminals 94 (L) and 86 (R).

94 (L) – 86 (R) : Approx. 108 – 132Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.



AKS0035U

TCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of A/T assembly for damage, bend and loose connection (control module-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

A
B
C
D
E
F
G
H
I
J
L
M

LAN


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F6 terminals 3 (L) and 8 (R).

3 (L) – 8 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace A/T assembly.
 NG >> Repair harness between A/T assembly and harness connector F102.



Data Link Connector Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M8 terminals 6 (L) and 14 (R).

6 (L) – 14 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-16, "Work Flow"](#) .
 NG >> Repair harness between data link connector and unified meter and A/C amp.



Unified Meter and A/C Amp. Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of unified meter and A/C amp. for damage, bend and loose connection (meter-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect unified meter and A/C amp. connector.
2. Check resistance between unified meter and A/C amp. harness connector M48 terminals 1 (L) and 11 (R).

1 (L) – 11 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. and BCM.



AKS0035X

BCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of BCM for damage, bend and loose connection (control module-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M3 terminals 70 (L) and 71 (R).

70 (L) – 71 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace BCM.
 NG >> Repair harness between BCM and harness connector M15.



AKS0035Y

ABS Actuator and Electric Unit (Control Unit) Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E51 terminals 20 (L) and 23 (R).

20 (L) – 23 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



AKS0035Z

IPDM E/R Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of IPDM E/R for damage, bend and loose connection (control module-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

48 (L) – 49 (R) : Approx. 108 – 132Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



CAN Communication Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connector for damage, bend and loose connection (control module-side, meter-side, control unit-side and harness-side).
 - ECM
 - A/T assembly
 - Unified meter and A/C amp.
 - BCM
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - ECM connector
 - A/T assembly connector
 - Harness connector F102
2. Check continuity between ECM harness connector F101 terminals 94 (L) and 86 (R).

94 (L) – 86 (R) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
 - Harness between ECM and A/T assembly.
 - Harness between ECM and harness connector F102.

**3. CHECK HARNESS FOR SHORT CIRCUIT**


Check continuity between ECM harness connector F101 terminals 94 (L), 86 (R) and ground.

94 (L) – ground : Continuity should not exist.

86 (R) – ground : Continuity should not exist.

OK or NG

- OK >> GO TO 4.
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
 - Harness between ECM and A/T assembly.
 - Harness between ECM and harness connector F102.



4. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - Unified meter and A/C amp. connector
 - BCM connector
 - Harness connector M15
- Check continuity between data link connector M8 terminals 6 (L) and 14 (R).


6 (L) – 14 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M72.
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and BCM.
- Harness between data link connector and harness connector M15.



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M8 terminals 6 (L), 14 (R) and ground.

6 (L) – ground : Continuity should not exist.


14 (R) – ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M72.
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and BCM.
- Harness between data link connector and harness connector M15.



6. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
- Check continuity between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).


48 (L) – 49 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit).
- Harness between IPDM E/R and harness connector E108.




7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E9 terminals 48 (L), 49 (R) and ground.

- 48 (L) – ground : Continuity should not exist.**
- 49 (R) – ground : Continuity should not exist.**

OK or NG

- OK >> GO TO 8.
- NG >> Check the following harnesses. If any harness is damaged, repair the harness.
 - Harness between IPDM E/R and ABS actuator and electric unit (control unit).
 - Harness between IPDM E/R and harness connector E108.



8. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

Check components inspection. Refer to [LAN-39, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-16, "Work Flow"](#).
- NG >> Replace ECM and/or IPDM E/R.

IPDM E/R Ignition Relay Circuit Check

AKS00362

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-29, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-11, "IGNITION POWER SUPPLY — IGNITION SW. IN "ON" AND/OR "START""](#).


Component Inspection

ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

AKS00363

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 48 and 49.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 – 86	108 - 132
IPDM E/R	48 – 49	



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 2)

PFP:23710


System Description

AKS00326

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

AKS00327



PKIA2221E

CAN SYSTEM (TYPE 2)




[CAN]

Wiring Diagram — CAN —

AKS00329

LAN-CAN-03

DATA LINE



REFER TO THE FOLLOWING.



(F102) -SUPER MULTIPLE JUNCTION (SMJ)

(M3), (F101) -ELECTRICAL UNITS

A
B
C
D
E
F
G
H
I
J
LAN
L
M

LAN-CAN-04

▬ : DATA LINE



REFER TO THE FOLLOWING.

(E108) -SUPER MULTIPLE JUNCTION (SMJ)

(E51) -ELECTRICAL UNITS

TKWT0409E


CAN SYSTEM (TYPE 2)

[CAN]


AKS00C5C

Work Flow


- When there are no indications of "METER A/C AMP" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "METER A/C AMP", "BCM", and "ABS" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "METER A/C AMP", "BCM", and "ABS" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-44, "CHECK SHEET"](#) .
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks "v" onto the items with "No indication", "NG", or "UNKWVN" in the check sheet table. Refer to [LAN-44, "CHECK SHEET"](#) .

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual. So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

- According to the check sheet results (example), start inspection. Refer to [LAN-46, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

CAN SYSTEM (TYPE 2)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	METER/M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	—	—	—	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

CAN SYSTEM (TYPE 2)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of METER A/C AMP SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS	Attach copy of ABS SELF-DIAG RESULTS
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of METER A/C AMP CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR	Attach copy of ABS CAN DIAG SUPPORT MNTR

PKIA8694E

A

B

C

D

E

F

G

H

I

J

LAN

L

M

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between data link connector and unified meter and A/C amp. Refer to [LAN-51, "Circuit Check Between Data Link Connector and Unified Meter and A/C Amp."](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	METER/M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN ✓	UNKWN ✓	-	UNKWN ✓
METER A/C AMP	No indication ✓	-	UNKWN	UNKWN	-	UNKWN	UNKWN	-
BCM	-	NG	UNKWN	UNKWN ✓	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN ✓	-	-	-	-

PKIB0305E




Case 2

Check harness between unified meter and A/C amp. and BCM. Refer to [LAN-51, "Circuit Check Between Unified Meter and A/C Amp. and BCM"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	METER/M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN ✓	-	UNKWN ✓
METER A/C AMP	No indication	-	UNKWN	UNKWN	-	UNKWN ✓	UNKWN ✓	-
BCM	-	NG	UNKWN	UNKWN ✓	UNKWN ✓	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN ✓	-	-	-	-

PKIB0306E



CAN SYSTEM (TYPE 2)


[CAN]

Case 3

Check harness between BCM and ABS actuator and electric unit (control unit). Refer to [LAN-52, "Circuit Check Between BCM and ABS Actuator and Electric Unit \(Control Unit\)"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	METER/M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	—	—	—	—

PKIB0307E




Case 4

Check ECM circuit. Refer to [LAN-52, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	METER/M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	—	—	—	—

PKIB0308E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 5

Check data link connector circuit. Refer to [LAN-53, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	METER/M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	-	NG	UNKW	-	UNKW	UNKW	-	UNKW
METER A/C AMP	No indication ✓	-	UNKW	UNKW	-	UNKW	UNKW	-
BCM	-	NG	UNKW	UNKW	UNKW	-	-	UNKW
ABS	-	NG	UNKW	UNKW	-	-	-	-

PKIB0309E




Case 6

Check unified meter and A/C amp. circuit. Refer to [LAN-53, "Unified Meter and A/C Amp. Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	METER/M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	-	NG	UNKW	-	UNKW ✓	UNKW	-	UNKW
METER A/C AMP	No indication ✓	-	UNKW	UNKW	-	UNKW	UNKW	-
BCM	-	NG	UNKW	UNKW	UNKW ✓	-	-	UNKW
ABS	-	NG	UNKW	UNKW	-	-	-	-

PKIB0310E




Case 7

Check BCM circuit. Refer to [LAN-54, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	METER/M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN
METER A/C AMP	No indication	-	UNKWN	UNKWN	-	UNKWN	UNKWN	-
BCM	-	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-

PKIB0311E




Case 8

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-54, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	METER/M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN
METER A/C AMP	No indication	-	UNKWN	UNKWN	-	UNKWN	UNKWN	-
BCM	-	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-

PKIB0312E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 2)


[CAN]

Case 9

Check IPDM E/R circuit. Refer to [LAN-55, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	METER/M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	—	—	—	—

PKIB0313E



Case 10

Check CAN communication circuit. Refer to [LAN-56, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	METER/M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	—	—	—	—

PKIB0314E

Case 11

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-58, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	METER/M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	—	—	—	—

PKIB0315E

Case 12

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-58, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				IPDM E/R
				ECM	METER/M&A	BCM/SEC	VDC/TCS /ABS	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN ✓	—	—	—	—

PKIB0316E

Circuit Check Between Data Link Connector and Unified Meter and A/C Amp.

AKS0032C


1. CHECK HARNESS FOR OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector and unified meter and A/C amp. connector.
4. Check continuity between data link connector M8 terminals 6 (L), 14 (R) and unified meter and A/C amp. harness connector M48 terminals 1 (L), 11 (R).

6 (L) – 1 (L) : Continuity should exist.
14 (R) – 11 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-43, "Work Flow"](#) .
- NG >> Repair harness.



Circuit Check Between Unified Meter and A/C Amp. and BCM

AKS0033F


1. CHECK HARNESS FOR OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following connectors.
 - ECM connector
 - Unified meter and A/C amp. connector
 - BCM connector
4. Check continuity between unified meter and A/C amp. harness connector M48 terminals 1 (L), 11 (R) and BCM harness connector M3 terminals 70 (L), 71 (R).

1 (L) – 70 (L) : Continuity should exist.
11 (R) – 71 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-43, "Work Flow"](#) .
- NG >> Repair harness.



Circuit Check Between BCM and ABS Actuator and Electric Unit (Control Unit)

AKS0033G

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connector for damage, bend and loose connection (connector-side and harness-side).
 - Harness connector M15
 - Harness connector E108

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect BCM connector and harness connector M15.
2. Check continuity between BCM harness connector M3 terminals 70 (L), 71 (R) and harness connector M15 terminals 2G (L), 7G (R).

70 (L) – 2G (L) : Continuity should exist.

71 (R) – 7G (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E108 terminals 2G (L), 7G (R) and ABS actuator and electric unit (control unit) harness connector E51 terminals 20 (L), 23 (R).

2G (L) – 20 (L) : Continuity should exist.

7G (R) – 23 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-43, "Work Flow"](#) .
 NG >> Repair harness.



ECM Circuit Check

AKS0032D

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connector for damage, bend and loose connection (control module-side and harness-side).
 - ECM connector
 - Harness connector F102
 - Harness connector M72

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ECM connector.
2. Check resistance between ECM harness connector F101 terminals 94 (L) and 86 (R).

94 (L) – 86 (R)

: Approx. 108 – 132Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and data link connector.



Data Link Connector Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


Check resistance between data link connector M8 terminals 6 (L) and 14 (R).

6 (L) – 14 (R)

: Approx. 54 – 66Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-43, "Work Flow"](#) .
 NG >> Repair harness between data link connector and unified meter and A/C amp.



Unified Meter and A/C Amp. Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of unified meter and A/C amp. for damage, bend and loose connection (meter-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect unified meter and A/C amp. connector.
2. Check resistance between unified meter and A/C amp. harness connector M48 terminals 1 (L) and 11 (R).

1 (L) – 11 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. and BCM.



AKS0032G

BCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of BCM for damage, bend and loose connection (control module-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M3 terminals 70 (L) and 71 (R).

70 (L) – 71 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace BCM.
 NG >> Repair harness between BCM and harness connector M15.



AKS0032H

ABS Actuator and Electric Unit (Control Unit) Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E51 terminals 20 (L) and 23 (R).

20 (L) – 23 (R)

: Approx. 54 – 66Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



AKS0032I

IPDM E/R Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of IPDM E/R for damage, bend and loose connection (control module-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

48 (L) – 49 (R)

: Approx. 108 – 132Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



LKIA0030E

CAN Communication Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connector for damage, bend and loose connection (control module-side, meter-side, control unit-side and harness-side).
 - ECM
 - Unified meter and A/C amp.
 - BCM
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector F102.
2. Check continuity between ECM harness connector F101 terminals 94 (L) and 86 (R).

94 (L) – 86 (R) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector F102.



3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between ECM harness connector F101 terminals 94 (L), 86 (R) and ground.

94 (L) – ground : Continuity should not exist.

86 (R) – ground : Continuity should not exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness between ECM and harness connector F102.



4. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - Unified meter and A/C amp. connector
 - BCM connector
 - Harness connector M15
- Check continuity between data link connector M8 terminals 6 (L) and 14 (R).


6 (L) – 14 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M72.
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and BCM.
- Harness between data link connector and harness connector M15.



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M8 terminals 6 (L), 14 (R) and ground.

6 (L) – ground : Continuity should not exist.


14 (R) – ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M72.
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and BCM.
- Harness between data link connector and harness connector M15.



6. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
- Check continuity between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).


48 (L) – 49 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit).
- Harness between IPDM E/R and harness connector E108.



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E9 terminals 48 (L), 49 (R) and ground.

48 (L) – ground : Continuity should not exist.


49 (R) – ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit).
- Harness between IPDM E/R and harness connector E108.



8. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

Check components inspection. Refer to [LAN-58, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-43, "Work Flow"](#).

NG >> Replace ECM and/or IPDM E/R.

IPDM E/R Check

1. CHECK IPDM E/R

AKS0033H

1. Turn ignition switch ON and then OFF.
2. Check for illuminated parking lamps and tail lamps.

Parking lamps and tail lamps should not illuminate.

OK or NG

OK >> Replace ABS actuator and electric unit (control unit).

NG >> Replace IPDM E/R.

IPDM E/R Ignition Relay Circuit Check

AKS0032K

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-29, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-11, "IGNITION POWER SUPPLY — IGNITION SW. IN "ON" AND/OR "START" "](#).


Component Inspection

ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

AKS0032L

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 48 and 49.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 – 86	108 - 132
IPDM E/R	48 – 49	



CAN SYSTEM (TYPE 3)

PFP:23710


System Description

AKS0033Y

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

AKS0033Z



A
B
C
D
E
F
G
H
I
J

LAN

L
M

CAN SYSTEM (TYPE 3)


[CAN]

AKS00340




Wiring Diagram — CAN —

LAN-CAN-05

▬ : DATA LINE



NEXT PAGE



REFER TO THE FOLLOWING.

(F102) -SUPER MULTIPLE JUNCTION (SMJ)

(M3), (F101) -ELECTRICAL UNITS



TKWT0410E

CAN SYSTEM (TYPE 3)

[CAN]

LAN-CAN-06

▬ : DATA LINE



REFER TO THE FOLLOWING.

(E108) -SUPER MULTIPLE JUNCTION (SMJ)

(E51) -ELECTRICAL UNITS

TKWT0411E

CAN SYSTEM (TYPE 3)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	TIRE-P	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	UNKWN	—	—	—	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

PKIB0317E

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 3)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
METER A/C AMP
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
AIR PRESSURE
MONITOR
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
METER A/C AMP
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
AIR PRESSURE
MONITOR
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

PKIB0318E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between data link connector and unified meter and A/C amp. Refer to [LAN-77, "Circuit Check Between Data Link Connector and Unified Meter and A/C Amp."](#)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	TIRE-P	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN ✓	—	—	UNKWN ✓
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN ✓	UNKWN	—	—	—	UNKWN
AIR PRESSURE MONITOR	No indication ✓	NG	UNKWN	—	UNKWN	—	—	—	—
ABS	—	NG	UNKWN	UNKWN ✓	—	—	—	—	—

PKIB0319E



LAN

CAN SYSTEM (TYPE 3)

[CAN]


Case 2

Check harness between unified meter and A/C amp. and BCM. Refer to [LAN-77, "Circuit Check Between Unified Meter and A/C Amp. and BCM"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	TIRE-P	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	—	—	UNKWN ✓
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	—
BCM	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	—	UNKWN
AIR PRESSURE MONITOR	No indication ✓	NG	UNKWN	—	UNKWN	—	—	—	—
ABS	—	NG	UNKWN	UNKWN ✓	—	—	—	—	—

PKIB0320E

/// : Malfunctioning part



PKIA2028E

CAN SYSTEM (TYPE 3)


[CAN]

Case 3

Check harness between BCM and Low Tire Pressure Warning Control Unit. Refer to [LAN-78, "Circuit Check Between BCM and Low Tire Pressure Warning Control Unit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	TIRE-P	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	UNKWN	—	—	—	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—

PKIB0321E



PKIA2029E

LAN

CAN SYSTEM (TYPE 3)

[CAN]


Case 4

Check harness between Low Tire Pressure Warning Control Unit and ABS Actuator and Electric Unit (Control Unit). Refer to [LAN-78, "Circuit Check Between Low Tire Pressure Warning Control Unit and ABS Actuator and Electric Unit \(Control Unit\)"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	TIRE-P	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN ✓
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN ✓
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	UNKWN	—	—	—	—
ABS	—	NG	UNKWN	UNKWN ✓	—	—	—	—	—

PKIB0322E

/// : Malfunctioning part



PKIA2030E

CAN SYSTEM (TYPE 3)


[CAN]

Case 5

Check ECM circuit. Refer to [LAN-79, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	TIRE-P	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW ^N	—	UNKW ^N	UNKW ^N	—	—	UNKW ^N
METER A/C AMP	No indication	—	UNKW ^N	UNKW ^N	—	UNKW ^N	UNKW ^N	UNKW ^N	—
BCM	—	NG	UNKW ^N	UNKW ^N	UNKW ^N	—	—	—	UNKW ^N
AIR PRESSURE MONITOR	No indication	NG	UNKW ^N	—	UNKW ^N	—	—	—	—
ABS	—	NG	UNKW ^N	UNKW ^N	—	—	—	—	—

PKIB0323E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 3)

[CAN]


Case 6

Check data link connector circuit. Refer to [LAN-79, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	TIRE-P	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
AIR PRESSURE MONITOR	No indication ✓	NG	UNKWN	—	UNKWN	—	—	—	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—

PKIB0324E

▨ : Malfunctioning part



PKIA2032E

CAN SYSTEM (TYPE 3)


[CAN]

Case 7

Check unified meter and A/C amp. circuit. Refer to [LAN-80, "Unified Meter and A/C Amp. Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	TIRE-P	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	UNKWN	—	—	—	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—

PKIB0325E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 3)

[CAN]


Case 8

Check BCM circuit. Refer to [LAN-80, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	TIRE-P	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	UNKWN	—	—	—	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—

PKIB0326E

▨ : Malfunctioning part



PKIA2034E

CAN SYSTEM (TYPE 3)


[CAN]

Case 9

Check Low Tire Pressure Warning Control Unit circuit. Refer to [LAN-81, "Low Tire Pressure Warning Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	TIRE-P	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
AIR PRESSURE MONITOR	No indication ✓	NG	UNKWN	—	UNKWN	—	—	—	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—

PKIB0327E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 3)

[CAN]


Case 10

Check ABS actuator and electric unit. Refer to [LAN-81, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	TIRE-P	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	UNKWN	—	—	—	—
ABS	—	NG	UNKWN ✓	UNKWN	—	—	—	—	—

PKIB0328E

//// : Malfunctioning part



PKIA2036E

CAN SYSTEM (TYPE 3)


[CAN]

Case 11

Check IPDM E/R circuit. Refer to [LAN-82, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	TIRE-P	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN ✓
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN ✓
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	UNKWN	—	—	—	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—

PKIB0329E



Case 12

Check CAN communication circuit. Refer to [LAN-83, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	TIRE-P	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	—	—	UNKWN ✓
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	—
BCM	—	NG	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	—	UNKWN ✓
AIR PRESSURE MONITOR	No indication ✓	NG	UNKWN	—	UNKWN	—	—	—	—
ABS	—	NG	UNKWN ✓	UNKWN ✓	—	—	—	—	—

PKIB0330E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 3)

[CAN]

Case 13

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-85, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	TIRE-P	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	UNKWN	—	—	—	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—

PKIB0331E

Case 14

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-85, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	TIRE-P	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	UNKWN	—	—	—	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—

PKIB0332E

Circuit Check Between Data Link Connector and Unified Meter and A/C Amp.

AKS00342

1. CHECK HARNESS FOR OPEN CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector and unified meter and A/C amp. connector.
4. Check continuity between data link connector M8 terminals 6 (L), 14 (R) and unified meter and A/C amp. harness connector M48 terminals 1 (L), 11 (R).

6 (L) – 1 (L) : Continuity should exist.

14 (R) – 11 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-62, "Work Flow"](#).
- NG >> Repair harness.



Circuit Check Between Unified Meter and A/C Amp. and BCM

AKS00343

1. CHECK HARNESS FOR OPEN CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following connectors.
 - ECM connector
 - Unified meter and A/C amp. connector
 - BCM connector
4. Check continuity between unified meter and A/C amp. harness connector M48 terminals 1 (L), 11 (R) and BCM harness connector M3 terminals 70 (L), 71 (R).

1 (L) – 70 (L) : Continuity should exist.

11 (R) – 71 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-62, "Work Flow"](#).
- NG >> Repair harness.



A
B
C
D
E
F
G
H
I
J
L
M

LAN

Circuit Check Between BCM and Low Tire Pressure Warning Control Unit

AKS0034G

1. CHECK HARNESS FOR OPEN CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following connectors.
 - ECM connector
 - BCM connector
 - Low tire pressure warning control unit connector
4. Check continuity between BCM harness connector M3 terminals 70 (L), 71 (R) and low tire pressure warning control unit harness connector M77 terminals 9 (L), 21 (R).

70 (L) – 9 (L) : Continuity should exist.

71 (R) – 21 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-62, "Work Flow"](#) .
- NG >> Repair harness.



Circuit Check Between Low Tire Pressure Warning Control Unit and ABS Actuator and Electric Unit (Control Unit)

AKS00344

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connector for damage, bend and loose connection (connector-side and harness-side).
 - Harness connector M15
 - Harness connector E108

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect low tire pressure warning control unit connector and harness connector M15.
2. Check continuity between low tire pressure warning control unit harness connector M77 terminals 9 (L), 21 (R) and harness connector M15 terminals 2G (L), 7G (R).

9 (L) – 2G (L) : Continuity should exist.

21 (R) – 7G (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E108 terminals 2G (L), 7G (R) and ABS actuator and electric unit (control unit) harness connector E51 terminals 20 (L), 23 (R).

2G (L) – 20 (L) : Continuity should exist.
7G (R) – 23 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-62, "Work Flow"](#) .
 NG >> Repair harness.



AKS00345

ECM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connector for damage, bend and loose connection (control module-side and harness-side).
 - ECM connector
 - Harness connector F102
 - Harness connector M72

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector F101 terminals 94 (L) and 86 (R).

94 (L) – 86 (R) : Approx. 108 – 132Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and data link connector.



AKS00346

Data Link Connector Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M8 terminals 6 (L) and 14 (R).

6 (L) – 14 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-62, "Work Flow"](#) .
 NG >> Repair harness between data link connector and unified meter and A/C amp.



AKS00347

Unified Meter and A/C Amp. Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of unified meter and A/C amp. for damage, bend and loose connection (meter-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect unified meter and A/C amp. connector.
2. Check resistance between unified meter and A/C amp. harness connector M48 terminals 1 (L) and 11 (R).

1 (L) – 11 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. and BCM.



AKS00348

BCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of BCM for damage, bend and loose connection (control module-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M3 terminals 70 (L) and 71 (R).

70 (L) – 71 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace BCM.
 NG >> Repair harness between BCM and low tire pressure warning control unit.



Low Tire Pressure Warning Control Unit Circuit Check

AKS00349

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of low tire pressure warning control unit for damage, bend and loose connection (control unit-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect low tire pressure warning control unit connector.
2. Check resistance between low tire pressure warning control unit harness connector M77 terminals 9 (L) and 21 (R).

9 (L) – 21 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace low tire pressure warning control unit.
 NG >> Repair harness between low tire pressure warning control unit and harness connector M15.



ABS Actuator and Electric Unit (Control Unit) Circuit Check

AKS0034A

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E51 terminals 20 (L) and 23 (R).

20 (L) – 23 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



AKS0034B

IPDM E/R Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of IPDM E/R for damage, bend and loose connection (control module-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

48 (L) – 49 (R) : Approx. 108 – 132Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



CAN Communication Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connector for damage, bend and loose connection (control module-side, meter-side, control unit-side and harness-side).
 - ECM
 - Unified meter and A/C amp.
 - BCM
 - Low tire pressure warning control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector F102.
2. Check continuity between ECM harness connector F101 terminals 94 (L) and 86 (R).

94 (L) – 86 (R) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector F102.

**3. CHECK HARNESS FOR SHORT CIRCUIT**


Check continuity between ECM harness connector F101 terminals 94 (L), 86 (R) and ground.

94 (L) – ground : Continuity should not exist.

86 (R) – ground : Continuity should not exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness between ECM and harness connector F102.



4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - Unified meter and A/C amp. connector
 - BCM connector
 - Low tire pressure warning control unit connector
 - Harness connector M15
2. Check continuity between data link connector M8 terminals 6 (L) and 14 (R).


6 (L) – 14 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M72.
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and BCM.
- Harness between data link connector and low tire pressure warning control unit.
- Harness between data link connector and harness connector M15.



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M8 terminals 6 (L), 14 (R) and ground.

6 (L) – ground : Continuity should not exist.


14 (R) – ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M72.
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and BCM.
- Harness between data link connector and low tire pressure warning control unit.
- Harness between data link connector and harness connector M15.



6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).


48 (L) – 49 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit).
- Harness between IPDM E/R and harness connector E108.



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E9 terminals 48 (L), 49 (R) and ground.

48 (L) – ground : Continuity should not exist.


49 (R) – ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit).
- Harness between IPDM E/R and harness connector E108.



8. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

Check components inspection. Refer to [LAN-86, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-62, "Work Flow"](#).

NG >> Replace ECM and/or IPDM E/R.

IPDM E/R Check

1. CHECK IPDM E/R

1. Turn ignition switch ON and then OFF.
2. Check for illuminated parking lamps and tail lamps.

Parking lamps and tail lamps should not illuminate.

OK or NG

OK >> Replace ABS actuator and electric unit (control unit).

NG >> Replace IPDM E/R.

IPDM E/R Ignition Relay Circuit Check


Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-29, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-11, "IGNITION POWER SUPPLY — IGNITION SW. IN "ON" AND/OR "START" "](#).

Component Inspection ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 48 and 49.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	48 - 49	



CAN SYSTEM (TYPE 4)

PFP:23710


System Description

AKS00364

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

AKS00365



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 4)



[CAN]

AKS00366


LAN-CAN-03

▬ : DATA LINE

Wiring Diagram — CAN —



(M8)
W



(M48)
GY



REFER TO THE FOLLOWING.

(F102) -SUPER MULTIPLE JUNCTION (SMJ)

(M3), (F101) -ELECTRICAL UNITS



TKWT0408E

CAN SYSTEM (TYPE 4)

[CAN]

LAN-CAN-04

▬ : DATA LINE



REFER TO THE FOLLOWING.

E108 -SUPER MULTIPLE JUNCTION (SMJ)

E51 -ELECTRICAL UNITS

TKWT0409E

Work Flow

- When there are no indications of "METER A/C AMP" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".

(Example)	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td colspan="2" style="text-align: center;">NISSAN</td></tr> <tr><td colspan="2" style="text-align: center;">CONSULT- II</td></tr> <tr><td colspan="2" style="text-align: center;">ENGINE</td></tr> <tr><td colspan="2" style="text-align: center;">START (NISSAN BASED VHCL)</td></tr> <tr><td colspan="2" style="text-align: center;">START (RENAULT BASED VHCL)</td></tr> <tr><td colspan="2" style="text-align: center;">SUB MODE</td></tr> <tr> <td style="width: 50%;"></td> <td style="width: 50%; text-align: center;">LIGHT COPY</td> </tr> </table>	NISSAN		CONSULT- II		ENGINE		START (NISSAN BASED VHCL)		START (RENAULT BASED VHCL)		SUB MODE			LIGHT COPY	➔	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td colspan="2" style="text-align: center;">SELECT SYSTEM</td></tr> <tr><td colspan="2" style="text-align: center;">ENGINE</td></tr> <tr><td colspan="2" style="text-align: center;">A/T</td></tr> <tr><td colspan="2" style="text-align: center;">ABS</td></tr> <tr><td colspan="2" style="text-align: center;">AIR BAG</td></tr> <tr><td colspan="2" style="text-align: center;">BCM</td></tr> <tr><td colspan="2" style="text-align: center;">METER A/C AMP</td></tr> <tr><td colspan="2" style="text-align: center;"> </td></tr> <tr> <td style="width: 50%;"></td> <td style="width: 50%; text-align: center;">BACK LIGHT COPY</td> </tr> </table>	SELECT SYSTEM		ENGINE		A/T		ABS		AIR BAG		BCM		METER A/C AMP					BACK LIGHT COPY	PKIA2093E
NISSAN																																				
CONSULT- II																																				
ENGINE																																				
START (NISSAN BASED VHCL)																																				
START (RENAULT BASED VHCL)																																				
SUB MODE																																				
	LIGHT COPY																																			
SELECT SYSTEM																																				
ENGINE																																				
A/T																																				
ABS																																				
AIR BAG																																				
BCM																																				
METER A/C AMP																																				
	BACK LIGHT COPY																																			

- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "METER A/C AMP", "BCM", and "ABS" displayed on CONSULT-II.

(Example)	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td colspan="2" style="text-align: center;">SELECT DIAG MODE</td></tr> <tr><td colspan="2" style="text-align: center;">WORK SUPPORT</td></tr> <tr><td colspan="2" style="text-align: center;">SELF-DIAG RESULTS</td></tr> <tr><td colspan="2" style="text-align: center;">DATA MONITOR</td></tr> <tr><td colspan="2" style="text-align: center;">DATA MONITOR (SPEC)</td></tr> <tr><td colspan="2" style="text-align: center;">CAN DIAG SUPPORT MNTR</td></tr> <tr><td colspan="2" style="text-align: center;">ACTIVE TEST</td></tr> <tr><td colspan="2" style="text-align: center;"> </td></tr> <tr> <td style="width: 50%;"></td> <td style="width: 50%; text-align: center;">Scroll Down</td> </tr> <tr> <td style="width: 50%;"></td> <td style="width: 50%; text-align: center;">BACK LIGHT COPY</td> </tr> </table>	SELECT DIAG MODE		WORK SUPPORT		SELF-DIAG RESULTS		DATA MONITOR		DATA MONITOR (SPEC)		CAN DIAG SUPPORT MNTR		ACTIVE TEST					Scroll Down		BACK LIGHT COPY	➔	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td colspan="2" style="text-align: center;">SELF-DIAG RESULTS</td></tr> <tr><td colspan="2" style="text-align: center;">DTC RESULTS TIME</td></tr> <tr> <td style="width: 50%;">CAN COMM CIRCUIT [U1000]</td> <td style="width: 50%; text-align: center;">0</td> </tr> <tr><td colspan="2" style="text-align: center;"> </td></tr> <tr><td colspan="2" style="text-align: center;"> </td></tr> <tr><td colspan="2" style="text-align: center;"> </td></tr> <tr> <td style="width: 50%;"></td> <td style="width: 50%; text-align: center;">F.F.DATA</td> </tr> <tr> <td style="width: 50%; text-align: center;">ERASE</td> <td style="width: 50%; text-align: center;">PRINT</td> </tr> <tr> <td style="width: 50%; text-align: center;">MODE BACK</td> <td style="width: 50%; text-align: center;">LIGHT COPY</td> </tr> </table>	SELF-DIAG RESULTS		DTC RESULTS TIME		CAN COMM CIRCUIT [U1000]	0								F.F.DATA	ERASE	PRINT	MODE BACK	LIGHT COPY	PKIA8260E
SELECT DIAG MODE																																										
WORK SUPPORT																																										
SELF-DIAG RESULTS																																										
DATA MONITOR																																										
DATA MONITOR (SPEC)																																										
CAN DIAG SUPPORT MNTR																																										
ACTIVE TEST																																										
	Scroll Down																																									
	BACK LIGHT COPY																																									
SELF-DIAG RESULTS																																										
DTC RESULTS TIME																																										
CAN COMM CIRCUIT [U1000]	0																																									
	F.F.DATA																																									
ERASE	PRINT																																									
MODE BACK	LIGHT COPY																																									

- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "METER A/C AMP", "BCM", and "ABS" displayed on CONSULT-II.

(Example)	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td colspan="2" style="text-align: center;">SELECT DIAG MODE</td></tr> <tr><td colspan="2" style="text-align: center;">WORK SUPPORT</td></tr> <tr><td colspan="2" style="text-align: center;">SELF-DIAG RESULTS</td></tr> <tr><td colspan="2" style="text-align: center;">DATA MONITOR</td></tr> <tr><td colspan="2" style="text-align: center;">DATA MONITOR (SPEC)</td></tr> <tr><td colspan="2" style="text-align: center;">CAN DIAG SUPPORT MNTR</td></tr> <tr><td colspan="2" style="text-align: center;">ACTIVE TEST</td></tr> <tr><td colspan="2" style="text-align: center;"> </td></tr> <tr> <td style="width: 50%;"></td> <td style="width: 50%; text-align: center;">Scroll Down</td> </tr> <tr> <td style="width: 50%;"></td> <td style="width: 50%; text-align: center;">BACK LIGHT COPY</td> </tr> </table>	SELECT DIAG MODE		WORK SUPPORT		SELF-DIAG RESULTS		DATA MONITOR		DATA MONITOR (SPEC)		CAN DIAG SUPPORT MNTR		ACTIVE TEST					Scroll Down		BACK LIGHT COPY	➔	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td colspan="2" style="text-align: center;">CAN DIAG SUPPORT MNTR</td></tr> <tr><td colspan="2" style="text-align: center;">ENGINE</td></tr> <tr> <td style="width: 50%;"></td> <td style="width: 50%; text-align: center;">PRSENT</td> </tr> <tr> <td>INITIAL DIAG</td> <td style="text-align: center;">OK</td> </tr> <tr> <td>TRANSMIT DIAG</td> <td style="text-align: center;">OK</td> </tr> <tr> <td>TCM</td> <td style="text-align: center;">OK</td> </tr> <tr> <td>VDC/TCS/ABS</td> <td style="text-align: center;">OK</td> </tr> <tr> <td>METER/M&A</td> <td style="text-align: center;">OK</td> </tr> <tr> <td>ICC</td> <td style="text-align: center;">UNKWVN</td> </tr> <tr> <td>BCM/SEC</td> <td style="text-align: center;">OK</td> </tr> <tr> <td>IPDM E/R</td> <td style="text-align: center;">OK</td> </tr> <tr> <td>AWD/4WD/e4WD</td> <td style="text-align: center;">UNKWVN</td> </tr> <tr> <td style="text-align: center;">PRINT</td> <td style="text-align: center;">Scroll Down</td> </tr> <tr> <td style="text-align: center;">MODE BACK</td> <td style="text-align: center;">LIGHT COPY</td> </tr> </table>	CAN DIAG SUPPORT MNTR		ENGINE			PRSENT	INITIAL DIAG	OK	TRANSMIT DIAG	OK	TCM	OK	VDC/TCS/ABS	OK	METER/M&A	OK	ICC	UNKWVN	BCM/SEC	OK	IPDM E/R	OK	AWD/4WD/e4WD	UNKWVN	PRINT	Scroll Down	MODE BACK	LIGHT COPY	PKIA8343E
SELECT DIAG MODE																																																				
WORK SUPPORT																																																				
SELF-DIAG RESULTS																																																				
DATA MONITOR																																																				
DATA MONITOR (SPEC)																																																				
CAN DIAG SUPPORT MNTR																																																				
ACTIVE TEST																																																				
	Scroll Down																																																			
	BACK LIGHT COPY																																																			
CAN DIAG SUPPORT MNTR																																																				
ENGINE																																																				
	PRSENT																																																			
INITIAL DIAG	OK																																																			
TRANSMIT DIAG	OK																																																			
TCM	OK																																																			
VDC/TCS/ABS	OK																																																			
METER/M&A	OK																																																			
ICC	UNKWVN																																																			
BCM/SEC	OK																																																			
IPDM E/R	OK																																																			
AWD/4WD/e4WD	UNKWVN																																																			
PRINT	Scroll Down																																																			
MODE BACK	LIGHT COPY																																																			

- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-91, "CHECK SHEET"](#) .
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks "v" onto the items with "No indication", "NG", or "UNKWVN" in the check sheet table. Refer to [LAN-91, "CHECK SHEET"](#) .

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual. So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

- According to the check sheet results (example), start inspection. Refer to [LAN-93, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

CAN SYSTEM (TYPE 4)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	METER/M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	—	—	—	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 4)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
METER A/C AMP
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
METER A/C AMP
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

PKIA8694E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between data link connector and unified meter and A/C amp. Refer to [LAN-103, "Circuit Check Between Data Link Connector and Unified Meter and A/C Amp."](#)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	METER/M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW	—	UNKW ✓	UNKW ✓	UNKW ✓	UNKW ✓
METER A/C AMP	No indication ✓	—	UNKW	UNKW	—	UNKW	UNKW	—
BCM	—	NG	UNKW	UNKW ✓	UNKW	—	—	UNKW
ABS	—	NG	UNKW	UNKW ✓	—	—	—	—

PKIA8695E



LAN

CAN SYSTEM (TYPE 4)

[CAN]


Case 2

Check harness between unified meter and A/C amp. and BCM. Refer to [LAN-103, "Circuit Check Between Unified Meter and A/C Amp. and BCM"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	METER/M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	—	—	—	—

PKIA8696E

//// : Malfunctioning part



PKIA2019E

CAN SYSTEM (TYPE 4)


[CAN]

Case 3

Check harness between BCM and ABS actuator and electric unit (control unit). Refer to [LAN-103, "Circuit Check Between BCM and ABS Actuator and Electric Unit \(Control Unit\)"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	METER/M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	—	—	—	—

PKIA8697E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 4)


[CAN]

Case 4

Check ECM circuit. Refer to [LAN-104, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	METER/M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	UNKW N
METER A/C AMP	No indication	—	UNKW N	UNKW N	—	UNKW N	UNKW N	—
BCM	—	NG	UNKW N	UNKW N	UNKW N	—	—	UNKW N
ABS	—	NG	UNKW N	UNKW N	—	—	—	—

PKIA8698E



PKIA2021E

CAN SYSTEM (TYPE 4)


[CAN]

Case 5

Check data link connector circuit. Refer to [LAN-105, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	METER/M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	—	—	—	—

PKIA8699E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 4)

[CAN]


Case 6

Check unified meter and A/C amp. circuit. Refer to [LAN-105, "Unified Meter and A/C Amp. Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	METER/M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	UNKWN
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN ✓	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	—	—	—	—

PKIA8700E

//// : Malfunctioning part



PKIA2023E

CAN SYSTEM (TYPE 4)


[CAN]

Case 7

Check BCM circuit. Refer to [LAN-106, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	METER/M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	—	—	—	—

PKIA8701E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 4)

[CAN]


Case 8

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-106, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	METER/M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN ✓	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN
ABS	—	NG	UNKWN ✓	UNKWN	—	—	—	—

PKIA8702E

//// : Malfunctioning part



PKIA2025E

CAN SYSTEM (TYPE 4)


[CAN]

Case 9

Check IPDM E/R circuit. Refer to [LAN-107, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	METER/M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN ✓
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN ✓
ABS	—	NG	UNKWN	UNKWN	—	—	—	—

PKIA8703E



Case 10

Check CAN communication circuit. Refer to [LAN-108, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	METER/M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—
BCM	—	NG	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	UNKWN ✓
ABS	—	NG	UNKWN ✓	UNKWN ✓	—	—	—	—

PKIA8704E

A
B
C
D
E
F
G
H
I
J

LAN

L
M

CAN SYSTEM (TYPE 4)

[CAN]

Case 11

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-110, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	METER/M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN ✓	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	—	—	—	—

PKIA8706E

Case 12

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-110, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	METER/M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN ✓	—	—	—	—

PKIA8705E

Circuit Check Between Data Link Connector and Unified Meter and A/C Amp.

AKS00368

1. CHECK HARNESS FOR OPEN CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector and unified meter and A/C amp. connector.
4. Check continuity between data link connector M8 terminals 6 (L), 14 (R) and unified meter and A/C amp. harness connector M48 terminals 1 (L), 11 (R).

6 (L) – 1 (L) : Continuity should exist.

14 (R) – 11 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-90, "Work Flow"](#).
- NG >> Repair harness.

**Circuit Check Between Unified Meter and A/C Amp. and BCM**

AKS00369

1. CHECK HARNESS FOR OPEN CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following connectors.
 - ECM connector
 - Unified meter and A/C amp. connector
 - BCM connector
4. Check continuity between unified meter and A/C amp. harness connector M48 terminals 1 (L), 11 (R) and BCM harness connector M3 terminals 70 (L), 71 (R).

1 (L) – 70 (L) : Continuity should exist.

11 (R) – 71 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-90, "Work Flow"](#).
- NG >> Repair harness.

**Circuit Check Between BCM and ABS Actuator and Electric Unit (Control Unit)**

AKS0036A

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connector for damage, bend and loose connection (connector-side and harness-side).
 - Harness connector M15
 - Harness connector E108

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector and harness connector M15.
2. Check continuity between BCM harness connector M3 terminals 70 (L), 71 (R) and harness connector M15 terminals 2G (L), 7G (R).


70 (L) – 2G (L) : Continuity should exist.

71 (R) – 7G (R) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E108 terminals 2G (L), 7G (R) and ABS actuator and electric unit (control unit) harness connector E51 terminals 20 (L), 23 (R).


2G (L) – 20 (L) : Continuity should exist.

7G (R) – 23 (R) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-90, "Work Flow"](#).

NG >> Repair harness.



ECM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connector for damage, bend and loose connection (control module-side and harness-side).
 - ECM connector
 - Harness connector F102
 - Harness connector M72

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ECM connector.
2. Check resistance between ECM harness connector F101 terminals 94 (L) and 86 (R).

94 (L) – 86 (R)

: Approx. 108 – 132Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and data link connector.



Data Link Connector Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


Check resistance between data link connector M8 terminals 6 (L) and 14 (R).

6 (L) – 14 (R)

: Approx. 54 – 66Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-90, "Work Flow"](#) .
 NG >> Repair harness between data link connector and unified meter and A/C amp.



Unified Meter and A/C Amp. Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of unified meter and A/C amp. for damage, bend and loose connection (meter-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect unified meter and A/C amp. connector.
2. Check resistance between unified meter and A/C amp. harness connector M48 terminals 1 (L) and 11 (R).

1 (L) – 11 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. and BCM.



AKS0036E

BCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of BCM for damage, bend and loose connection (control module-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M3 terminals 70 (L) and 71 (R).

70 (L) – 71 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace BCM.
 NG >> Repair harness between BCM and harness connector M15.



AKS0036F

ABS Actuator and Electric Unit (Control Unit) Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E51 terminals 20 (L) and 23 (R).

20 (L) – 23 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
- NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



AKS0036G

IPDM E/R Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of IPDM E/R for damage, bend and loose connection (control module-side and harness-side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

48 (L) – 49 (R) : Approx. 108 – 132Ω

OK or NG

- OK >> Replace IPDM E/R.
- NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



LKIA0030E

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN Communication Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connector for damage, bend and loose connection (control module-side, meter-side, control unit-side and harness-side).
 - ECM
 - Unified meter and A/C amp.
 - BCM
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector F102.
2. Check continuity between ECM harness connector F101 terminals 94 (L) and 86 (R).

94 (L) – 86 (R) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector F102.



3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between ECM harness connector F101 terminals 94 (L), 86 (R) and ground.

94 (L) – ground : Continuity should not exist.

86 (R) – ground : Continuity should not exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness between ECM and harness connector F102.



4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - Unified meter and A/C amp. connector
 - BCM connector
 - Harness connector M15
2. Check continuity between data link connector M8 terminals 6 (L) and 14 (R).


6 (L) – 14 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M72.
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and BCM.
- Harness between data link connector and harness connector M15.



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M8 terminals 6 (L), 14 (R) and ground.

6 (L) – ground : Continuity should not exist.


14 (R) – ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M72.
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and BCM.
- Harness between data link connector and harness connector M15.



6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).


48 (L) – 49 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit).
- Harness between IPDM E/R and harness connector E108.




7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E9 terminals 48 (L), 49 (R) and ground.

- 48 (L) – ground : Continuity should not exist.**
- 49 (R) – ground : Continuity should not exist.**

OK or NG

- OK >> GO TO 8.
- NG >> Check the following harnesses. If any harness is damaged, repair the harness.
 - Harness between IPDM E/R and ABS actuator and electric unit (control unit).
 - Harness between IPDM E/R and harness connector E108.



8. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

Check components inspection. Refer to [LAN-110, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-90, "Work Flow"](#).
- NG >> Replace ECM and/or IPDM E/R.

IPDM E/R Check

AKS0036I

1. CHECK IPDM E/R

1. Turn ignition switch ON and then OFF.
2. Check for illuminated parking lamps and tail lamps.

Parking lamps and tail lamps should not illuminate.

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
- NG >> Replace IPDM E/R.

IPDM E/R Ignition Relay Circuit Check

AKS0036J

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-29, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-11, "IGNITION POWER SUPPLY — IGNITION SW. IN "ON" AND/OR "START" "](#).


Component Inspection

AKS0036K

ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 48 and 49.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 – 86	108 - 132
IPDM E/R	48 – 49	



CAN SYSTEM (TYPE 5)

PFP:23710


System Description

AKS0036L

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

AKS0036M



A
B
C
D
E
F
G
H
I
J

LAN

L
M

CAN SYSTEM (TYPE 5)



[CAN]

Wiring Diagram — CAN —


AKS0036N

LAN-CAN-05


▬ : DATA LINE



(M8)
W



(M48)
GY



(M77)
W

REFER TO THE FOLLOWING.

(F102) -SUPER MULTIPLE JUNCTION (SMJ)

(M3), (F101) -ELECTRICAL UNITS



TKWT0410E

CAN SYSTEM (TYPE 5)

[CAN]

LAN-CAN-06

▬ : DATA LINE



REFER TO THE FOLLOWING.

E108 -SUPER MULTIPLE JUNCTION (SMJ)

E51 -ELECTRICAL UNITS

TKWT0411E

Work Flow

- When there are no indications of "METER A/C AMP" or "AIR PRESSURE MONITOR" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".

(Example)

	NISSAN CONSULT- II ENGINE START (NISSAN BASED VHCL) START (RENAULT BASED VHCL) SUB MODE LIGHT COPY	➔	SELECT SYSTEM ENGINE A/T ABS AIR BAG BCM METER A/C AMP BACK LIGHT COPY
--	--	---	---

PKIA2093E

- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "METER A/C AMP", "BCM", "AIR PRESSURE MONITOR" and "ABS" displayed on CONSULT-II.

(Example)

	SELECT DIAG MODE WORK SUPPORT SELF-DIAG RESULTS DATA MONITOR DATA MONITOR (SPEC) CAN DIAG SUPPORT MNTR ACTIVE TEST Scroll Down BACK LIGHT COPY	➔	SELF-DIAG RESULTS DTC RESULTS TIME <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 70%;">CAN COMM CIRCUIT [U1000]</td> <td style="width: 30%; text-align: center;">0</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td colspan="2" style="text-align: center;">F.F.DATA</td> </tr> <tr> <td>ERASE</td> <td>PRINT</td> </tr> <tr> <td>MODE BACK</td> <td>LIGHT COPY</td> </tr> </table>	CAN COMM CIRCUIT [U1000]	0							F.F.DATA		ERASE	PRINT	MODE BACK	LIGHT COPY
CAN COMM CIRCUIT [U1000]	0																
F.F.DATA																	
ERASE	PRINT																
MODE BACK	LIGHT COPY																

PKIA8260E

- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "METER A/C AMP", "BCM", "AIR PRESSURE MONITOR" and "ABS" displayed on CONSULT-II.

(Example)

	SELECT DIAG MODE WORK SUPPORT SELF-DIAG RESULTS DATA MONITOR DATA MONITOR (SPEC) CAN DIAG SUPPORT MNTR ACTIVE TEST Scroll Down BACK LIGHT COPY	➔	CAN DIAG SUPPORT MNTR ENGINE <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 60%;"></td> <td style="width: 40%; text-align: center;">PRSNTR</td> </tr> <tr> <td>INITIAL DIAG</td> <td style="text-align: center;">OK</td> </tr> <tr> <td>TRANSMIT DIAG</td> <td style="text-align: center;">OK</td> </tr> <tr> <td>TCM</td> <td style="text-align: center;">OK</td> </tr> <tr> <td>VDC/TCS/ABS</td> <td style="text-align: center;">OK</td> </tr> <tr> <td>METER/M&A</td> <td style="text-align: center;">OK</td> </tr> <tr> <td>ICC</td> <td style="text-align: center;">UNKWVN</td> </tr> <tr> <td>BCM/SEC</td> <td style="text-align: center;">OK</td> </tr> <tr> <td>IPDM E/R</td> <td style="text-align: center;">OK</td> </tr> <tr> <td>AWD/4WD/e4WD</td> <td style="text-align: center;">UNKWVN</td> </tr> <tr> <td>PRINT</td> <td style="text-align: center;">Scroll Down</td> </tr> <tr> <td>MODE BACK</td> <td>LIGHT COPY</td> </tr> </table>		PRSNTR	INITIAL DIAG	OK	TRANSMIT DIAG	OK	TCM	OK	VDC/TCS/ABS	OK	METER/M&A	OK	ICC	UNKWVN	BCM/SEC	OK	IPDM E/R	OK	AWD/4WD/e4WD	UNKWVN	PRINT	Scroll Down	MODE BACK	LIGHT COPY
	PRSNTR																										
INITIAL DIAG	OK																										
TRANSMIT DIAG	OK																										
TCM	OK																										
VDC/TCS/ABS	OK																										
METER/M&A	OK																										
ICC	UNKWVN																										
BCM/SEC	OK																										
IPDM E/R	OK																										
AWD/4WD/e4WD	UNKWVN																										
PRINT	Scroll Down																										
MODE BACK	LIGHT COPY																										

PKIA8343E

- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-115, "CHECK SHEET"](#) .
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks "v" onto the items with "No indication", "NG", or "UNKWVN" in the check sheet table. Refer to [LAN-115, "CHECK SHEET"](#) .

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual. So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

- According to the check sheet results (example), start inspection. Refer to [LAN-117, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

CAN SYSTEM (TYPE 5)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	TIRE-P	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	UNKWN	—	—	—	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

A
B
C
D
E
F
G
H
I
J
LAN
L
M

LAN

CAN SYSTEM (TYPE 5)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
METER A/C AMP
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
AIR PRESSURE
MONITOR
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
METER A/C AMP
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
AIR PRESSURE
MONITOR
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

PKIB0318E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between data link connector and unified meter and A/C amp. Refer to [LAN-129, "Circuit Check Between Data Link Connector and Unified Meter and A/C Amp."](#)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	TIRE-P	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	UNKWN ✓
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN ✓	UNKWN	—	—	—	UNKWN
AIR PRESSURE MONITOR	No indication ✓	NG	UNKWN	—	UNKWN	—	—	—	—
ABS	—	NG	UNKWN	UNKWN ✓	—	—	—	—	—

PKIB0334E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 5)

[CAN]


Case 2

Check harness between unified meter and A/C amp. and BCM. Refer to [LAN-129, "Circuit Check Between Unified Meter and A/C Amp. and BCM"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	TIRE-P	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	—	UNKWN ✓	UNKWN ✓
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	—
BCM	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	—	UNKWN
AIR PRESSURE MONITOR	No indication ✓	NG	UNKWN	—	UNKWN	—	—	—	—
ABS	—	NG	UNKWN	UNKWN ✓	—	—	—	—	—

PKIB0335E

/// : Malfunctioning part



PKIA2028E

CAN SYSTEM (TYPE 5)


[CAN]

Case 3

Check harness between BCM and Low Tire Pressure Warning Control Unit. Refer to [LAN-130, "Circuit Check Between BCM and Low Tire Pressure Warning Control Unit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	TIRE-P	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	UNKWN	—	—	—	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—

PKIB0336E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 5)

[CAN]


Case 4

Check harness between Low Tire Pressure Warning Control Unit and ABS Actuator and Electric Unit (Control Unit). Refer to [LAN-130, "Circuit Check Between Low Tire Pressure Warning Control Unit and ABS Actuator and Electric Unit \(Control Unit\)"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	TIRE-P	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN ✓	UNKWN ✓
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN ✓
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	UNKWN	—	—	—	—
ABS	—	NG	UNKWN	UNKWN ✓	—	—	—	—	—

PKIB0337E

/// : Malfunctioning part



PKIA2030E

CAN SYSTEM (TYPE 5)


[CAN]

Case 5

Check ECM circuit. Refer to [LAN-131, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	TIRE-P	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW ^N	—	UNKW ^N	UNKW ^N	—	UNKW ^N	UNKW ^N
METER A/C AMP	No indication	—	UNKW ^N	UNKW ^N	—	UNKW ^N	UNKW ^N	UNKW ^N	—
BCM	—	NG	UNKW ^N	UNKW ^N	UNKW ^N	—	—	—	UNKW ^N
AIR PRESSURE MONITOR	No indication	NG	UNKW ^N	—	UNKW ^N	—	—	—	—
ABS	—	NG	UNKW ^N	UNKW ^N	—	—	—	—	—

PKIB0338E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 5)

[CAN]


Case 6

Check data link connector circuit. Refer to [LAN-131, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	TIRE-P	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	UNKWN
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
AIR PRESSURE MONITOR	No indication ✓	NG	UNKWN	—	UNKWN	—	—	—	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—

PKIB0339E

▨ : Malfunctioning part



PKIA2032E

CAN SYSTEM (TYPE 5)


[CAN]

Case 7

Check unified meter and A/C amp. circuit. Refer to [LAN-132, "Unified Meter and A/C Amp. Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	TIRE-P	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	UNKWN
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	UNKWN	—	—	—	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—

PKIB0340E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 5)

[CAN]


Case 8

Check BCM circuit. Refer to [LAN-132, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	TIRE-P	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	—	UNKWN	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	—
BCM	—	NG	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	—	UNKWN ✓
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	UNKWN	—	—	—	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—

PKIB0341E

▨ : Malfunctioning part



PKIA2034E

CAN SYSTEM (TYPE 5)


[CAN]

Case 9

Check Low Tire Pressure Warning Control Unit circuit. Refer to [LAN-133, "Low Tire Pressure Warning Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	TIRE-P	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	UNKWN	—	—	—	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—

PKIB0342E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 5)

[CAN]


Case 10

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-133, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	TIRE-P	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	UNKWN	—	—	—	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—

PKIB0343E

//// : Malfunctioning part



PKIA2036E

CAN SYSTEM (TYPE 5)


[CAN]

Case 11

Check IPDM E/R circuit. Refer to [LAN-134, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	TIRE-P	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	UNKWN ✓
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN ✓
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	UNKWN	—	—	—	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—

PKIB0344E



Case 12

Check CAN communication circuit. Refer to [LAN-135, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	TIRE-P	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	UNKWN ✓
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	—
BCM	—	NG	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	—	UNKWN ✓
AIR PRESSURE MONITOR	No indication ✓	NG	UNKWN	—	UNKWN	—	—	—	—
ABS	—	NG	UNKWN ✓	UNKWN ✓	—	—	—	—	—

PKIB0345E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 5)

[CAN]

Case 13

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-137, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	TIRE-P	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	UNKWN	—	—	—	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—

PKIB0346E

Case 14

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-137, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	TIRE-P	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	UNKWN	—	—	—	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—

PKIB0347E

Circuit Check Between Data Link Connector and Unified Meter and A/C Amp.

AKS0036P

1. CHECK HARNESS FOR OPEN CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector and unified meter and A/C amp. connector.
4. Check continuity between data link connector M8 terminals 6 (L), 14 (R) and unified meter and A/C amp. harness connector M48 terminals 1 (L), 11 (R).

6 (L) – 1 (L) : Continuity should exist.

14 (R) – 11 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-114, "Work Flow"](#).
- NG >> Repair harness.



Circuit Check Between Unified Meter and A/C Amp. and BCM

AKS0036Q

1. CHECK HARNESS FOR OPEN CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following connectors.
 - ECM connector
 - Unified meter and A/C amp. connector
 - BCM connector
4. Check continuity between unified meter and A/C amp. harness connector M48 terminals 1 (L), 11 (R) and BCM harness connector M3 terminals 70 (L), 71 (R).

1 (L) – 70 (L) : Continuity should exist.

11 (R) – 71 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-114, "Work Flow"](#).
- NG >> Repair harness.



Circuit Check Between BCM and Low Tire Pressure Warning Control Unit

AKS0036R

1. CHECK HARNESS FOR OPEN CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following connectors.
 - ECM connector
 - BCM connector
 - Low tire pressure warning control unit connector
4. Check continuity between BCM harness connector M3 terminals 70 (L), 71 (R) and low tire pressure warning control unit harness connector M77 terminals 9 (L), 21 (R).

70 (L) – 9 (L) : Continuity should exist.

71 (R) – 21 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-114, "Work Flow"](#).
- NG >> Repair harness.

**Circuit Check Between Low Tire Pressure Warning Control Unit and ABS Actuator and Electric Unit (Control Unit)**

AKS0036S

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connector for damage, bend and loose connection (connector-side and harness-side).
 - Harness connector M15
 - Harness connector E108

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect low tire pressure warning control unit connector and harness connector M15.
2. Check continuity between low tire pressure warning control unit harness connector M77 terminals 9 (L), 21 (R) and harness connector M15 terminals 2G (L), 7G (R).

9 (L) – 2G (L) : Continuity should exist.

21 (R) – 7G (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E108 terminals 2G (L), 7G (R) and ABS actuator and electric unit (control unit) harness connector E51 terminals 20 (L), 23 (R).

2G (L) – 20 (L) : Continuity should exist.
7G (R) – 23 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-114, "Work Flow"](#) .
 NG >> Repair harness.



AKS0036T

ECM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connector for damage, bend and loose connection (control module-side and harness-side).
 - ECM connector
 - Harness connector F102
 - Harness connector M72

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector F101 terminals 94 (L) and 86 (R).

94 (L) – 86 (R) : Approx. 108 – 132Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and data link connector.



AKS0036U

Data Link Connector Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M8 terminals 6 (L) and 14 (R).

6 (L) – 14 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-114, "Work Flow"](#) .
 NG >> Repair harness between data link connector and unified meter and A/C amp.



AKS0036V

Unified Meter and A/C Amp. Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of unified meter and A/C amp. for damage, bend and loose connection (meter-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect unified meter and A/C amp. connector.
2. Check resistance between unified meter and A/C amp. harness connector M48 terminals 1 (L) and 11 (R).

1 (L) – 11 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. and BCM.



AKS0036W

BCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of BCM for damage, bend and loose connection (control module-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M3 terminals 70 (L) and 71 (R).

70 (L) – 71 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace BCM.
 NG >> Repair harness between BCM and low tire pressure warning control unit.



Low Tire Pressure Warning Control Unit Circuit Check

AKS0036X

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of low tire pressure warning control unit for damage, bend and loose connection (control unit-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect low tire pressure warning control unit connector.
2. Check resistance between low tire pressure warning control unit harness connector M77 terminals 9 (L) and 21 (R).

9 (L) – 21 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace low tire pressure warning control unit.
 NG >> Repair harness between low tire pressure warning control unit and harness connector M15.



ABS Actuator and Electric Unit (Control Unit) Circuit Check

AKS0036Y

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E51 terminals 20 (L) and 23 (R).

20 (L) – 23 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



AKS0036Z

IPDM E/R Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of IPDM E/R for damage, bend and loose connection (control module-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

48 (L) – 49 (R) : Approx. 108 – 132Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



LKIA0030E

CAN Communication Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connector for damage, bend and loose connection (control module-side, meter-side, control unit-side and harness-side).
 - ECM
 - Unified meter and A/C amp.
 - BCM
 - Low tire pressure warning control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector F102.
2. Check continuity between ECM harness connector F101 terminals 94 (L) and 86 (R).

94 (L) – 86 (R) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector F102.



3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between ECM harness connector F101 terminals 94 (L), 86 (R) and ground.

94 (L) – ground : Continuity should not exist.

86 (R) – ground : Continuity should not exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness between ECM and harness connector F102.



4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - Unified meter and A/C amp. connector
 - BCM connector
 - Low tire pressure warning control unit connector
 - Harness connector M15
2. Check continuity between data link connector M8 terminals 6 (L) and 14 (R).


6 (L) – 14 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M72.
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and BCM.
- Harness between data link connector and low tire pressure warning control unit.
- Harness between data link connector and harness connector M15.



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M8 terminals 6 (L), 14 (R) and ground.

6 (L) – ground : Continuity should not exist.


14 (R) – ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M72.
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and BCM.
- Harness between data link connector and low tire pressure warning control unit.
- Harness between data link connector and harness connector M15.



6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).


48 (L) – 49 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit).
- Harness between IPDM E/R and harness connector E108.



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E9 terminals 48 (L), 49 (R) and ground.

48 (L) – ground : Continuity should not exist.


49 (R) – ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit).
- Harness between IPDM E/R and harness connector E108.



8. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

Check components inspection. Refer to [LAN-138, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-114, "Work Flow"](#).

NG >> Replace ECM and/or IPDM E/R.

IPDM E/R Check

1. CHECK IPDM E/R

1. Turn ignition switch ON and then OFF.
2. Check for illuminated parking lamps and tail lamps.

Parking lamps and tail lamps should not illuminate.

OK or NG

OK >> Replace ABS actuator and electric unit (control unit).

NG >> Replace IPDM E/R.

IPDM E/R Ignition Relay Circuit Check


Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-29, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-11, "IGNITION POWER SUPPLY — IGNITION SW. IN "ON" AND/OR "START" "](#).

Component Inspection ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 48 and 49.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	48 - 49	



CAN SYSTEM (TYPE 6)

PFP:23710


System Description

AKS0034H

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

AKS0034I



A
B
C
D
E
F
G
H
I
J

LAN

L
M

CAN SYSTEM (TYPE 6)



[CAN]

AKS0034J


Wiring Diagram — CAN —

LAN-CAN-07


▬ : DATA LINE



(M8)
W



(M22)
W



(M48)
GY



REFER TO THE FOLLOWING.

(F102) -SUPER MULTIPLE JUNCTION (SMJ)

(M3), (F101) -ELECTRICAL UNITS

NEXT PAGE



TKWT0412E

CAN SYSTEM (TYPE 6)

[CAN]

LAN-CAN-08

▬ : DATA LINE



REFER TO THE FOLLOWING.

(E108) -SUPER MULTIPLE JUNCTION (SMJ)

(E118) -ELECTRICAL UNITS

TKWT0413E

Work Flow

- When there are no indications of "METER A/C AMP" or "AIR PRESSURE MONITOR" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".

(Example)

	NISSAN CONSULT- II ENGINE START (NISSAN BASED VHCL) START (RENAULT BASED VHCL) SUB MODE LIGHT COPY	➔	SELECT SYSTEM ENGINE A/T ABS AIR BAG BCM METER A/C AMP BACK LIGHT COPY
--	--	---	---

PKIA2093E

- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "METER A/C AMP", "BCM", "AIR PRESSURE MONITOR" and "ABS" displayed on CONSULT-II.

(Example)

	SELECT DIAG MODE WORK SUPPORT SELF-DIAG RESULTS DATA MONITOR DATA MONITOR (SPEC) CAN DIAG SUPPORT MNTR ACTIVE TEST Scroll Down BACK LIGHT COPY	➔	SELF-DIAG RESULTS DTC RESULTS TIME <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 70%;">CAN COMM CIRCUIT [U1000]</td> <td style="width: 30%;">0</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </table> F.F.DATA ERASE PRINT MODE BACK LIGHT COPY	CAN COMM CIRCUIT [U1000]	0				
CAN COMM CIRCUIT [U1000]	0								

PKIA8260E

- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "METER A/C AMP", "BCM", "AIR PRESSURE MONITOR" and "ABS" displayed on CONSULT-II.

(Example)

	SELECT DIAG MODE WORK SUPPORT SELF-DIAG RESULTS DATA MONITOR DATA MONITOR (SPEC) CAN DIAG SUPPORT MNTR ACTIVE TEST Scroll Down BACK LIGHT COPY	➔	CAN DIAG SUPPORT MNTR ENGINE <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 60%;"></td> <td style="width: 40%;">PRSENT</td> </tr> <tr> <td>INITIAL DIAG</td> <td>OK</td> </tr> <tr> <td>TRANSMIT DIAG</td> <td>OK</td> </tr> <tr> <td>TCM</td> <td>OK</td> </tr> <tr> <td>VDC/TCS/ABS</td> <td>OK</td> </tr> <tr> <td>METER/M&A</td> <td>OK</td> </tr> <tr> <td>ICC</td> <td>UNKWVN</td> </tr> <tr> <td>BCM/SEC</td> <td>OK</td> </tr> <tr> <td>IPDM E/R</td> <td>OK</td> </tr> <tr> <td>AWD/4WD/e4WD</td> <td>UNKWVN</td> </tr> </table> PRINT Scroll Down MODE BACK LIGHT COPY		PRSENT	INITIAL DIAG	OK	TRANSMIT DIAG	OK	TCM	OK	VDC/TCS/ABS	OK	METER/M&A	OK	ICC	UNKWVN	BCM/SEC	OK	IPDM E/R	OK	AWD/4WD/e4WD	UNKWVN
	PRSENT																						
INITIAL DIAG	OK																						
TRANSMIT DIAG	OK																						
TCM	OK																						
VDC/TCS/ABS	OK																						
METER/M&A	OK																						
ICC	UNKWVN																						
BCM/SEC	OK																						
IPDM E/R	OK																						
AWD/4WD/e4WD	UNKWVN																						

PKIA8343E

- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-143, "CHECK SHEET"](#) .

- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks "v" onto the items with "No indication", "NG", or "UNKWVN" in the check sheet table. Refer to [LAN-143, "CHECK SHEET"](#) .

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual. So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

- According to the check sheet results (example), start inspection. Refer to [LAN-145, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

CAN SYSTEM (TYPE 6)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

A
B
C
D
E
F
G
H
I
J
LAN
L
M

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

CAN SYSTEM (TYPE 6)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
METER A/C AMP
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
METER A/C AMP
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

PKIB0349E

CAN SYSTEM (TYPE 6)

[CAN]

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between data link connector and unified meter and A/C amp. Refer to [LAN-151, "Circuit Check Between Data Link Connector and Unified Meter and A/C Amp."](#)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—

PKIB0350E




Case 2

Check harness between unified meter and A/C amp. and BCM. Refer to [LAN-151, "Circuit Check Between Unified Meter and A/C Amp. and BCM"](#)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—

PKIB0351E



A
B
C
D
E
F
G
H
I
J
K
L
M

LAN

CAN SYSTEM (TYPE 6)


[CAN]

Case 3

Check harness between BCM and steering angle sensor. Refer to [LAN-152, "Circuit Check Between BCM and Steering Angle Sensor"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—

PKIB0352E




Case 4

Check harness between steering angle sensor and VDC/TCS/ABS control unit. Refer to [LAN-152, "Circuit Check Between Steering Angle Sensor and VDC/TCS/ABS Control Unit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—

PKIB0353E



CAN SYSTEM (TYPE 6)


[CAN]

Case 5

Check ECM circuit. Refer to [LAN-153, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	UNKWN ✓
METER A/C AMP	No indication	—	UNKWN	UNKWN ✓	—	UNKWN	—	UNKWN	—
BCM	—	NG	UNKWN	UNKWN ✓	UNKWN	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN ✓	—	—	UNKWN	—	—

PKIB0354E




Case 6

Check data link connector circuit. Refer to [LAN-153, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	UNKWN
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—

PKIB0355E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 6)


[CAN]

Case 7

Check unified meter and A/C amp. circuit. Refer to [LAN-154, "Unified Meter and A/C Amp. Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	—	UNKWN	UNKWN
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN ✓	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—

PKIB0356E




Case 8

Check BCM circuit. Refer to [LAN-154, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	—	UNKWN	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN ✓	—	UNKWN	—
BCM	—	NG	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	—	UNKWN ✓
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—

PKIB0357E



CAN SYSTEM (TYPE 6)


[CAN]

Case 9

Check steering angle sensor circuit. Refer to [LAN-155, "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW	—	UNKW	UNKW	—	UNKW	UNKW
METER A/C AMP	No indication	—	UNKW	UNKW	—	UNKW	—	UNKW	—
BCM	—	NG	UNKW	UNKW	UNKW	—	—	—	UNKW
ABS	—	NG	UNKW	UNKW	—	—	UNKW	—	—

PKIB0358E




Case 10

Check VDC/TCS/ABS control unit circuit. Refer to [LAN-155, "VDC/TCS/ABS Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW	—	UNKW	UNKW	—	UNKW	UNKW
METER A/C AMP	No indication	—	UNKW	UNKW	—	UNKW	—	UNKW	—
BCM	—	NG	UNKW	UNKW	UNKW	—	—	—	UNKW
ABS	—	NG	UNKW	UNKW	—	—	UNKW	—	—

PKIB0359E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 6)


[CAN]

Case 11

Check IPDM E/R circuit. Refer to [LAN-156, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW N	—	UNKW N	UNKW N	—	UNKW N	UNKW N
METER A/C AMP	No indication	—	UNKW N	UNKW N	—	UNKW N	—	UNKW N	—
BCM	—	NG	UNKW N	UNKW N	UNKW N	—	—	—	UNKW N
ABS	—	NG	UNKW N	UNKW N	—	—	UNKW N	—	—

PKIB0360E



Case 12

Check CAN communication circuit. Refer to [LAN-157, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW N	—	UNKW N	UNKW N	—	UNKW N	UNKW N
METER A/C AMP	No indication	—	UNKW N	UNKW N	—	UNKW N	—	UNKW N	—
BCM	—	NG	UNKW N	UNKW N	UNKW N	—	—	—	UNKW N
ABS	—	NG	UNKW N	UNKW N	—	—	UNKW N	—	—

PKIB0361E

Case 13

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-159, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW N	—	UNKW N	UNKW N	—	UNKW N	UNKW N
METER A/C AMP	No indication	—	UNKW N	UNKW N	—	UNKW N	—	UNKW N	—
BCM	—	NG	UNKW N	UNKW N	UNKW N	—	—	—	UNKW N
ABS	—	NG	UNKW N	UNKW N	—	—	UNKW N	—	—

PKIB0362E

Case 14

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-159, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—

PKIB0363E

Circuit Check Between Data Link Connector and Unified Meter and A/C Amp.

AKS0034L


1. CHECK HARNESS FOR OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector and unified meter and A/C amp. connector.
4. Check continuity between data link connector M8 terminals 6 (L), 14 (R) and unified meter and A/C amp. harness connector M48 terminals 1 (L), 11 (R).

6 (L) – 1 (L) : Continuity should exist.
14 (R) – 11 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-142, "Work Flow"](#) .
- NG >> Repair harness.



Circuit Check Between Unified Meter and A/C Amp. and BCM

AKS0034M


1. CHECK HARNESS FOR OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following connectors.
 - ECM connector
 - Unified meter and A/C amp. connector
 - BCM connector
4. Check continuity between unified meter and A/C amp. harness connector M48 terminals 1 (L), 11 (R) and BCM harness connector M3 terminals 70 (L), 71 (R).

1 (L) – 70 (L) : Continuity should exist.
11 (R) – 71 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-142, "Work Flow"](#) .
- NG >> Repair harness.



Circuit Check Between BCM and Steering Angle Sensor

1. CHECK HARNESS FOR OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following connectors.
 - ECM connector
 - BCM connector
 - Steering angle sensor connector
4. Check continuity between BCM harness connector M3 terminals 70 (L), 71 (R) and steering angle sensor harness connector M22 terminals 4 (L), 5 (R).


70 (L) – 4 (L) : Continuity should exist.

71 (R) – 5 (R) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-142, "Work Flow"](#).

NG >> Repair harness.



Circuit Check Between Steering Angle Sensor and VDC/TCS/ABS Control Unit

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connector for damage, bend and loose connection (connector-side and harness-side).
 - Harness connector M15
 - Harness connector E108

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector and harness connector M15.
2. Check continuity between steering angle sensor harness connector M22 terminals 4 (L), 5 (R) and harness connector M15 terminals 2G (L), 7G (R).


4 (L) – 2G (L) : Continuity should exist.

5 (R) – 7G (R) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect VDC/TCS/ABS control unit connector.
2. Check continuity between harness connector E108 terminals 2G (L), 7G (R) and VDC/TCS/ABS control unit harness connector E118 terminals 61 (L), 63 (R).

2G (L) – 61 (L) : Continuity should exist.
7G (R) – 63 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-142, "Work Flow"](#) .
 NG >> Repair harness.



AKS0034P

ECM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connector for damage, bend and loose connection (control module-side and harness-side).
 - ECM connector
 - Harness connector F102
 - Harness connector M72

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector F101 terminals 94 (L) and 86 (R).

94 (L) – 86 (R) : Approx. 108 – 132Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and data link connector.



AKS0034Q

Data Link Connector Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

A
B
C
D
E
F
G
H
I
J
L
M

LAN


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M8 terminals 6 (L) and 14 (R).

6 (L) – 14 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-142. "Work Flow"](#) .
 NG >> Repair harness between data link connector and unified meter and A/C amp.



Unified Meter and A/C Amp. Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of unified meter and A/C amp. for damage, bend and loose connection (meter-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect unified meter and A/C amp. connector.
2. Check resistance between unified meter and A/C amp. harness connector M48 terminals 1 (L) and 11 (R).

1 (L) – 11 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. and BCM.



BCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of BCM for damage, bend and loose connection (control module-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M3 terminals 70 (L) and 71 (R).

70 (L) – 71 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace BCM.
 NG >> Repair harness between BCM and steering angle sensor.



Steering Angle Sensor Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M22 terminals 4 (L) and 5 (R).

4 (L) – 5 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and harness connector M15.



VDC/TCS/ABS Control Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of VDC/TCS/ABS control unit for damage, bend and loose connection (control unit-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect VDC/TCS/ABS control unit connector.
2. Check resistance between VDC/TCS/ABS control unit harness connector E118 terminals 61 (L) and 63 (R).

61 (L) – 63 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace VDC/TCS/ABS control unit.
 NG >> Repair harness between VDC/TCS/ABS control unit and IPDM E/R.



AKS0034V

IPDM E/R Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of IPDM E/R for damage, bend and loose connection (control module-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

48 (L) – 49 (R) : Approx. 108 – 132Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and VDC/TCS/ABS control unit.



CAN Communication Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connector for damage, bend and loose connection (control module-side, meter-side, sensor-side, control unit-side and harness-side).
 - ECM
 - Unified meter and A/C amp.
 - BCM
 - Steering angle sensor
 - VDC/TCS/ABS control unit
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector F102.
2. Check continuity between ECM harness connector F101 terminals 94 (L) and 86 (R).

94 (L) – 86 (R) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector F102.



3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between ECM harness connector F101 terminals 94 (L), 86 (R) and ground.

94 (L) – ground : Continuity should not exist.

86 (R) – ground : Continuity should not exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness between ECM and harness connector F102.



4. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - Unified meter and A/C amp. connector
 - BCM connector
 - Steering angle sensor connector
 - Harness connector M15
- Check continuity between data link connector M8 terminals 6 (L) and 14 (R).


6 (L) – 14 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M72.
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and BCM.
- Harness between data link connector and steering angle sensor.
- Harness between data link connector and harness connector M15.



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M8 terminals 6 (L), 14 (R) and ground.

6 (L) – ground : Continuity should not exist.


14 (R) – ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M72.
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and BCM.
- Harness between data link connector and steering angle sensor.
- Harness between data link connector and harness connector M15.



6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect VDC/TCS/ABS control unit connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).


48 (L) – 49 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and VDC/TCS/ABS control unit.
- Harness between IPDM E/R and harness connector E108.



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E9 terminals 48 (L), 49 (R) and ground.

48 (L) – ground : Continuity should not exist.


49 (R) – ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and VDC/TCS/ABS control unit.
- Harness between IPDM E/R and harness connector E108.



8. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

Check components inspection. Refer to [LAN-160, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-142, "Work Flow"](#).

NG >> Replace ECM and/or IPDM E/R.

IPDM E/R Check

1. CHECK IPDM E/R

1. Turn ignition switch ON and then OFF.
2. Check for illuminated parking lamps and tail lamps.

Parking lamps and tail lamps should not illuminate.

OK or NG

OK >> Replace VDC/TCS/ABS control unit.

NG >> Replace IPDM E/R.

IPDM E/R Ignition Relay Circuit Check

Check the following. If no malfunction is found, replace the IPDM E/R.


- IPDM E/R power supply circuit. Refer to [PG-29, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-11, "IGNITION POWER SUPPLY — IGNITION SW. IN "ON" AND/OR "START" "](#).

Component Inspection**ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION**

AKS0034Z

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 48 and 49.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	48 - 49	



CAN SYSTEM (TYPE 7)

PFP:23710


System Description

AKS00350

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

AKS00351



PKIA2224E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 7)






[CAN]

Wiring Diagram — CAN —

AKS00352

LAN-CAN-09

▬ : DATA LINE



REFER TO THE FOLLOWING.

(F102) -SUPER MULTIPLE JUNCTION (SMJ)

(M3), (F101) -ELECTRICAL UNITS


TKWT0414E

CAN SYSTEM (TYPE 7)

[CAN]

LAN-CAN-10

▬ : DATA LINE



A
B
C
D
E
F
G
H
I
J
K
L
M

LAN

49	48	47	46	45
56	55	54	53	52
51	50			



REFER TO THE FOLLOWING.

- (E108) -SUPER MULTIPLE JUNCTION (SMJ)
- (E118) -ELECTRICAL UNITS

TKWT0415E

CAN SYSTEM (TYPE 7)

[CAN]

AKS00C5H

Work Flow

- When there are no indications of "METER A/C AMP" or "AIR PRESSURE MONITOR" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".

(Example)

NISSAN	
CONSULT-II	
ENGINE	
START (NISSAN BASED VHCL)	
START (RENAULT BASED VHCL)	
SUB MODE	
	LIGHT COPY



SELECT SYSTEM			
ENGINE			
A/T			
ABS			
AIR BAG			
BCM			
METER A/C AMP			
	BACK	LIGHT	COPY

PKIA2093E

- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "METER A/C AMP", "BCM", "AIR PRESSURE MONITOR" and "ABS" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE	
WORK SUPPORT	
SELF-DIAG RESULTS	
DATA MONITOR	
DATA MONITOR (SPEC)	
CAN DIAG SUPPORT MNTR	
ACTIVE TEST	
Scroll Down	
	BACK LIGHT COPY



SELF-DIAG RESULTS	
DTC RESULTS TIME	
CAN COMM CIRCUIT [U1000]	0
F.F.DATA	
ERASE	PRINT
MODE	BACK LIGHT COPY

PKIA8260E

- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "METER A/C AMP", "BCM", "AIR PRESSURE MONITOR" and "ABS" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE	
WORK SUPPORT	
SELF-DIAG RESULTS	
DATA MONITOR	
DATA MONITOR (SPEC)	
CAN DIAG SUPPORT MNTR	
ACTIVE TEST	
Scroll Down	
	BACK LIGHT COPY



CAN DIAG SUPPORT MNTR			
ENGINE			
		PRSNTR	
INITIAL DIAG	OK		
TRANSMIT DIAG	OK		
TCM	OK		
VDC/TCS/ABS	OK		
METER/M&A	OK		
ICC	UNKWVN		
BCM/SEC	OK		
IPDM E/R	OK		
AWD/4WD/e4WD	UNKWVN		
PRINT			Scroll Down
MODE	BACK	LIGHT	COPY

PKIA8343E

- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-165, "CHECK SHEET"](#).

- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks "v" onto the items with "No indication", "NG", or "UNKWVN" in the check sheet table. Refer to [LAN-165, "CHECK SHEET"](#).

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual. So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

- According to the check sheet results (example), start inspection. Refer to [LAN-167, "CHECK SHEET RESULTS \(EXAMPLE\)"](#).

CAN SYSTEM (TYPE 7)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM/SEC	TIRE-P	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

A
B
C
D
E
F
G
H
I
J
LAN
L
M

LAN

CAN SYSTEM (TYPE 7)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
METER A/C AMP
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
AIR PRESSURE
MONITOR
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
METER A/C AMP
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
AIR PRESSURE
MONITOR
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

PKIB0318E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between data link connector and unified meter and A/C amp. Refer to [LAN-181, "Circuit Check Between Data Link Connector and Unified Meter and A/C Amp."](#)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM/SEC	TIRE-P	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN ✓	—	—	UNKWN ✓	UNKWN ✓
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—
BCM	—	NG	UNKWN	UNKWN ✓	UNKWN	—	—	—	—	UNKWN
AIR PRESSURE MONITOR	No indication ✓	NG	UNKWN	—	UNKWN	—	—	—	—	—
ABS	—	NG	UNKWN	UNKWN ✓	—	—	—	UNKWN	—	—

PKIB0365E



LAN

CAN SYSTEM (TYPE 7)


[CAN]

Case 2

Check harness between unified meter and A/C amp. and BCM. Refer to [LAN-181, "Circuit Check Between Unified Meter and A/C Amp. and BCM"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM/SEC	TIRE-P	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	—	—	UNKWN ✓	UNKWN ✓
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	—
BCM	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	—	—	UNKWN
AIR PRESSURE MONITOR	No indication ✓	NG	UNKWN	—	UNKWN	—	—	—	—	—
ABS	—	NG	UNKWN	UNKWN ✓	—	—	—	UNKWN	—	—

PKIB0366E



PKIA2050E

CAN SYSTEM (TYPE 7)


[CAN]

Case 3

Check harness between BCM and Low Tire Pressure Warning Control Unit. Refer to [LAN-182, "Circuit Check Between BCM and Low Tire Pressure Warning Control Unit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM/SEC	TIRE-P	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—

PKIB0367E



PKIA2051E

LAN

CAN SYSTEM (TYPE 7)


[CAN]

Case 4

Check harness between Low Tire Pressure Warning Control Unit and steering angle sensor. Refer to [LAN-182, "Circuit Check Between Low Tire Pressure Warning Control Unit and Steering Angle Sensor"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM/SEC	TIRE-P	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—

PKIB0368E



PKIA2052E

CAN SYSTEM (TYPE 7)

[CAN]


Case 5

Check harness between steering angle sensor and VDC/TCS/ABS control unit. Refer to [LAN-183, "Circuit Check Between Steering Angle Sensor and VDC/TCS/ABS Control Unit"](#).

A
B
C
D
E
F
G
H
I
J
L
M

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM/SEC	TIRE-P	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—

PKIB0369E



LAN

CAN SYSTEM (TYPE 7)


[CAN]

Case 6

Check ECM circuit. Refer to [LAN-183, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM/SEC	TIRE-P	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW ^N ✓	—	UNKW ^N ✓	UNKW ^N ✓	—	—	UNKW ^N ✓	UNKW ^N ✓
METER A/C AMP	No indication	—	UNKW ^N	UNKW ^N ✓	—	UNKW ^N	UNKW ^N	—	UNKW ^N	—
BCM	—	NG	UNKW ^N	UNKW ^N ✓	UNKW ^N	—	—	—	—	UNKW ^N
AIR PRESSURE MONITOR	No indication	NG	UNKW ^N	—	UNKW ^N	—	—	—	—	—
ABS	—	NG	UNKW ^N	UNKW ^N ✓	—	—	—	UNKW ^N	—	—

PKIB0370E



PKIA2054E

CAN SYSTEM (TYPE 7)


[CAN]

Case 7

Check data link connector circuit. Refer to [LAN-184, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM/SEC	TIRE-P	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN
AIR PRESSURE MONITOR	No indication ✓	NG	UNKWN	—	UNKWN	—	—	—	—	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—

PKIB0371E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 7)

[CAN]


Case 8

Check unified meter and A/C amp. circuit. Refer to [LAN-184, "Unified Meter and A/C Amp. Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM/SEC	TIRE-P	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	—	—	UNKWN	UNKWN
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN ✓	—	—	—	—	UNKWN
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	UNKWN ✓	—	—	—	—	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—

PKIB0372E

▨ : Malfunctioning part



PKIA2056E

CAN SYSTEM (TYPE 7)


[CAN]

Case 9

Check BCM circuit. Refer to [LAN-185, "BCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM/SEC	TIRE-P	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	—	—	UNKWN	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN ✓	UNKWN	—	UNKWN	—
BCM	—	NG	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	—	—	UNKWN ✓
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—

PKIB0373E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 7)

[CAN]


Case 10

Check Low Tire Pressure Warning Control Unit circuit. Refer to [LAN-185, "Low Tire Pressure Warning Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM/SEC	TIRE-P	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—

PKIB0374E

//// : Malfunctioning part



PKIA2058E

CAN SYSTEM (TYPE 7)


[CAN]

Case 11

Check steering angle sensor circuit. Refer to [LAN-186. "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM/SEC	TIRE-P	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	UNKWN ✓	—	—

PKIB0375E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 7)

[CAN]


Case 12

Check VDC/TCS/ABS control unit circuit. Refer to [LAN-186, "VDC/TCS/ABS Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM/SEC	TIRE-P	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN ✓	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	UNKWN ✓	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—
ABS	—	NG	UNKWN ✓	UNKWN	—	—	—	UNKWN	—	—

PKIB0376E

▨ : Malfunctioning part



PKIA2060E

CAN SYSTEM (TYPE 7)


[CAN]

Case 13

Check IPDM E/R circuit. Refer to [LAN-187, "IPDM E/R Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM/SEC	TIRE-P	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWVN	—	UNKWVN	UNKWVN	—	—	UNKWVN	UNKWVN ✓
METER A/C AMP	No indication	—	UNKWVN	UNKWVN	—	UNKWVN	UNKWVN	—	UNKWVN	—
BCM	—	NG	UNKWVN	UNKWVN	UNKWVN	—	—	—	—	UNKWVN ✓
AIR PRESSURE MONITOR	No indication	NG	UNKWVN	—	UNKWVN	—	—	—	—	—
ABS	—	NG	UNKWVN	UNKWVN	—	—	—	UNKWVN	—	—

PKIB0377E



Case 14

Check CAN communication circuit. Refer to [LAN-188, "CAN Communication Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM/SEC	TIRE-P	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWVN ✓	—	UNKWVN ✓	UNKWVN ✓	—	—	UNKWVN ✓	UNKWVN ✓
METER A/C AMP	No indication ✓	—	UNKWVN	UNKWVN	—	UNKWVN	UNKWVN	—	UNKWVN	—
BCM	—	NG	UNKWVN ✓	UNKWVN ✓	UNKWVN ✓	—	—	—	—	UNKWVN ✓
AIR PRESSURE MONITOR	No indication ✓	NG	UNKWVN	—	UNKWVN	—	—	—	—	—
ABS	—	NG	UNKWVN ✓	UNKWVN ✓	—	—	—	UNKWVN ✓	—	—

PKIB0378E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 7)

[CAN]

Case 15

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-190, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM/SEC	TIRE-P	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—

PKIB0379E

Case 16

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-190, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM/SEC	TIRE-P	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—
BCM	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—

PKIB0380E

Circuit Check Between Data Link Connector and Unified Meter and A/C Amp.

AKS00354

1. CHECK HARNESS FOR OPEN CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector and unified meter and A/C amp. connector.
4. Check continuity between data link connector M8 terminals 6 (L), 14 (R) and unified meter and A/C amp. harness connector M48 terminals 1 (L), 11 (R).

6 (L) – 1 (L) : Continuity should exist.

14 (R) – 11 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-164, "Work Flow"](#).
- NG >> Repair harness.



Circuit Check Between Unified Meter and A/C Amp. and BCM

AKS00355

1. CHECK HARNESS FOR OPEN CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following connectors.
 - ECM connector
 - Unified meter and A/C amp. connector
 - BCM connector
4. Check continuity between unified meter and A/C amp. harness connector M48 terminals 1 (L), 11 (R) and BCM harness connector M3 terminals 70 (L), 71 (R).

1 (L) – 70 (L) : Continuity should exist.

11 (R) – 71 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-164, "Work Flow"](#).
- NG >> Repair harness.



A
B
C
D
E
F
G
H
I
J
L
M

LAN

Circuit Check Between BCM and Low Tire Pressure Warning Control Unit

AKS00356

1. CHECK HARNESS FOR OPEN CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following connectors.
 - ECM connector
 - BCM connector
 - Low tire pressure warning control unit connector
4. Check continuity between BCM harness connector M3 terminals 70 (L), 71 (R) and low tire pressure warning control unit harness connector M77 terminals 9 (L), 21 (R).

70 (L) – 9 (L) : Continuity should exist.

71 (R) – 21 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-164, "Work Flow"](#).
- NG >> Repair harness.



Circuit Check Between Low Tire Pressure Warning Control Unit and Steering Angle Sensor

AKS00357

1. CHECK HARNESS FOR OPEN CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following connectors.
 - ECM connector
 - Low tire pressure warning control unit connector
 - Steering angle sensor connector
4. Check continuity between Low tire pressure warning control unit harness connector M77 terminals 9 (L), 21 (R) and steering angle sensor harness connector M22 terminals 4 (L), 5 (R).

9 (L) – 4 (L) : Continuity should exist.

21 (R) – 5 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-164, "Work Flow"](#).
- NG >> Repair harness.



Circuit Check Between Steering Angle Sensor and VDC/TCS/ABS Control Unit

AKS00358

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connector for damage, bend and loose connection (connector-side and harness-side).
 - Harness connector M15
 - Harness connector E108

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect steering angle sensor connector and harness connector M15.
2. Check continuity between steering angle sensor harness connector M22 terminals 4 (L), 5 (R) and harness connector M15 terminals 2G (L), 7G (R).

4 (L) – 2G (L) : Continuity should exist.**5 (R) – 7G (R) : Continuity should exist.**

OK or NG

OK >> GO TO 3.

NG >> Repair harness.

**3. CHECK HARNESS FOR OPEN CIRCUIT**


1. Disconnect VDC/TCS/ABS control unit connector.
2. Check continuity between harness connector E108 terminals 2G (L), 7G (R) and VDC/TCS/ABS control unit harness connector E118 terminals 61 (L), 63 (R).

2G (L) – 61 (L) : Continuity should exist.**7G (R) – 63 (R) : Continuity should exist.**

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-164, "Work Flow"](#).

NG >> Repair harness.

**ECM Circuit Check**

AKS00359

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connector for damage, bend and loose connection (control module-side and harness-side).
 - ECM connector
 - Harness connector F102
 - Harness connector M72

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector F101 terminals 94 (L) and 86 (R).

94 (L) – 86 (R) : Approx. 108 – 132Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and data link connector.



Data Link Connector Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M8 terminals 6 (L) and 14 (R).

6 (L) – 14 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-164, "Work Flow"](#).
 NG >> Repair harness between data link connector and unified meter and A/C amp.



Unified Meter and A/C Amp. Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of unified meter and A/C amp. for damage, bend and loose connection (meter-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect unified meter and A/C amp. connector.
2. Check resistance between unified meter and A/C amp. harness connector M48 terminals 1 (L) and 11 (R).

1 (L) – 11 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. and BCM.



AKS0035C

BCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of BCM for damage, bend and loose connection (control module-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M3 terminals 70 (L) and 71 (R).

70 (L) – 71 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace BCM.
 NG >> Repair harness between BCM and low tire pressure warning control unit.



AKS0035D

Low Tire Pressure Warning Control Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of low tire pressure warning control unit for damage, bend and loose connection (control unit-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect low tire pressure warning control unit connector.
2. Check resistance between low tire pressure warning control unit harness connector M77 terminals 9 (L) and 21 (R).

9 (L) – 21 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace low tire pressure warning control unit.
 NG >> Repair harness between low tire pressure warning control unit and steering angle sensor.



AKS0035E

Steering Angle Sensor Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M22 terminals 4 (L) and 5 (R).

4 (L) – 5 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and harness connector M15.



AKS0035F

VDC/TCS/ABS Control Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of VDC/TCS/ABS control unit for damage, bend and loose connection (control unit-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect VDC/TCS/ABS control unit connector.
2. Check resistance between VDC/TCS/ABS control unit harness connector E118 terminals 61 (L) and 63 (R).

61 (L) – 63 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace VDC/TCS/ABS control unit.
 NG >> Repair harness between VDC/TCS/ABS control unit and IPDM E/R.



AKS0035G

IPDM E/R Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of IPDM E/R for damage, bend and loose connection (control module-side and harness-side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

48 (L) – 49 (R) : Approx. 108 – 132Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and VDC/TCS/ABS control unit.



LKIA0030E

CAN Communication Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connector for damage, bend and loose connection (control module-side, meter-side, sensor-side, control unit-side and harness-side).
 - ECM
 - Unified meter and A/C amp.
 - BCM
 - Low tire pressure warning control unit
 - Steering angle sensor
 - VDC/TCS/ABS control unit
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector F102.
2. Check continuity between ECM harness connector F101 terminals 94 (L) and 86 (R).

94 (L) – 86 (R) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector F102.




3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector F101 terminals 94 (L), 86 (R) and ground.

94 (L) – ground : Continuity should not exist.
86 (R) – ground : Continuity should not exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness between ECM and harness connector F102.



4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - Unified meter and A/C amp. connector
 - BCM connector
 - Low tire pressure warning control unit connector
 - Steering angle sensor connector
 - Harness connector M15
2. Check continuity between data link connector M8 terminals 6 (L) and 14 (R).


6 (L) – 14 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M72.
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and BCM.
- Harness between data link connector and low tire pressure warning control unit.
- Harness between data link connector and steering angle sensor.
- Harness between data link connector and harness connector M15.



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M8 terminals 6 (L), 14 (R) and ground.

6 (L) – ground : Continuity should not exist.


14 (R) – ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M72.
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and BCM.
- Harness between data link connector and low tire pressure warning control unit.
- Harness between data link connector and steering angle sensor.
- Harness between data link connector and harness connector M15.



6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect VDC/TCS/ABS control unit connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).


48 (L) – 49 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and VDC/TCS/ABS control unit.
- Harness between IPDM E/R and harness connector E108.



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E9 terminals 48 (L), 49 (R) and ground.

48 (L) – ground : Continuity should not exist.


49 (R) – ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and VDC/TCS/ABS control unit.
- Harness between IPDM E/R and harness connector E108.



8. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

Check components inspection. Refer to [LAN-191, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-164, "Work Flow"](#).

NG >> Replace ECM and/or IPDM E/R.

IPDM E/R Check

1. CHECK IPDM E/R

1. Turn ignition switch ON and then OFF.
2. Check for illuminated parking lamps and tail lamps.

Parking lamps and tail lamps should not illuminate.

OK or NG

OK >> Replace VDC/TCS/ABS control unit.

NG >> Replace IPDM E/R.

IPDM E/R Ignition Relay Circuit Check


Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-29, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-11, "IGNITION POWER SUPPLY — IGNITION SW. IN "ON" AND/OR "START" "](#).

Component Inspection ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 48 and 49.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	48 - 49	



A
B
C
D
E
F
G
H
I
J
L
M

LAN

