

SECTION **LAN**
LAN SYSTEM

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CONTENTS

CAN	
PRECAUTIONS	3
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	3
Precautions for Battery Service	3
Precautions When Using CONSULT-II	3
CHECK POINTS FOR USING CONSULT-II	3
Precautions For Trouble Diagnosis	3
CAN SYSTEM	3
Precautions For Harness Repair	4
CAN SYSTEM	4
TROUBLE DIAGNOSES WORK FLOW	5
When Displaying CAN Communication System Errors	5
WHEN A MALFUNCTION IS DETECTED BY CAN COMMUNICATION SYSTEM	5
WHEN A MALFUNCTION IS DETECTED EXCEPT CAN COMMUNICATION SYSTEM	5
TROUBLE DIAGNOSIS FLOW CHART	6
Diagnosis Procedure	7
SELECTING CAN SYSTEM TYPE (HOW TO USE SPECIFICATION TABLE)	7
ACQUISITION OF DATA BY CONSULT-II	8
HOW TO USE CHECK SHEET TABLE	9
CAN Diagnostic Support Monitor	15
DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR ECM	15
DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR TCM	16
DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR UNIFIED METER AND A/C AMP.	17
DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR BCM	18
DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)	18
DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR VDC/TCS/ABS CON-	
TROL UNIT	19
DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR IPDM E/R	20
CAN COMMUNICATION	21
System Description	21
CAN Communication Unit	21
TYPE 1	22
TYPE 2	24
TYPE 3	25
TYPE 4	26
TYPE 5	28
CAN SYSTEM (TYPE 1)	30
System Description	30
Component Parts and Harness Connector Location..	30
Wiring Diagram — CAN —	31
CHECK SHEET	33
CHECK SHEET RESULTS (EXAMPLE)	35
Inspection Between TCM and Data Link Connector Circuit	45
Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit	45
ECM Circuit Inspection	46
TCM Circuit Inspection	47
Data Link Connector Circuit Inspection	47
Unified Meter and A/C Amp. Circuit Inspection	48
BCM Circuit Inspection	48
ABS Actuator and Electric Unit (Control Unit) Circuit Inspection	49
IPDM E/R Circuit Inspection	49
CAN Communication Circuit Inspection	50
IPDM E/R Ignition Relay Circuit Inspection	53
CAN SYSTEM (TYPE 2)	54
System Description	54
Component Parts and Harness Connector Location..	54
Wiring Diagram — CAN —	55
CHECK SHEET	57
CHECK SHEET RESULTS (EXAMPLE)	59
Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit	66
ECM Circuit Inspection	67

Data Link Connector Circuit Inspection	68	Inspection Between Data Link Connector and VDC/ TCS/ABS Control Unit Circuit	109
Unified Meter and A/C Amp. Circuit Inspection	68	ECM Circuit Inspection	110
BCM Circuit Inspection	69	Data Link Connector Circuit Inspection	111
ABS Actuator and Electric Unit (Control Unit) Circuit Inspection	69	Unified Meter and A/C Amp. Circuit Inspection	111
IPDM E/R Circuit Inspection	70	BCM Circuit Inspection	112
CAN Communication Circuit Inspection	71	Steering Angle Sensor Circuit Inspection	112
IPDM E/R Ignition Relay Circuit Inspection	74	VDC/TCS/ABS Control Unit Circuit Inspection	113
CAN SYSTEM (TYPE 3)	75	IPDM E/R Circuit Inspection	113
System Description	75	CAN Communication Circuit Inspection	114
Component Parts and Harness Connector Location	75	IPDM E/R Ignition Relay Circuit Inspection	117
Wiring Diagram — CAN —	76	CAN SYSTEM (TYPE 5)	118
CHECK SHEET	78	System Description	118
CHECK SHEET RESULTS (EXAMPLE)	80	Component Parts and Harness Connector Location	118
Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit	87	Wiring Diagram — CAN —	119
ECM Circuit Inspection	88	CHECK SHEET	121
Data Link Connector Circuit Inspection	89	CHECK SHEET RESULTS (EXAMPLE)	123
Unified Meter and A/C Amp. Circuit Inspection	89	Inspection Between TCM and Data Link Connector Circuit	134
BCM Circuit Inspection	90	Inspection Between Data Link Connector and VDC/ TCS/ABS Control Unit Circuit	134
ABS Actuator and Electric Unit (Control Unit) Circuit Inspection	90	ECM Circuit Inspection	135
IPDM E/R Circuit Inspection	91	TCM Circuit Inspection	136
CAN Communication Circuit Inspection	92	Data Link Connector Circuit Inspection	136
IPDM E/R Ignition Relay Circuit Inspection	95	Unified Meter and A/C Amp. Circuit Inspection	137
CAN SYSTEM (TYPE 4)	96	BCM Circuit Inspection	137
System Description	96	Steering Angle Sensor Circuit Inspection	138
Component Parts and Harness Connector Location	96	VDC/TCS/ABS Control Unit Circuit Inspection	138
Wiring Diagram — CAN —	97	IPDM E/R Circuit Inspection	139
CHECK SHEET	99	CAN Communication Circuit Inspection	139
CHECK SHEET RESULTS (EXAMPLE)	101	IPDM E/R Ignition Relay Circuit Inspection	142

PRECAUTIONS

PPF:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

AKS00CNH

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precautions for Battery Service

AKS003TZ

Before disconnecting the battery, lower both the driver and passenger windows. This will prevent any interference between the window edge and the vehicle when the door is opened/closed. During normal operation, the window slightly raises and lowers automatically to prevent any window to vehicle interference. The automatic window function will not work with the battery disconnected.

Precautions When Using CONSULT-II

AKS003M4

When connecting CONSULT-II to data link connector, connect them through CONSULT-II CONVERTER.

CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

CHECK POINTS FOR USING CONSULT-II

1. Has CONSULT-II been used without connecting CONSULT-II CONVERTER on this vehicle?
 - If YES, GO TO 2.
 - If NO, GO TO 5.
2. Is there any indication other than indications relating to CAN communication system in the self-diagnosis results?
 - If YES, GO TO 3.
 - If NO, GO TO 4.
3. Based on self-diagnosis results unrelated to CAN communication, carry out the inspection.
4. Malfunctions may be detected in self-diagnosis depending on control units carrying out CAN communication. Therefore, erase the self-diagnosis results.
5. Diagnose CAN communication system. Refer to [LAN-5, "TROUBLE DIAGNOSES WORK FLOW"](#) .

Precautions For Trouble Diagnosis CAN SYSTEM

AKS000ZD

- Do not apply voltage of 7.0 V or higher to the measurement terminals.
- Use the tester with its open terminal voltage being 7.0 V or less.
- Be sure to turn ignition switch OFF and disconnect the battery cable from the negative terminal before checking the circuit.

A
B
C
D
E
F
G
H
I
J
L
M

LAN


PRECAUTIONS

[CAN]


Precautions For Harness Repair CAN SYSTEM

AKS000ZE

- Solder the repaired parts, and wrap with tape. [Frays of twisted line must be within 110 mm (4.33 in).]



- Do not perform bypass wire connections for the repair parts. (The spliced wire will become separated and the characteristics of twisted line will be lost.)



TROUBLE DIAGNOSES WORK FLOW

PPF:00004

When Displaying CAN Communication System Errors

AKS00C60

WHEN A MALFUNCTION IS DETECTED BY CAN COMMUNICATION SYSTEM

- CAN communication line is open. (CAN H, CAN L, or both)
- CAN communication line is shorted. (Ground, between CAN lines, or other harnesses)
- The areas related to CAN communication of unit is malfunctioning.

WHEN A MALFUNCTION IS DETECTED EXCEPT CAN COMMUNICATION SYSTEM

- Removal and installation of parts: When the units that perform CAN communication or the sensors related to CAN communication are removed and installed, malfunction may be detected (or DTC other than CAN communication may be detected).
- Fuse blown out (removed): CAN communication of the unit may be stopped at such time.
- Low voltage: If the voltage decreases because of battery discharge when IGN is ON, malfunction may be detected by self-diagnosis according to the units.

A

B

C

D

E

F

G

H

I


J

LAN

L

M

TROUBLE DIAGNOSIS FLOW CHART



- Step 1: Refer to [LAN-7, "SELECTING CAN SYSTEM TYPE \(HOW TO USE SPECIFICATION TABLE\)"](#) .
- Step 2: Refer to [LAN-8, "ACQUISITION OF DATA BY CONSULT-II"](#) .
- Step 3: Refer to [LAN-9, "HOW TO USE CHECK SHEET TABLE"](#) .
- Step 4: Refer to [LAN-10, "Example of Filling in Check Sheet When Initial Conditions Are Reproduced"](#) .
- Step 5: Check and repair according to system diagnosis.

TROUBLE DIAGNOSES WORK FLOW

[CAN]

AKS00C6P

Diagnosis Procedure

SELECTING CAN SYSTEM TYPE (HOW TO USE SPECIFICATION TABLE)

Determine CAN system type from the equipment of the vehicle to select applicable check sheet.

(Example) Coupe/2WD/VQ35DE/MT/VDC

CAN Communication Unit

Go to CAN system, when selecting your CAN system type from the following table.

Body type	Coupe					Roadster		
Axle	2WD							
Engine	VQ35DE							
Transmission	A/T		M/T			A/T		M/T
Brake control	TCS	VDC	ABS	TCS	VDC	TCS	TCS	VDC
CAN system type	1	5	2	3	4	1	3	4
CAN system trouble diagnosis	XX-XX	XX-XX	XX-XX	XX-XX	XX-XX	XX-XX	XX-XX	XX-XX

Check basic specification of the vehicle.

Which number is selected when sequentially selecting from the top of the specification table?
The number is "CAN system type" of the applicable vehicle.

In the case of this example:
It corresponds to type 4.

PKIB9408E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

HOW TO USE CHECK SHEET TABLE

Check sheet table		Use when the initial conditions are reproduced								Use when the initial conditions are not reproduced	
		CAN DIAG SUPPORT MNTR									
		SELECT SYSTEM screen		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB2814E

1. Unit names displayed on CONSULT-II
2. “No indication”: Put a check mark to it if the unit name described in step 1 is not displayed on “SELECT SYSTEM” screen of CONSULT-II. (Unit communicating with CONSULT-II via CAN communication line)
“—”: Column not used (Unit communicating with CONSULT-II excluding CAN communication line)
3. “NG”: Display “NG” when malfunction is detected in the initial diagnosis of the diagnosed unit. Replace the unit if “NG” is displayed.
“—”: Column not used (Initial diagnosis is not performed.)
4. “UNKWN”: Display “UNKWN” when the diagnosed unit does not transmit the data normally. Put a check mark to it if “UNKWN” is displayed on CONSULT-II.
“—”: Column not used (Transmit diagnosis is not performed.)
5. “UNKWN”: Display “UNKWN” when the diagnosed unit does not receive the data normally. Put a check mark to it if “UNKWN” is displayed on CONSULT-II.
“—”: Column not used (It is not necessary for CAN communication trouble diagnosis.)

NOTE:


CAN communication diagnosis checks if CAN communication works normally. (Contents of data are not diagnosed.)

- When the initial conditions are reproduced. Refer to [LAN-10, "Example of Filling in Check Sheet When Initial Conditions Are Reproduced"](#) .
- When the initial conditions are not reproduced. Refer to [LAN-13, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#) .

TROUBLE DIAGNOSES WORK FLOW

[CAN]

Example of Filling in Check Sheet When Initial Conditions Are Reproduced



- Put a check mark to "No indication" if some of unit names listed on the column of diagnosis system selection screen of a check sheet table are not displayed on "SELECT SYSTEM" screen attached to the check sheet.

NOTE:

Put a check mark to "No indication" of METER A/C AMP because METER A/C AMP is not displayed on "SELECT SYSTEM" screen.


- Confirm the unit name that "UNKWN" is displayed from the copy of "CAN DIAG SUPPORT MNTR" screen of "ENGINE" attached to the check sheet, and then put a check mark to the check sheet table.

NOTE:

In "CAN DIAG SUPPORT MNTR" screen, "UNKWN" is displayed on "TCM", "METER/M&A", "ICC", "AWD/4WD/e4WD" and "EPS". But put a check mark to "METER/M&A" because "UNKWN" is listed on the column of reception diagnosis of the check sheet table.

TROUBLE DIAGNOSES WORK FLOW

[CAN]



- Confirm the unit name that "UNKWN" is displayed on the copy of "CAN DIAG SUPPORT MNTR" screen of "BCM", "ABS" and "IPDM E/R" as well as "ENGINE". And then, put a check mark to the check sheet table.

NOTE:

- For "BCM", "UNKWN" is displayed on "METER/M&A". Put a check mark to it.
- For "ABS", "UNKWN" is displayed on "TCM" and "METER/M&A". But a put a check mark to "METER/M&A" because "UNKWN" is listed on the column of reception diagnosis on the check sheet.
- For "IPDM E/R", "UNKWN" is not displayed. Do not put a check to it.

A
B
C
D
E
F
G
H
I
J
LAN
L
M

TROUBLE DIAGNOSES WORK FLOW

[CAN]

The arranged results of CAN diagnosis support monitor

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—


Choose similar indications between the results of CAN diagnosis support monitor and the results of the check sheet. Malfunctioning parts are found.

Case 4

Check unified meter and A/C amp. circuit.

Check sheet results (example)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—



PKIB2817E

NOTE:

There is a case that some of "CAN DIAG SUPPORT MNTR" and "SELF-DIAG RESULTS" are not needed for diagnosis. In the case, "UNKWN" and "CAN COMM CIRCUIT(U1000)" in "Check sheet results (example)" change to "—". Then, ignore check marks on the check sheet table.

4. Perform system diagnosis for possible causes identified.
5. Perform diagnosis again after inspection and repair. Make sure that repair is completely performed, and then end the procedure.

Start CAN system trouble diagnosis if this procedure can be confirmed. Refer to [LAN-21, "CAN Communication Unit"](#).

TROUBLE DIAGNOSES WORK FLOW

[CAN]

Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

SYSTEM ENGINE	SYSTEM METER A/C AMP	SYSTEM BCM	SYSTEM ABS	SYSTEM IPDM E/R
SELF-DIAG RESULTS	SELF-DIAG RESULTS	SELF-DIAG RESULTS	SELF-DIAG RESULTS	SELF-DIAG RESULTS
DTC RESULTS	DTC RESULTS	DTC RESULTS	DTC RESULTS	DTC RESULTS
CAN COMM CIRCUIT [U1000]	CAN COMM CIRCUIT [U1000]	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	CAN COMM CIRCUIT [U1000]	CAN COMM CIRCUIT [U1000]
CAN COMM CIRCUIT [U1001]	CAN COMM CIRCUIT PAST [U1000]		1	CAN COMM CIRCUIT PAST [U1000]
1t				
1t				

PKIB2818E

- See "SELF-DIAG RESULTS" of all units attached to the check sheet. If "CAN COMM CIRCUIT", "CAN COMM CIRCUIT (U1000)" or "CAN COMM CIRCUIT (U1001)" is displayed, put a check mark to the applicable column of self-diagnostic results of the check sheet table.

NOTE:

- For "ENGINE", "CAN COMM CIRCUIT (U1000)" and "CAN COMM CIRCUIT (U1001)" are displayed. Put a check mark to it.
- For "METER/M&A", "CAN COMM CIRCUIT (U1000)" is displayed. Put a check mark to it.
- For "BCM", "NO DTC IS DETECTED" is displayed. Do not put a check mark to it.
- For "ABS", "CAN COMM CIRCUIT (U1000)" is displayed. Put a check mark to it.
- For "IPDM E/R", "CAN COMM CIRCUIT (U1000)" is displayed. Put a check mark to it.

A
B
C
D
E
F
G
H
I
J
L
M

LAN

TROUBLE DIAGNOSES WORK FLOW

[CAN]

The arranged results of self-diagnosis

Check sheet table

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
	Initial diagnosis	Transmit diagnosis	Receive diagnosis									
			ECM	METER M/A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R				
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
METER A/C AMP	No indication	-	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	CAN COMM CIRCUIT (U1000)	-
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-	CAN COMM CIRCUIT (U1000)	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	-	-	CAN COMM CIRCUIT (U1000)	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	UNKWN	-	-	-	-	CAN COMM CIRCUIT (U1000)	-


When the arranged results of self-diagnosis and check sheet results (example) are corresponding, possible causes can be selected.

Case 2
Check ECM circuit.

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
	Initial diagnosis	Transmit diagnosis	Receive diagnosis									
			ECM	METER M/A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R				
ENGINE	-	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	CAN COMM CIRCUIT (U1000)	-
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	CAN COMM CIRCUIT (U1000)	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	CAN COMM CIRCUIT (U1000)	-
IPDM E/R	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	CAN COMM CIRCUIT (U1000)	-

Case 9
Check CAN communication circuit.

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
	Initial diagnosis	Transmit diagnosis	Receive diagnosis									
			ECM	METER M/A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R				
ENGINE	-	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	CAN COMM CIRCUIT (U1000)	-
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	CAN COMM CIRCUIT (U1000)	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	CAN COMM CIRCUIT (U1000)	-
IPDM E/R	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	CAN COMM CIRCUIT (U1000)	-



PKIB2819E

NOTE:

There is a case that some of "CAN DIAG SUPPORT MNTR" and "SELF-DIAG RESULTS" are not needed for diagnosis. In the case, "UNKWN" and "CAN COMM CIRCUIT(U1000)" in "Check sheet results (example)" change to "-". Then, ignore check marks on the check sheet table.

2. For the selected possible causes, it is expected that malfunctions have been found in the past.

TROUBLE DIAGNOSES WORK FLOW

[CAN]

AKS00C6Q

CAN Diagnostic Support Monitor

DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR ECM

(Example)	CAN DIAG SUPPORT MNTR <table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th colspan="2">ENGINE</th></tr> <tr><td> </td><td style="text-align: right;">PRSNT</td></tr> <tr><td>INITIAL DIAG</td><td style="text-align: right;">OK</td></tr> <tr><td>TRANSMIT DIAG</td><td style="text-align: right;">OK</td></tr> <tr><td>TCM</td><td style="text-align: right;">OK</td></tr> <tr><td>VDC/TCS/ABS</td><td style="text-align: right;">OK</td></tr> <tr><td>METER/M&A</td><td style="text-align: right;">OK</td></tr> <tr><td>ICC</td><td style="text-align: right;">UNKWN</td></tr> <tr><td>BCM/SEC</td><td style="text-align: right;">OK</td></tr> <tr><td>IPDM E/R</td><td style="text-align: right;">OK</td></tr> <tr><td>AWD/4WD/e4WD</td><td style="text-align: right;">UNKWN</td></tr> <tr><td>PRINT</td><td style="text-align: right;">Scroll Down</td></tr> <tr><td>MODE</td><td>BACK</td></tr> <tr><td>LIGHT</td><td>COPY</td></tr> </table>	ENGINE			PRSNT	INITIAL DIAG	OK	TRANSMIT DIAG	OK	TCM	OK	VDC/TCS/ABS	OK	METER/M&A	OK	ICC	UNKWN	BCM/SEC	OK	IPDM E/R	OK	AWD/4WD/e4WD	UNKWN	PRINT	Scroll Down	MODE	BACK	LIGHT	COPY	CAN DIAG SUPPORT MNTR <table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th colspan="2">ENGINE</th></tr> <tr><td> </td><td style="text-align: right;">PRSNT</td></tr> <tr><td>TRANSMIT DIAG</td><td style="text-align: right;">OK</td></tr> <tr><td>TCM</td><td style="text-align: right;">OK</td></tr> <tr><td>VDC/TCS/ABS</td><td style="text-align: right;">OK</td></tr> <tr><td>METER/M&A</td><td style="text-align: right;">OK</td></tr> <tr><td>ICC</td><td style="text-align: right;">UNKWN</td></tr> <tr><td>BCM/SEC</td><td style="text-align: right;">OK</td></tr> <tr><td>IPDM E/R</td><td style="text-align: right;">OK</td></tr> <tr><td>AWD/4WD/e4WD</td><td style="text-align: right;">UNKWN</td></tr> <tr><td>EPS</td><td style="text-align: right;">UNKWN</td></tr> <tr><td>PRINT</td><td style="text-align: right;">Scroll Up</td></tr> <tr><td>MODE</td><td>BACK</td></tr> <tr><td>LIGHT</td><td>COPY</td></tr> </table>	ENGINE			PRSNT	TRANSMIT DIAG	OK	TCM	OK	VDC/TCS/ABS	OK	METER/M&A	OK	ICC	UNKWN	BCM/SEC	OK	IPDM E/R	OK	AWD/4WD/e4WD	UNKWN	EPS	UNKWN	PRINT	Scroll Up	MODE	BACK	LIGHT	COPY
ENGINE																																																										
	PRSNT																																																									
INITIAL DIAG	OK																																																									
TRANSMIT DIAG	OK																																																									
TCM	OK																																																									
VDC/TCS/ABS	OK																																																									
METER/M&A	OK																																																									
ICC	UNKWN																																																									
BCM/SEC	OK																																																									
IPDM E/R	OK																																																									
AWD/4WD/e4WD	UNKWN																																																									
PRINT	Scroll Down																																																									
MODE	BACK																																																									
LIGHT	COPY																																																									
ENGINE																																																										
	PRSNT																																																									
TRANSMIT DIAG	OK																																																									
TCM	OK																																																									
VDC/TCS/ABS	OK																																																									
METER/M&A	OK																																																									
ICC	UNKWN																																																									
BCM/SEC	OK																																																									
IPDM E/R	OK																																																									
AWD/4WD/e4WD	UNKWN																																																									
EPS	UNKWN																																																									
PRINT	Scroll Up																																																									
MODE	BACK																																																									
LIGHT	COPY																																																									

SKIB0591E

"SELECT SYSTEM" screen	"CAN DIAG SUPPORT MNTR" screen	Description	Present
ENGINE	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	TCM	Make sure of normal reception from TCM.	OK/UNKWN
	VDC/TCS/ABS	Make sure of normal reception from VDC/TCS/ABS control unit.	OK/UNKWN
		Make sure of normal reception from ABS actuator and electric unit (control unit).	OK/UNKWN
	METER/M&A	Make sure of normal reception from unified meter and A/C amp.	OK/UNKWN
	ICC	ICC is not diagnosed.	UNKWN
	BCM/SEC	Make sure of normal reception from BCM.	OK/UNKWN
	IPDM E/R	Make sure of normal reception from IPDM E/R.	OK/UNKWN
	AWD/4WD/e4WD	AWD/4WD/e4WD is not diagnosed.	UNKWN
EPS	EPS is not diagnosed.	UNKWN	

Display Results (Present)

- OK: Normal
- NG: Malfunction
- UNKWN: The diagnosed unit does not transmit or receive the applicable data normally.

LAN

TROUBLE DIAGNOSES WORK FLOW

[CAN]

DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR TCM

(Example)

CAN DIAG SUPPORT MNTR			
A/T			
		PRSNT	
INITIAL DIAG		OK	
TRANSMIT DIAG		OK	
ECM		OK	
VDC/TCS/ABS		OK	
METER/M&A		OK	
ICC/e4WD		UNKWN	
AWD/4WD		UNKWN	
PRINT			
MODE	BACK	LIGHT	COPY

SKIB1623E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
A/T	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	ECM	Make sure of normal reception from ECM.	OK/UNKWN
	VDC/TCS/ABS	Make sure of normal reception from ABS actuator and electric unit (control unit).	OK/UNKWN
	METER/M&A	Make sure of normal reception from unified meter and A/C amp.	OK/UNKWN
	ICC/e4WD	ICC/4WD is not diagnosed.	UNKWN
	AWD/4WD	AWD/4WD is not diagnosed.	UNKWN

Display Results (Present)

- OK: Normal
- NG: Malfunction
- UNKWN: The diagnosed unit does not transmit or receive the applicable data normally.

TROUBLE DIAGNOSES WORK FLOW

[CAN]

DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR UNIFIED METER AND A/C AMP.

(Example)

CAN DIAG SUPPORT MNTR				CAN DIAG SUPPORT MNTR			
METER A/C AMP				METER A/C AMP			
		PRSNT	PAST			PRSNT	PAST
TRANSMIT DIAG	OK	OK	OK	IPDM E/R	-	-	-
ECM	OK	OK	OK	DISPLAY	-	-	-
TCM	OK	OK	OK	I-KEY	-	-	-
BCM/SEC	OK	OK	OK	EPS	-	-	-
VDC/TCS/ABS	OK	OK	OK	AWD/4WD	-	-	-
IPDM E/R	-	-	-	e4WD	-	-	-
DISPLAY	-	-	-	ICC	-	-	-
I-KEY	-	-	-	LANE KEEP	-	-	-
EPS	-	-	-	TIRE-P	OK	OK	OK
PRINT			Scroll Down	PRINT		Scroll Up	
MODE	BACK	LIGHT	COPY	MODE	BACK	LIGHT	COPY

SKIB1624E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present	Past
METER A/C AMP	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN/-	OK/0/1~39/-
	ECM	Make sure of normal reception from ECM.	OK/UNKWN/-	
	TCM	Make sure of normal reception from TCM.	OK/UNKWN/-	
	BCM/SEC	Make sure of normal reception from BCM.	OK/UNKWN/-	
	VDC/TCS/ABS	Make sure of normal reception from VDC/TCS/ABS control unit.	OK/UNKWN/-	
		Make sure of normal reception from ABS actuator and electric unit (control unit).	OK/UNKWN/-	
	IPDM E/R	IPDM E/R is not diagnosed.	-	
	DISPLAY	DISPLAY is not diagnosed.	-	
	I-KEY	I-KEY is not diagnosed.	-	
	EPS	EPS is not diagnosed.	-	
	AWD/4WD	AWD/4WD is not diagnosed.	-	
	e4WD	e4WD is not diagnosed.	-	
	ICC	ICC is not diagnosed.	-	
LANE KEEP	LANE KEEP is not diagnosed.	-		
TIRE-P	Not available for CAN system diagnosis.	OK/UNKWN		

Display Results (Present)

- OK: Normal
- UNKWN: The diagnosed unit does not transmit or receive the applicable data normally.
- -: There is no received unit or the unit is not in the condition that reception diagnosis is performed

Display Results (Past)

- OK: Normal
- 0: There is malfunction now.
- 1 ~ 39: Displays when it is normal at present and finds malfunction in the past. It increases like 0→1→2...38→39 after returning to the normal condition whenever IGN OFF→ON. If it is over 39, it is fixed to 39 until the self-diagnostic results are erased. It returns to 0 when malfunction is detected again in the process.
- -: Undiagnosed

TROUBLE DIAGNOSES WORK FLOW

[CAN]

DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR BCM

(Example)

CAN DIAG SUPPORT MNTR			
BCM			
	PRSN		
INITIAL DIAG	OK		
TRANSMIT DIAG	OK		
ECM	OK		
IPDM E/R	OK		
METER/M&A	OK		
I-KEY	OK		
PRINT			
MODE	BACK	LIGHT	COPY

SKIB1625E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
BCM	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	ECM	Make sure of normal reception from ECM.	OK/UNKWN
	IPDM E/R	Make sure of normal reception from IPDM E/R.	OK/UNKWN
	METER/M&A	Make sure of normal reception from unified meter and A/C amp.	OK/UNKWN
	I-KEY	I-KEY is not diagnosed.	OK

Display Results (Present)

- OK: Normal
- NG: Malfunction
- UNKWN: The diagnosed unit does not transmit or receive the applicable data normally.

DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

ABS models

(Example)

CAN DIAG SUPPORT MNTR			
ABS			
	PRSN		
INITIAL DIAG	OK		
TRANSMIT DIAG	OK		
ECM	OK		
PRINT			
MODE	BACK	LIGHT	COPY

PKIA8949E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
ABS	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	ECM	Make sure of normal reception from ECM.	OK/UNKWN

Display Results (Present)

- OK: Normal
- NG: Malfunction
- UNKWN: The diagnosed unit does not transmit or receive the applicable data normally.

TROUBLE DIAGNOSES WORK FLOW

[CAN]

TCS models

(Example)

CAN DIAG SUPPORT MNTR			
ABS			
	PRSNT		
INITIAL DIAG	OK		
TRANSMIT DIAG	OK		
ECM	OK		
TCM	OK		
PRINT			
MODE	BACK	LIGHT	COPY

SKIB0594E

A
B
C
D
E
F

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
ABS	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	ECM	Make sure of normal reception from ECM.	OK/UNKWN
	TCM	Make sure of normal reception from TCM.	OK/UNKWN

Display Results (Present)

- OK: Normal
- NG: Malfunction
- UNKWN: The diagnosed unit does not transmit or receive the applicable data normally.

DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR VDC/TCS/ABS CONTROL UNIT

(Example)

CAN DIAG SUPPORT MNTR			
ABS			
	PRSNT		
INITIAL DIAG	OK		
TRANSMIT DIAG	OK		
ECM	OK		
TCM	OK		
METER/M&A	OK		
STRG	OK		
PRINT			
MODE	BACK	LIGHT	COPY

SKIB1626E

G
H
I
J
LAN

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
ABS	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	ECM	Make sure of normal reception from ECM.	OK/UNKWN
	TCM	Make sure of normal reception from TCM.	OK/UNKWN
	METER/M&A	Make sure of normal reception from unified meter and A/C amp.	OK/UNKWN
	STRG	Make sure of normal reception from steering angle sensor.	OK/UNKWN

Display Results (Present)

- OK: Normal
- NG: Malfunction
- UNKWN: The diagnosed unit does not transmit or receive the applicable data normally.

CAN COMMUNICATION

PFP:23710

System Description

AKS000ZF

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

AKS00AVB

Go to CAN system, when selecting your CAN system type from the following table.

Body type	Coupe					Roadster		
Axle	2WD							
Engine	VQ35DE							
Transmission	A/T		M/T			A/T	M/T	
Brake control	TCS	VDC	ABS	TCS	VDC	TCS	TCS	VDC
CAN system type	1	5	2	3	4	1	3	4
CAN system trouble diagnosis	LAN-30	LAN-118	LAN-54	LAN-75	LAN-96	LAN-30	LAN-75	LAN-96

A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN COMMUNICATION

[CAN]

TYPE 1

System Diagram



Input/output Signal Chart

T: Transmit R: Receive

Signals	ECM	TCM	Unified meter and A/C amp.	BCM	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T	R	R		R	
Engine coolant temperature signal	T		R			
Accelerator pedal position signal	T	R			R	
Closed throttle position signal	T	R				
Wide open throttle position signal	T	R				
Battery voltage signal	T	R				
Stop lamp switch signal		R	T			
Fuel consumption monitor signal	T		R			
A/T self-diagnosis signal	R	T				
A/T CHECK indicator lamp signal		T	R			
A/T position indicator signal		T	R		R	
Manual mode gear position signal		T	R			
ABS operation signal		R			T	
A/T shift schedule change demand signal		R			T	
A/C switch signal	R			T		
A/C compressor request signal	T					R
A/C compressor feedback signal	T		R			
Blower fan motor switch signal	R			T		
Cooling fan speed request signal	T					R
Position lights request signal			R	T		R
Low beam request signal				T		R
Low beam status signal	R					T
High beam request signal			R	T		R
High beam status signal	R					T
Day time running light request signal				T		R

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Unified meter and A/C amp.	BCM	ABS actuator and electric unit (control unit)	IPDM E/R	
Vehicle speed signal			R		T		A
	R	R	T	R			B
Sleep request 1 signal			R	T			
Sleep request 2 signal				T		R	C
Wake up request 1 signal			R	T			
Door switch signal			R	T		R	D
Turn indicator signal			R	T			
Seat belt buckle switch signal			T	R			
Buzzer output signal			R	T			E
Fuel level sensor signal	R		T				
Malfunction indicator lamp signal	T		R				F
ASCD SET lamp signal	T		R				
ASCD operation signal	T	R					
ASCD CRUISE lamp signal	T		R				G
ASCD OD cancel request signal	T	R					
Output shaft revolution signal	R	T					
Turbine revolution signal	R	T					H
Front wiper request signal				T		R	
Front wiper stop position signal				R		T	I
Rear window defogger switch signal				T		R	
Rear window defogger control signal	R					T	
Manual mode signal		R	T				J
Not manual mode signal		R	T				
Manual mode shift up signal		R	T				
Manual mode shift down signal		R	T				
Manual mode indicator signal		T	R				
Theft warning horn request signal				T		R	L
Horn chirp signal				T		R	
Ignition switch signal				T		R	
ABS warning lamp signal			R		T		M
TCS OFF indicator lamp signal			R		T		
SLIP indicator lamp signal			R		T		
Brake warning lamp signal			R		T		

A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN COMMUNICATION

[CAN]

TYPE 2

System Diagram



Input/output Signal Chart

T: Transmit R: Receive

Signals	ECM	Unified meter and A/C amp.	BCM	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T	R		R	
Engine coolant temperature signal	T	R			
Accelerator pedal position signal	T			R	
Fuel consumption monitor signal	T	R			
A/C switch signal	R		T		
A/C compressor request signal	T				R
A/C compressor feedback signal	T	R			
Blower fan motor switch signal	R		T		
Cooling fan speed request signal	T				R
Position lights request signal		R	T		R
Low beam request signal			T		R
Low beam status signal	R				T
High beam request signal		R	T		R
High beam status signal	R				T
Day time running light request signal			T		R
Vehicle speed signal		R		T	
	R	T	R		
Sleep request 1 signal		R	T		
Sleep request 2 signal			T		R
Wake up request 1 signal		R	T		
Door switch signal		R	T		R
Turn indicator signal		R	T		
Seat belt buckle switch signal		T	R		
Buzzer output signal		R	T		
Fuel level sensor signal	R	T			
Malfunction indicator lamp signal	T	R			


CAN COMMUNICATION

[CAN]

Signals	ECM	Unified meter and A/C amp.	BCM	ABS actuator and electric unit (control unit)	IPDM E/R
ASCD SET lamp signal	T	R			
ASCD CRUISE lamp signal	T	R			
Front wiper request signal			T		R
Front wiper stop position signal			R		T
Rear window defogger switch signal			T		R
Rear window defogger control signal	R				T
Theft warning horn request signal			T		R
Horn chirp signal			T		R
Ignition switch signal			T		R
ABS warning lamp signal		R		T	
Brake warning lamp signal		R		T	

TYPE 3

System Diagram



Input/output Signal Chart

T: Transmit R: Receive

Signals	ECM	Unified meter and A/C amp.	BCM	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T	R		R	
Engine coolant temperature signal	T	R			
Accelerator pedal position signal	T			R	
Fuel consumption monitor signal	T	R			
A/C switch signal	R		T		
A/C compressor request signal	T				R
A/C compressor feedback signal	T	R			
Blower fan motor switch signal	R		T		
Cooling fan speed request signal	T				R
Position lights request signal		R	T		R
Low beam request signal			T		R
Low beam status signal	R				T


CAN COMMUNICATION

[CAN]

Signals	ECM	Unified meter and A/C amp.	BCM	ABS actuator and electric unit (control unit)	IPDM E/R
High beam request signal		R	T		R
High beam status signal	R				T
Day time running light request signal			T		R
Vehicle speed signal		R		T	
	R	T	R		
Sleep request 1 signal		R	T		
Sleep request 2 signal			T		R
Wake up request 1 signal		R	T		
Door switch signal		R	T		R
Turn indicator signal		R	T		
Seat belt buckle switch signal		T	R		
Buzzer output signal		R	T		
Fuel level sensor signal	R	T			
Malfunction indicator lamp signal	T	R			
ASCD SET lamp signal	T	R			
ASCD CRUISE lamp signal	T	R			
Front wiper request signal			T		R
Front wiper stop position signal			R		T
Rear window defogger switch signal			T		R
Rear window defogger control signal	R				T
Theft warning horn request signal			T		R
Horn chirp signal			T		R
Ignition switch signal			T		R
ABS warning lamp signal		R		T	
TCS OFF indicator lamp signal		R		T	
SLIP indicator lamp signal		R		T	
Brake warning lamp signal		R		T	

TYPE 4

System Diagram



CAN COMMUNICATION

[CAN]

Input/output Signal Chart

T: Transmit R: Receive

Signals	ECM	Unified meter and A/C amp.	BCM	Steering angle sensor	VDC/TCS/ABS control unit	IPDM E/R
Engine speed signal	T	R			R	
Engine coolant temperature signal	T	R				
Accelerator pedal position signal	T				R	
Fuel consumption monitor signal	T	R				
A/C switch signal	R		T			
A/C compressor request signal	T					R
A/C compressor feedback signal	T	R				
Blower fan motor switch signal	R		T			
Cooling fan speed request signal	T					R
Position lights request signal		R	T			R
Low beam request signal			T			R
Low beam status signal	R					T
High beam request signal		R	T			R
High beam status signal	R					T
Day time running light request signal			T			R
Vehicle speed signal		R			T	
	R	T	R			
Sleep request 1 signal		R	T			
Sleep request 2 signal			T			R
Wake up request 1 signal		R	T			
Door switch signal		R	T			R
Turn indicator signal		R	T			
Seat belt buckle switch signal		T	R			
Buzzer output signal		R	T			
Fuel level sensor signal	R	T				
Malfunction indicator signal	T	R				
ASCD SET lamp signal	T	R				
ASCD CRUISE lamp signal	T	R				
Front wiper request signal			T			R
Front wiper stop position signal			R			T
Rear window defogger switch signal			T			R
Rear window defogger control signal	R					T
Theft warning horn request signal			T			R
Horn chirp signal			T			R
Ignition switch signal			T			R
Steering angle sensor signal				T	R	
Tire pressure signal		R	T			
ABS warning lamp signal		R			T	
VDC OFF indicator lamp signal		R			T	
SLIP indicator lamp signal		R			T	
Brake warning lamp signal		R			T	

A

B

C

D

E

F

G

H

I

J

LAN

L


M

CAN COMMUNICATION

[CAN]

TYPE 5

System Diagram



PKIB7466E

Input/output Signal Chart

T: Transmit R: Receive

Signals	ECM	TCM	Unified meter and A/C amp.	BCM	Steering angle sensor	VDC/TCS/ABS control unit	IPDM E/R
Engine speed signal	T	R	R			R	
Engine coolant temperature signal	T		R				
Accelerator pedal position signal	T	R				R	
Closed throttle position signal	T	R					
Wide open throttle position signal	T	R					
Battery voltage signal	T	R					
Stop lamp switch signal		R	T				
Fuel consumption monitor signal	T		R				
A/T self-diagnosis signal	R	T					
A/T CHECK indicator lamp signal		T	R				
A/T position indicator signal		T	R			R	
Manual mode gear position signal		T	R				
ABS operation signal		R				T	
A/T shift schedule change demand signal		R				T	
A/C switch signal	R			T			
A/C compressor request signal	T						R
A/C compressor feedback signal	T		R				
Blower fan motor switch signal	R			T			
Cooling fan speed request signal	T						R
Position lights request signal			R	T			R
Low beam request signal				T			R
Low beam status signal	R						T
High beam request signal			R	T			R
High beam status signal	R						T
Day time running light request signal				T			R

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Unified meter and A/C amp.	BCM	Steering angle sensor	VDC/TCS/ABS control unit	IPDM E/R	A
Vehicle speed signal			R			T		B
Sleep request 1 signal	R	R	T	R				C
Sleep request 2 signal				T			R	D
Wake up request 1 signal			R	T				E
Door switch signal			R	T			R	F
Turn indicator signal			R	T				G
Seat belt buckle switch signal			T	R				H
Buzzer output signal			R	T				I
Fuel level sensor signal	R		T					J
Malfunction indicator lamp signal	T		R					K
ASCD SET lamp signal	T		R					L
ASCD operation signal	T	R						M
ASCD CRUISE lamp signal	T		R					N
ASCD OD cancel request signal	T	R						O
Output shaft revolution signal	R	T						P
Turbine revolution signal	R	T						Q
Front wiper request signal				T			R	R
Front wiper stop position signal				R			T	S
Rear window defogger switch signal				T			R	T
Rear window defogger control signal	R						T	U
Manual mode signal		R	T					V
Not manual mode signal		R	T					W
Manual mode shift up signal		R	T					X
Manual mode shift down signal		R	T					Y
Manual mode indicator signal		T	R					Z
Theft warning horn request signal				T			R	AA
Horn chirp signal				T			R	AB
Ignition switch signal				T			R	AC
Steering angle sensor signal					T	R		AD
ABS warning lamp signal			R			T		AE
TCS OFF indicator lamp signal			R			T		AF
SLIP indicator lamp signal			R			T		AG
Brake warning lamp signal			R			T		AH

LAN

CAN SYSTEM (TYPE 1)

PFP:23710


System Description

AKS00A8P

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

AKS00A8Q



CAN SYSTEM (TYPE 1)


[CAN]

Wiring Diagram — CAN —


AKS00ABR

LAN-CAN-01


▬ : DATA LINE




A
B
C
D
E
F
G
H
I
J
LAN
L
M




(M8)
W



(M48)
GY



(F6)
GY



(F502)
GY

*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

REFER TO THE FOLLOWING.


(F102) -SUPER MULTIPLE JUNCTION (SMJ)

(M90), (F101) -ELECTRICAL UNITS

TKWT2517E

LAN-CAN-02

▬ : DATA LINE



52	51	50	49	48	47	46	45
60	59	58	57	56	55	54	53

E9
W



REFER TO THE FOLLOWING.

E108 -SUPER MULTIPLE JUNCTION (SMJ)

E51 -ELECTRICAL UNITS

TKWT1554E

CAN SYSTEM (TYPE 1)

[CAN]

AKS00A8S

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								IPDM E/R
				ECM	TCM	METER /M&A	BCM /SEC	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

PKIB2210E

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 1)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
METER A/C AMP
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
METER A/C AMP
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIA8199E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between TCM and data link connector. Refer to [LAN-45, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	BCM /SEC	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	✓	✓	✓	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	✓	—	✓	—	CAN COMM CIRCUIT (U1000) ✓	—
METER A/C AMP	No indication	—	UNKWN	✓	✓	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	✓	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	✓	✓	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	✓	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB2211E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 1)


[CAN]

Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to [LAN-45. "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	BCM /SEC	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U000)	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U000)	—

PKIB2212E



SKIB1551E

CAN SYSTEM (TYPE 1)


[CAN]

Case 3

Check ECM circuit. Refer to [LAN-46, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	BCM /SEC	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U000)	CAN COMM CIRCUIT (U001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U000)	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U000)	—

PKIB2213E



SKIB1552E

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 1)


[CAN]

Case 4

Check TCM circuit. Refer to [LAN-47, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	BCM /SEC	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UN KN WN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U000)	CAN COMM CIRCUIT (U001)
A/T	—	NG	UNKWN	UN KN WN	—	UN KN WN	—	UN KN WN	—	CAN COMM CIRCUIT (U000)	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UN KN WN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UN KN WN	—	—	—	—	CAN COMM CIRCUIT (U000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB2214E



SKIB1553E

CAN SYSTEM (TYPE 1)


[CAN]

Case 5

Check data link connector circuit. Refer to [LAN-47, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	BCM /SEC	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB2215E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 1)

[CAN]


Case 6

Check unified meter and A/C amp. circuit. Refer to [LAN-48, "Unified Meter and A/C Amp. Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	BCM /SEC	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001) ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	UNKWN	—	CAN COMM CIRCUIT (U000) ✓	—
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB2216E

//// : Malfunctioning part



SKIB1555E

CAN SYSTEM (TYPE 1)


[CAN]

Case 7

Check BCM circuit. Refer to [LAN-48. "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	BCM /SEC	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN ✓	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN ✓	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB2217E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 1)


[CAN]

Case 8

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-49, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	BCM /SEC	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U000)	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB2218E



SKIB1557E

CAN SYSTEM (TYPE 1)


[CAN]

Case 9

Check IPDM E/R circuit. Refer to [LAN-49, "IPDM E/R Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	BCM /SEC	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB2219E



Case 10

Check CAN communication circuit. Refer to [LAN-50, "CAN Communication Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	BCM /SEC	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB2220E

CAN SYSTEM (TYPE 1)

[CAN]

Case 11

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-53, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	BCM /SEC	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	✓	UNKWN	UNKWN	✓	UNKWN	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	✓	—	UNKWN	✓	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB2221E

Case 12

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-53, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	BCM /SEC	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB2222E

Inspection Between TCM and Data Link Connector Circuit

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F102
 - Harness connector M72

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F102.
2. Check continuity between A/T assembly harness connector F6 terminals 3 (L), 8 (P) and harness connector F102 terminals 26H (L), 27H (P).

3 (L) – 26H (L) : Continuity should exist.
8 (P) – 27H (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M72 terminals 26H (L), 27H (P) and data link connector M8 terminals 6 (L), 14 (P).

26H (L) – 6 (L) : Continuity should exist.
27H (P) – 14 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-5, "TROUBLE DIAGNOSES WORK FLOW"](#).
 NG >> Repair harness.



Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M15
 - Harness connector E108

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M15.
2. Check continuity between data link connector M8 terminals 6 (L), 14 (P) and harness connector M15 terminals 2G (L), 7G (P).

6 (L) – 2G (L) : Continuity should exist.
14 (P) – 7G (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E108 terminals 2G (L), 7G (P) and ABS actuator and electric unit (control unit) harness connector E51 terminals 20 (L), 23 (P).

2G (L) – 20 (L) : Continuity should exist.
7G (P) – 23 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-5, "TROUBLE DIAGNOSES WORK FLOW"](#).
 NG >> Repair harness.



ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ECM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector F101 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.



TCM Circuit Inspection**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F6 terminals 3 (L) and 8 (P).

3 (L) – 8 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace control valve with TCM.
 NG >> Repair harness between A/T assembly and harness connector F102.

**Data Link Connector Circuit Inspection****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M8 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-5, "TROUBLE DIAGNOSES WORK FLOW"](#) .
 NG >> Repair harness between data link connector and unified meter and A/C amp.



Unified Meter and A/C Amp. Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of unified meter and A/C amp. for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect unified meter and A/C amp. connector.
2. Check resistance between unified meter and A/C amp. harness connector M48 terminals 1 (L) and 11 (P).

1 (L) – 11 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. and data link connector.



BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M90 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-18, "Removal and Installation of BCM"](#).
 NG >> Repair harness between BCM and data link connector.



ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

AKS00A92

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E51 terminals 20 (L) and 23 (P).

20 (L) – 23 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



IPDM E/R Circuit Inspection

AKS00A93

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E9 terminals 48 (L) and 49 (P).

48 (L) – 49 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and harness connector E108.



CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, meter side, control unit side and harness side).
 - ECM
 - A/T assembly
 - Unified meter and A/C amp.
 - BCM
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - ECM connector
 - A/T assembly connector
 - Harness connector F102
2. Check continuity between ECM harness connector F101 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
 - Harness between ECM and A/T assembly
 - Harness between ECM and harness connector F102



3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between ECM harness connector F101 terminals 94 (L), 86 (P) and ground.

94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 4.
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
 - Harness between ECM and A/T assembly
 - Harness between ECM and harness connector F102



4. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect following connectors.
 - Unified meter and A/C amp. connector
 - BCM connector
 - Harness connector M15
2. Check continuity between data link connector M8 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

- NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between data link connector and harness connector M72
 - Harness between data link connector and unified meter and A/C amp.
 - Harness between data link connector and BCM
 - Harness between data link connector and harness connector M15



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M8 terminals 6 (L), 14 (P) and ground.


6 (L) – Ground : Continuity should not exist.

14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

- NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between data link connector and harness connector M72
 - Harness between data link connector and unified meter and A/C amp.
 - Harness between data link connector and BCM
 - Harness between data link connector and harness connector M15



6. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E9 terminals 48 (L) and 49 (P).

48 (L) – 49 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

- NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
 - Harness between IPDM E/R and harness connector E108



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E9 terminals 48 (L), 49 (P) and ground.

48 (L) – Ground : Continuity should not exist.


49 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E108



8. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.

94 – 86 : Approx. 108 – 132 Ω


3. Check resistance between IPDM E/R terminals 48 and 49.

48 – 49 : Approx. 108 – 132 Ω

OK or NG

OK >> GO TO 9.

NG >> Replace ECM and/or IPDM E/R.



9. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all the connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 10.

NG >> Refer to [LAN-13, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

10. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
 - A/T assembly
 - Unified meter and A/C amp.
 - BCM
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Check results

Reproduced>>Install removed unit, and then check the other unit.

Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

AKS00C6R

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-11, "IGNITION POWER SUPPLY — IGNITION SW. IN "ON" AND/OR "START" "](#) .

CAN SYSTEM (TYPE 2)

PFP:23710


System Description

AKS009DC

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

AKS009DD



CAN SYSTEM (TYPE 2)


[CAN]

Wiring Diagram — CAN —



AKS009DE

LAN-CAN-03

▬▬▬▬ : DATA LINE



A
B
C
D
E
F
G
H
I
J
LAN
L
M




REFER TO THE FOLLOWING.

- (F102) -SUPER MULTIPLE JUNCTION (SMJ)
- (M90), (F101) -ELECTRICAL UNITS

TKWT2518E

LAN-CAN-04

▬ : DATA LINE



52	51	50	49	48	47	46	45
60	59	58	57	56	55	54	53

E9
W



REFER TO THE FOLLOWING.

(E108) -SUPER MULTIPLE JUNCTION (SMJ)

(E51) -ELECTRICAL UNITS

TKWT1555E

CAN SYSTEM (TYPE 2)

[CAN]

AKS00A9N

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

A
B
C
D
E
F
G
H
I
J
LAN
L
M

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM /SEC	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

PKIB2223E

CAN SYSTEM (TYPE 2)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
METER A/C AMP
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
METER A/C AMP
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIA8229E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to [LAN-66](#), "Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit".

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM /SEC	VDC/TCS /ABS	IPDM E/R		
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
METER A/C AMP	No indication	-	UNKWN	UNKWN	-	UNKWN	UNKWN	-	CAN COMM CIRCUIT (U1000)	-
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	CAN COMM CIRCUIT (U1000)	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	CAN COMM CIRCUIT (U1000)	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	UNKWN	-	-	CAN COMM CIRCUIT (U1000)	-

PKIB2224E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 2)


[CAN]

Case 2

Check ECM circuit. Refer to [LAN-67, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM /SEC	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001) ✓
METER A/C AMP	No indication	—	UNKWN	UNKWN ✓	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN ✓	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	UNKWN	—	—	CAN COMM CIRCUIT (U000) ✓	—

PKIB2225E



SKIB1562E

CAN SYSTEM (TYPE 2)


[CAN]

Case 3

Check data link connector circuit. Refer to [LAN-68, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM /SEC	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWVN	—	UNKWVN	UNKWVN	—	UNKWVN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
METER A/C AMP	No indication ✓	—	UNKWVN	UNKWVN	—	UNKWVN	UNKWVN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWVN	UNKWVN	UNKWVN	—	—	UNKWVN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWVN	UNKWVN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWVN	UNKWVN	—	UNKWVN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB2226E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 2)


[CAN]

Case 4

Check unified meter and A/C amp. circuit. Refer to [LAN-68, "Unified Meter and A/C Amp. Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM /SEC	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U000)	—
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB2227E



CAN SYSTEM (TYPE 2)


[CAN]

Case 5

Check BCM circuit. Refer to [LAN-69, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM /SEC	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U000)	—
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U000)	—

PKIB2228E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 2)


[CAN]

Case 6

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-69, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM /SEC	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U000)	—
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB2229E



SKIB1566E

CAN SYSTEM (TYPE 2)


[CAN]

Case 7

Check IPDM E/R circuit. Refer to [LAN-70, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM /SEC	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB2230E



Case 8

Check CAN communication circuit. Refer to [LAN-71, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM /SEC	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication ✓	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN ✓	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB2231E

Case 9

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-74, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM /SEC	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB2232E

Case 10

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-74, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM /SEC	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB2233E

Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

AKS00A9Q

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M15
 - Harness connector E108

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M15.
2. Check continuity between data link connector M8 terminals 6 (L), 14 (P) and harness connector M15 terminals 2G (L), 7G (P).

6 (L) – 2G (L) : Continuity should exist.
14 (P) – 7G (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E108 terminals 2G (L), 7G (P) and ABS actuator and electric unit (control unit) harness connector E51 terminals 20 (L), 23 (P).

2G (L) – 20 (L) : Continuity should exist.
7G (P) – 23 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-5, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness.



ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, connector side and harness side).
 - ECM connector
 - Harness connector F102
 - Harness connector M72

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

A
B
C
D
E
F
G
H
I
J
L
M

LAN


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector F101 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and data link connector.



Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M8 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-5, "TROUBLE DIAGNOSES WORK FLOW"](#) .
 NG >> Repair harness between data link connector and unified meter and A/C amp.



Unified Meter and A/C Amp. Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of unified meter and A/C amp. for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect unified meter and A/C amp. connector.
2. Check resistance between unified meter and A/C amp. harness connector M48 terminals 1 (L) and 11 (P).

1 (L) – 11 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. and data link connector.



AKS00A9U

BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M90 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-18, "Removal and Installation of BCM"](#).
 NG >> Repair harness between BCM and data link connector.



AKS00A9V

ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E51 terminals 20 (L) and 23 (P).

20 (L) – 23 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
- NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



AKS00A9W

IPDM E/R Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E9 terminals 48 (L) and 49 (P).

48 (L) – 49 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
- NG >> Repair harness between IPDM E/R and harness connector E108.



CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, meter side, control unit side and harness side).
 - ECM
 - Unified meter and A/C amp.
 - BCM
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector F102.
2. Check continuity between ECM harness connector F101 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector F102.



3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between ECM harness connector F101 terminals 94 (L), 86 (P) and ground.

94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness between ECM and harness connector F102.



4. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect following connectors.
 - Unified meter and A/C amp. connector
 - BCM connector
 - Harness connector M15
2. Check continuity between data link connector M8 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

- NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between data link connector and harness connector M72
 - Harness between data link connector and unified meter and A/C amp.
 - Harness between data link connector and BCM
 - Harness between data link connector and harness connector M15



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M8 terminals 6 (L), 14 (P) and ground.


6 (L) – Ground : Continuity should not exist.

14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

- NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between data link connector and harness connector M72
 - Harness between data link connector and unified meter and A/C amp.
 - Harness between data link connector and BCM
 - Harness between data link connector and harness connector M15



6. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E9 terminals 48 (L) and 49 (P).

48 (L) – 49 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

- NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
 - Harness between IPDM E/R and harness connector E108



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E9 terminals 48 (L), 49 (P) and ground.

48 (L) – Ground : Continuity should not exist.


49 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E108



8. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.

94 – 86 : Approx. 108 – 132 Ω


3. Check resistance between IPDM E/R terminals 48 and 49.

48 – 49 : Approx. 108 – 132 Ω

OK or NG

OK >> GO TO 9.

NG >> Replace ECM and/or IPDM E/R.



9. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all the connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 10.

NG >> Refer to [LAN-13, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

A
B
C
D
E
F
G
H
I
J
L
M

LAN

10. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
 - Unified meter and A/C amp.
 - BCM
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Check results

Reproduced>>Install removed unit, and then check the other unit.

Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

AKS00C6S

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-11, "IGNITION POWER SUPPLY — IGNITION SW. IN "ON" AND/OR "START""](#) .

CAN SYSTEM (TYPE 3)

PFP:23710


System Description

AKS00A97

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

AKS00A98



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 3)



[CAN]

AKS00A99


Wiring Diagram — CAN —

LAN-CAN-05

▬ : DATA LINE



(M8)
W



(M48)
GY



REFER TO THE FOLLOWING.

(F102) -SUPER MULTIPLE JUNCTION (SMJ)

(M90), (F101) -ELECTRICAL UNITS


TKWT3324E

CAN SYSTEM (TYPE 3)

[CAN]

LAN-CAN-06

▬ : DATA LINE



PRECEDING PAGE

A
B
C
D
E
F
G
H
I
J
K
L
M

LAN

52	51	50	49	48	47	46	45
60	59	58	57	56	55	54	53



REFER TO THE FOLLOWING.

(E108) -SUPER MULTIPLE JUNCTION (SMJ)

(E51) -ELECTRICAL UNITS

TKWT3325E

CAN SYSTEM (TYPE 3)

[CAN]

AKS00A9A

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							IPDM E/R
				ECM	METER /M&A	BCM /SEC	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

PKIB2234E

CAN SYSTEM (TYPE 3)

[CAN]

A
B
C
D
E
F
G
H
I
J
LAN
L
M

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
METER A/C AMP
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
METER A/C AMP
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIA8215E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to [LAN-87, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM /SEC	VDC/TCS /ABS	IPDM E/R		
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	UN KN WN ✓	UN KN WN ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
METER A/C AMP	No indication	-	UNKWN	UNKWN	-	UNKWN	UN KN WN ✓	-	CAN COMM CIRCUIT (U1000) ✓	-
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	UN KN WN ✓	CAN COMM CIRCUIT (U1000)	-
ABS	-	NG	UNKWN	UN KN WN ✓	-	-	-	-	CAN COMM CIRCUIT (U1000) ✓	-
IPDM E/R	No indication ✓	-	UNKWN	UNKWN	-	UNKWN	-	-	CAN COMM CIRCUIT (U1000) ✓	-

PKIB2235E



SKIB1561E

CAN SYSTEM (TYPE 3)


[CAN]

Case 2

Check ECM circuit. Refer to [LAN-88, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM /SEC	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U000) ✓	CAN COMM CIRCUIT (U001) ✓
METER A/C AMP	No indication	—	UNKWN	UNKWN ✓	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	UNKWN	—	—	CAN COMM CIRCUIT (U000) ✓	—

PKIB2236E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 3)


[CAN]

Case 3

Check data link connector circuit. Refer to [LAN-89, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM /SEC	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB2237E



CAN SYSTEM (TYPE 3)


[CAN]

Case 4

Check unified meter and A/C amp. circuit. Refer to [LAN-89, "Unified Meter and A/C Amp. Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM /SEC	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UN ✓ WN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U ✓ 001)
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U ✓ 000)	—
BCM	No indication	NG	UNKWN	UNKWN	UN ✓ WN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB2238E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 3)


[CAN]

Case 5

Check BCM circuit. Refer to [LAN-90, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM /SEC	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U000)	—
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U000)	—

PKIB2239E



SKIB1565E

CAN SYSTEM (TYPE 3)


[CAN]

Case 6

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-90, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM /SEC	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U000)	—
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB2240E



SKIB1566E

LAN

CAN SYSTEM (TYPE 3)


[CAN]

Case 7

Check IPDM E/R circuit. Refer to [LAN-91, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS			
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	METER /M&A	BCM /SEC	VDC/TCS /ABS	IPDM E/R				
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)	
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	—	—	—	✓	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	✓	CAN COMM CIRCUIT (U000)	—

PKIB2241E



Case 8

Check CAN communication circuit. Refer to [LAN-92, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	METER /M&A	BCM /SEC	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	✓	—	✓	✓	✓	✓	✓	✓	✓
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	✓	—
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	✓	—
ABS	—	NG	✓	UNKWN	—	—	—	—	—	✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	✓	—

PKIB2242E

Case 9

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-95, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM /SEC	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB2243E

Case 10

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-95, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	METER /M&A	BCM /SEC	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB2244E

Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

AKS00A9D

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M15
 - Harness connector E108

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M15.
2. Check continuity between data link connector M8 terminals 6 (L), 14 (P) and harness connector M15 terminals 2G (L), 7G (P).

6 (L) – 2G (L) : Continuity should exist.
14 (P) – 7G (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E108 terminals 2G (L), 7G (P) and ABS actuator and electric unit (control unit) harness connector E51 terminals 20 (L), 23 (P).

2G (L) – 20 (L) : Continuity should exist.
7G (P) – 23 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-5, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness.



AKS00A9E

ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, connector side and harness side).
 - ECM connector
 - Harness connector F102
 - Harness connector M72

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ECM connector.
2. Check resistance between ECM harness connector F101 terminals 94 (L) and 86 (P).

94 (L) – 86 (P)

: Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and data link connector.



Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


Check resistance between data link connector M8 terminals 6 (L) and 14 (P).

6 (L) – 14 (P)

: Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-5, "TROUBLE DIAGNOSES WORK FLOW"](#) .
 NG >> Repair harness between data link connector and unified meter and A/C amp.



Unified Meter and A/C Amp. Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of unified meter and A/C amp. for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect unified meter and A/C amp. connector.
2. Check resistance between unified meter and A/C amp. harness connector M48 terminals 1 (L) and 11 (P).

1 (L) – 11 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. and data link connector.



AKS00A9H

BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M90 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-18, "Removal and Installation of BCM"](#) .
 NG >> Repair harness between BCM and data link connector.



AKS00A9I

ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E51 terminals 20 (L) and 23 (P).

20 (L) – 23 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
- NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



AKS00A9J

IPDM E/R Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E9 terminals 48 (L) and 49 (P).

48 (L) – 49 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
- NG >> Repair harness between IPDM E/R and harness connector E108.



SKIA6873E

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, meter side, control unit side and harness side).
 - ECM
 - Unified meter and A/C amp.
 - BCM
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector F102.
2. Check continuity between ECM harness connector F101 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector F102.



3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between ECM harness connector F101 terminals 94 (L), 86 (P) and ground.

94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness between ECM and harness connector F102.



4. CHECK HARNESS FOR SHORT CIRCUIT


- Disconnect following connectors.
 - Unified meter and A/C amp. connector
 - BCM connector
 - Harness connector M15
- Check continuity between data link connector M8 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

- NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between data link connector and harness connector M72
 - Harness between data link connector and unified meter and A/C amp.
 - Harness between data link connector and BCM
 - Harness between data link connector and harness connector M15



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M8 terminals 6 (L), 14 (P) and ground.


6 (L) – Ground : Continuity should not exist.

14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

- NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between data link connector and harness connector M72
 - Harness between data link connector and unified meter and A/C amp.
 - Harness between data link connector and BCM
 - Harness between data link connector and harness connector M15



6. CHECK HARNESS FOR SHORT CIRCUIT


- Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
- Check continuity between IPDM E/R harness connector E9 terminals 48 (L) and 49 (P).

48 (L) – 49 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

- NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
 - Harness between IPDM E/R and harness connector E108



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E9 terminals 48 (L), 49 (P) and ground.

48 (L) – Ground : Continuity should not exist.


49 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E108



8. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.

94 – 86 : Approx. 108 – 132 Ω


3. Check resistance between IPDM E/R terminals 48 and 49.

48 – 49 : Approx. 108 – 132 Ω

OK or NG

OK >> GO TO 9.

NG >> Replace ECM and/or IPDM E/R.



9. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all the connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 10.

NG >> Refer to [LAN-13, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

10. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
 - Unified meter and A/C amp.
 - BCM
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Check results

Reproduced>>Install removed unit, and then check the other unit.
 Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

AKS00C6T

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-11, "IGNITION POWER SUPPLY — IGNITION SW. IN "ON" AND/OR "START""](#) .

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 4)


System Description

AKS009DT

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

AKS009DU



CAN SYSTEM (TYPE 4)


[CAN]

Wiring Diagram — CAN —


AKS009DV

LAN-CAN-07


▬ : DATA LINE




A
B
C
D
E
F
G
H
I
J
LAN
L
M



(M8)
W



(M22)
W



(M48)
GY



REFER TO THE FOLLOWING.


(F102) -SUPER MULTIPLE JUNCTION (SMJ)

(M90), (F101) -ELECTRICAL UNITS

TKWT3326E

LAN-CAN-08

▬ : DATA LINE



52	51	50	49	48	47	46	45
60	59	58	57	56	55	54	53



REFER TO THE FOLLOWING.

(E108) -SUPER MULTIPLE JUNCTION (SMJ)

(E118) -ELECTRICAL UNITS

TKWT3327E

CAN SYSTEM (TYPE 4)

[CAN]

AKS00AA0

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

A
B
C
D
E
F
G
H
I
J
LAN
L
M

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								IPDM E/R
				ECM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

PKIB2245E

CAN SYSTEM (TYPE 4)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
METER A/C AMP
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
METER A/C AMP
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIA8215E

CAN SYSTEM (TYPE 4)

[CAN]

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between data link connector and VDC/TCS/ABS control unit. Refer to [LAN-109, "Inspection Between Data Link Connector and VDC/TCS/ABS Control Unit Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U000)	—
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U000)	—

PKIB2246E



SKIB1570E

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 4)


[CAN]

Case 2

Check ECM circuit. Refer to [LAN-110, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U000) ✓	CAN COMM CIRCUIT (U001) ✓
METER A/C AMP	No indication	—	UNKWN	UNKWN ✓	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN ✓	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U000) ✓	—

PKIB2247E



SKIB1571E

CAN SYSTEM (TYPE 4)


[CAN]

Case 3

Check data link connector circuit. Refer to [LAN-111, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB2248E



SKIB1572E

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 4)


[CAN]

Case 4

Check unified meter and A/C amp. circuit. Refer to [LAN-111, "Unified Meter and A/C Amp. Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB2249E



CAN SYSTEM (TYPE 4)


[CAN]

Case 5

Check BCM circuit. Refer to [LAN-112. "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB2250E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 4)

[CAN]


Case 6

Check steering angle sensor circuit. Refer to [LAN-112, "Steering Angle Sensor Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB2252E

////// : Malfunctioning part



SKIB1575E

CAN SYSTEM (TYPE 4)


[CAN]

Case 7

Check VDC/TCS/ABS control unit circuit. Refer to [LAN-113, "VDC/TCS/ABS Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKW	—	UNKW	UNKW	—	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)
METER A/C AMP	No indication	—	UNKW	UNKW	—	UNKW	—	UNKW	—	CAN COMM CIRCUIT (U000)	—
BCM	No indication	NG	UNKW	UNKW	UNKW	—	—	—	UNKW	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW	UNKW	UNKW	—	UNKW	—	—	CAN COMM CIRCUIT (U000)	—
IPDM E/R	No indication	—	UNKW	UNKW	—	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB2253E



SKIB1576E

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 4)


[CAN]

Case 8

Check IPDM E/R circuit. Refer to [LAN-113, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U000)	—

PKIB2254E



Case 9

Check CAN communication circuit. Refer to [LAN-114, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U000)	CAN COMM CIRCUIT (U001)
METER A/C AMP	No indication	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U000)	—
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U000)	—

PKIB2255E

Case 10

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-117, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKW	—	UNKW	UNKW	—	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
METER A/C AMP	No indication	—	UNKW	UNKW	—	UNKW	—	UNKW	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKW	UNKW	UNKW	—	—	—	UNKW	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW	UNKW	UNKW	—	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW	UNKW	—	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB2256E

Case 11

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-117, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKW	—	UNKW	UNKW	—	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
METER A/C AMP	No indication	—	UNKW	UNKW	—	UNKW	—	UNKW	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKW	UNKW	UNKW	—	—	—	UNKW	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW	UNKW	—	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB2257E

Inspection Between Data Link Connector and VDC/TCS/ABS Control Unit Circuit

AKS00AA3

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M15
 - Harness connector E108

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M15.
2. Check continuity between data link connector M8 terminals 6 (L), 14 (P) and harness connector M15 terminals 2G (L), 7G (P).

6 (L) – 2G (L) : Continuity should exist.
14 (P) – 7G (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect VDC/TCS/ABS control unit connector.
2. Check continuity between harness connector E108 terminals 2G (L), 7G (P) and VDC/TCS/ABS control unit harness connector E118 terminals 61 (L), 63 (P).

2G (L) – 61 (L) : Continuity should exist.
7G (P) – 63 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-5, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness.



ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, connector side and harness side).
 - ECM connector
 - Harness connector F102
 - Harness connector M72

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

AKS00AA4

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ECM connector.
2. Check resistance between ECM harness connector F101 terminals 94 (L) and 86 (P).

94 (L) – 86 (P)

: Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and data link connector.



Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


Check resistance between data link connector M8 terminals 6 (L) and 14 (P).

6 (L) – 14 (P)

: Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-5, "TROUBLE DIAGNOSES WORK FLOW"](#) .
 NG >> Repair harness between data link connector and unified meter and A/C amp.



Unified Meter and A/C Amp. Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of unified meter and A/C amp. for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect unified meter and A/C amp. connector.
2. Check resistance between unified meter and A/C amp. harness connector M48 terminals 1 (L) and 11 (P).

1 (L) – 11 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. and data link connector.



AKS00AA7

BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M90 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-18, "Removal and Installation of BCM"](#) .
 NG >> Repair harness between BCM and data link connector.



AKS00AA8

Steering Angle Sensor Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M22 terminals 4 (L) and 5 (P).

4 (L) – 5 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



AKS00AA9

VDC/TCS/ABS Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of VDC/TCS/ABS control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect VDC/TCS/ABS control unit connector.
2. Check resistance between VDC/TCS/ABS control unit harness connector E118 terminals 61 (L) and 63 (P).

61 (L) – 63 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace VDC/TCS/ABS control unit.
 NG >> Repair harness between VDC/TCS/ABS control unit and IPDM E/R.



AKS00AAA

IPDM E/R Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E9 terminals 48 (L) and 49 (P).

48 (L) – 49 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
- NG >> Repair harness between IPDM E/R and harness connector E108.



AKS00AAB

CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, meter side, sensor side, control unit side and harness side).
 - ECM
 - Unified meter and A/C amp.
 - BCM
 - Steering angle sensor
 - VDC/TCS/ABS control unit
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector F102.
2. Check continuity between ECM harness connector F101 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness between ECM and harness connector F102.



3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector F101 terminals 94 (L), 86 (P) and ground.


94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector F102.



4. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - Unified meter and A/C amp. connector
 - BCM connector
 - Steering angle sensor connector
 - Harness connector M15
- Check continuity between data link connector M8 terminals 6 (L) and 14 (P).


6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M72
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and BCM
- Harness between data link connector and steering angle sensor
- Harness between data link connector and harness connector M15



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M8 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M72
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and BCM
- Harness between data link connector and steering angle sensor
- Harness between data link connector and harness connector M15



6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect VDC/TCS/ABS control unit connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E9 terminals 48 (L) and 49 (P).


48 (L) – 49 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and VDC/TCS/ABS control unit
- Harness between IPDM E/R and harness connector E108



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E9 terminals 48 (L), 49 (P) and ground.

48 (L) – Ground : Continuity should not exist.


49 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and VDC/TCS/ABS control unit
- Harness between IPDM E/R and harness connector E108



8. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.

94 – 86 : Approx. 108 – 132 Ω


3. Check resistance between IPDM E/R terminals 48 and 49.

48 – 49 : Approx. 108 – 132 Ω

OK or NG

OK >> GO TO 9.

NG >> Replace ECM and/or IPDM E/R.



9. CHECK SYMPTOM

1. Fill in described symptoms on the column “Symptom” in the check sheet.
2. Connect all the connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 10.

NG >> Refer to [LAN-13, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

10. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
 - Unified meter and A/C amp.
 - BCM
 - Steering angle sensor
 - VDC/TCS/ABS control unit
 - ECM
 - IPDM E/R

Check results

Reproduced>>Install removed unit, and then check the other unit.

Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

AKS00C6U

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-11, "IGNITION POWER SUPPLY — IGNITION SW. IN "ON" AND/OR "START" "](#) .

CAN SYSTEM (TYPE 5)

PFP:23710


System Description

AKS00DT5

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

AKS00DT6



CAN SYSTEM (TYPE 5)


[CAN]

AKS00DT7


Wiring Diagram — CAN —

LAN-CAN-09


▬ : DATA LINE




A
B
C
D
E
F
G
H
I
J
LAN
L
M




(M8)
W




(M22)
W



(M48)
GY



(F6)
GY



(F502)
GY

*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

REFER TO THE FOLLOWING.


(F102) -SUPER MULTIPLE JUNCTION (SMJ)

(M90), (F101) -ELECTRICAL UNITS

TKWT3239E

LAN-CAN-10

▬ : DATA LINE



52	51	50	49	48	47	46	45
60	59	58	57	56	55	54	53



REFER TO THE FOLLOWING.

(E108) -SUPER MULTIPLE JUNCTION (SMJ)

(E118) -ELECTRICAL UNITS

TKWT3240E

CAN SYSTEM (TYPE 5)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
METER A/C AMP
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
METER A/C AMP
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIA8199E

CAN SYSTEM (TYPE 5)

[CAN]

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between TCM and data link connector. Refer to [LAN-134, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	✓	✓	—	UNKWN	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—
METER A/C AMP	No indication	—	UNKWN	✓	✓	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	✓	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	✓	✓	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	✓	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB8663E



PKIB7467E

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 5)


[CAN]

Case 2

Check harness between data link connector and VDC/TCS/ABS control unit. Refer to [LAN-134, "Inspection Between Data Link Connector and VDC/TCS/ABS Control Unit Circuit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						VDC/TCS /ABS			IPDM E/R
				ECM	TCM	METER /M&A	BCM /SEC	STRG					
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB8664E



PKIB7468E

CAN SYSTEM (TYPE 5)


[CAN]

Case 3

Check ECM circuit. Refer to [LAN-135, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U100) ✓	CAN COMM CIRCUIT (U101) ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U100) ✓	—
METER A/C AMP	No indication	—	UNKWN	UNKWN ✓	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U100) ✓	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U100) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U100) ✓	—

PKIB8665E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 5)


[CAN]

Case 4

Check TCM circuit. Refer to [LAN-136, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U100)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U100)	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U100)	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U100)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB8666E



PKIB7470E

CAN SYSTEM (TYPE 5)


[CAN]

Case 5

Check data link connector circuit. Refer to [LAN-136, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB8667E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 5)


[CAN]

Case 6

Check unified meter and A/C amp. circuit. Refer to [LAN-137, "Unified Meter and A/C Amp. Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	✓	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	✓	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	✓	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	✓	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB8668E



PKIB7472E

CAN SYSTEM (TYPE 5)


[CAN]

Case 7

Check BCM circuit. Refer to [LAN-137, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN ✓	—	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN ✓	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB8669E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 5)


[CAN]

Case 8

Check steering angle sensor circuit. Refer to [LAN-138, "Steering Angle Sensor Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB8670E



PKIB7474E

CAN SYSTEM (TYPE 5)


[CAN]

Case 9

Check VDC/TCS/ABS control unit circuit. Refer to [LAN-138, "VDC/TCS/ABS Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						VDC/TCS /ABS			IPDM E/R
				ECM	TCM	METER /M&A	BCM /SEC	STRG					
ENGINE	—	NG	UNKW	—	UNKW	UNKW	UNKW	—	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKW	UNKW	—	UNKW	—	—	UNKW	—	CAN COMM CIRCUIT (U1000)	—	
METER A/C AMP	No indication	—	UNKW	UNKW	UNKW	—	UNKW	—	UNKW	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKW	UNKW	—	UNKW	—	—	—	UNKW	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKW	UNKW	UNKW	UNKW	—	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKW	UNKW	—	—	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB8671E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 5)


[CAN]

Case 10

Check IPDM E/R circuit. Refer to [LAN-139, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	—	UNKW N	UNKW N	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKW N	UNKW N	—	UNKW N	—	—	UNKW N	—	CAN COMM CIRCUIT (U1000)	—
METER A/C AMP	No indication	—	UNKW N	UNKW N	UNKW N	—	UNKW N	—	UNKW N	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	UNKW N	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW N	UNKW N	UNKW N	UNKW N	—	UNKW N	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW N	UNKW N	—	—	UNKW N	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB8672E



Case 11

Check CAN communication circuit. Refer to [LAN-139, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	—	UNKW N	UNKW N	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKW N	UNKW N	—	UNKW N	—	—	UNKW N	—	CAN COMM CIRCUIT (U1000)	—
METER A/C AMP	No indication	—	UNKW N	UNKW N	UNKW N	—	UNKW N	—	UNKW N	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	UNKW N	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW N	UNKW N	UNKW N	UNKW N	—	UNKW N	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW N	UNKW N	—	—	UNKW N	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB8673E

CAN SYSTEM (TYPE 5)

[CAN]

Case 12

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-142, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS			
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	—	UNKWN ✓	UNKWN	CAN COMM CIRCUIT (U100) ✓	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN ✓	—	UNKWN	—	UNKWN ✓	—	CAN COMM CIRCUIT (U100) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB8674E

Case 13

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-142, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	—	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U100) ✓	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB8675E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

Inspection Between TCM and Data Link Connector Circuit

AKS00D70

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F102
 - Harness connector M72

OK or NG

- OK >> GO TO 2.
NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F102.
2. Check continuity between A/T assembly harness connector F6 terminals 3 (L), 8 (P) and harness connector F102 terminals 26H (L), 27H (P).

- 3 (L) – 26H (L) : Continuity should exist.**
8 (P) – 27H (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M72 terminals 26H (L), 27H (P) and data link connector M8 terminals 6 (L), 14 (P).

- 26H (L) – 6 (L) : Continuity should exist.**
27H (P) – 14 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-5, "TROUBLE DIAGNOSES WORK FLOW"](#).
NG >> Repair harness.



Inspection Between Data Link Connector and VDC/TCS/ABS Control Unit Circuit

AKS00DTP

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M15
 - Harness connector E108

OK or NG

- OK >> GO TO 2.
NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M15.
2. Check continuity between data link connector M8 terminals 6 (L), 14 (P) and harness connector M15 terminals 2G (L), 7G (P).

6 (L) – 2G (L) : Continuity should exist.
14 (P) – 7G (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect VDC/TCS/ABS control unit connector.
2. Check continuity between harness connector E108 terminals 2G (L), 7G (P) and VDC/TCS/ABS control unit harness connector E118 terminals 61 (L), 63 (P).

2G (L) – 61 (L) : Continuity should exist.
7G (P) – 63 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-5, "TROUBLE DIAGNOSES WORK FLOW"](#).
 NG >> Repair harness.



ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ECM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector F101 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.



TCM Circuit Inspection**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F6 terminals 3 (L) and 8 (P).

3 (L) – 8 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace control valve with TCM.
 NG >> Repair harness between A/T assembly and harness connector F102.

**Data Link Connector Circuit Inspection****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M8 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-5, "TROUBLE DIAGNOSES WORK FLOW"](#) .
 NG >> Repair harness between data link connector and unified meter and A/C amp.



Unified Meter and A/C Amp. Circuit Inspection**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of unified meter and A/C amp. for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect unified meter and A/C amp. connector.
2. Check resistance between unified meter and A/C amp. harness connector M48 terminals 1 (L) and 11 (P).

1 (L) – 11 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. and data link connector.

**BCM Circuit Inspection****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M90 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-18, "Removal and Installation of BCM"](#).
 NG >> Repair harness between BCM and data link connector.



Steering Angle Sensor Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M22 terminals 4 (L) and 5 (P).

4 (L) – 5 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



AKS00DTV

VDC/TCS/ABS Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of VDC/TCS/ABS control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect VDC/TCS/ABS control unit connector.
2. Check resistance between VDC/TCS/ABS control unit harness connector E118 terminals 61 (L) and 63 (P).

61 (L) – 63 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace VDC/TCS/ABS control unit.
 NG >> Repair harness between VDC/TCS/ABS control unit and IPDM E/R.



IPDM E/R Circuit Inspection**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E9 terminals 48 (L) and 49 (P).

48 (L) – 49 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and harness connector E108.

**CAN Communication Circuit Inspection****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, meter side, sensor side, control unit side and harness side).
 - ECM
 - A/T assembly
 - Unified meter and A/C amp.
 - BCM
 - Steering angle sensor
 - VDC/TCS/ABS control unit
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - ECM connector
 - A/T assembly connector
 - Harness connector F102
- Check continuity between ECM harness connector F101 terminals 94 (L) and 86 (P).


94 (L) – 86 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ECM and A/T assembly
- Harness between ECM and harness connector F102



3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector F101 terminals 94 (L), 86 (P) and ground.

94 (L) – Ground : Continuity should not exist.


86 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ECM and A/T assembly
- Harness between ECM and harness connector F102



4. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - Unified meter and A/C amp. connector
 - BCM connector
 - Steering angle sensor connector
 - Harness connector M15
- Check continuity between data link connector M8 terminals 6 (L) and 14 (P).


6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M72
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and BCM
- Harness between data link connector and steering angle sensor
- Harness between data link connector and harness connector M15



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M8 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M72
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and BCM
- Harness between data link connector and steering angle sensor
- Harness between data link connector and harness connector M15



6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect VDC/TCS/ABS control unit connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E9 terminals 48 (L) and 49 (P).


48 (L) – 49 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and VDC/TCS/ABS control unit
- Harness between IPDM E/R and harness connector E108



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E9 terminals 48 (L), 49 (P) and ground.

48 (L) – Ground : Continuity should not exist.


49 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and VDC/TCS/ABS control unit
- Harness between IPDM E/R and harness connector E108



8. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT


1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.
3. Check resistance between IPDM E/R terminals 48 and 49.

94 – 86 : Approx. 108 – 132 Ω

48 – 49 : Approx. 108 – 132 Ω

OK or NG

- OK >> GO TO 9.
 NG >> Replace ECM and/or IPDM E/R.



9. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all the connectors, and then make sure that the symptom is reproduced.

OK or NG

- OK >> GO TO 10.
 NG >> Refer to [LAN-13, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

10. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
 - A/T assembly
 - Unified meter and A/C amp.
 - BCM
 - Steering angle sensor
 - VDC/TCS/ABS control unit
 - ECM
 - IPDM E/R

Check results

- Reproduced>>Install removed unit, and then check the other unit.
 Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

AKS00DTZ

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-11, "IGNITION POWER SUPPLY — IGNITION SW. IN "ON" AND/OR "START" .](#)