

# SECTION **BCS**

## BODY CONTROL SYSTEM

### CONTENTS

<b>PRECAUTIONS</b> .....	<b>2</b>	TEM .....	<b>9</b>
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	2	CAN Communication System Description .....	10
Precautions for Battery Service .....	2	CAN Communication Unit .....	10
<b>BCM (BODY CONTROL MODULE)</b> .....	<b>3</b>	Schematic .....	11
System Description .....	3	COUPE MODELS .....	11
BCM FUNCTION .....	3	ROADSTER MODELS .....	13
COMBINATION SWITCH READING FUNCTION .....	3	ROADSTER MODELS .....	15
CAN COMMUNICATION CONTROL .....	6	CONSULT-II Function (BCM) .....	17
BCM STATUS CONTROL .....	7	CONSULT-II BASIC OPERATION .....	17
SYSTEMS CONTROLLED BY BCM DIRECTLY .....	8	ITEMS OF EACH PART .....	17
SYSTEMS CONTROLLED BY BCM AND IPDM E/R .....	8	WORK SUPPORT .....	18
SYSTEMS CONTROLLED BY BCM AND COMBINATION METER .....	8	CAN Communication Inspection Using CONSULT-II (Self-Diagnosis) .....	18
MAJOR COMPONENTS AND CONTROL SYSTEM		Removal and Installation of BCM .....	19
		REMOVAL .....	19
		INSTALLATION .....	19

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

**BCS**

# PRECAUTIONS

## PRECAUTIONS

PFP:00001

### Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

NKS0009L

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### Precautions for Battery Service

NKS0009M

Before disconnecting the battery, lower both the driver and passenger windows. This will prevent any interference between the window edge and the vehicle when the door is opened/closed. During normal operation, the window slightly raises and lowers automatically to prevent any window to vehicle interference. The automatic window function will not work with the battery disconnected.

# BCM (BODY CONTROL MODULE)

## BCM (BODY CONTROL MODULE)

PFP:284B2

### System Description

NKS0009N

BCM (Body Control Module) controls the operation of various electrical units installed in the vehicle.

### BCM FUNCTION

BCM has combination switch reading function for reading the operation of combination switches (light, wiper, washer and turn signal) in addition to a function for controlling the operation of various electrical components. Also it has an interface function allowing it to receive signals from the unified meter and A/C amp., and send signals to ECM using CAN communication.


### COMBINATION SWITCH READING FUNCTION

#### Description

- BCM reads combination switch (lighting switch, wiper switch) status, and controls various electrical component, according to the results.
- BCM reads information of a maximum of 20 switches by combining five output terminals (OUTPUT 1 - 5) and five input terminals (INPUT 1 - 5).

#### Operation Description

- BCM activates transistors of output terminals (OUTPUT 1 - 5) periodically and, allows current to flow in turn.
- If any (1 or more) switches are turned ON, circuit of output terminals (OUTPUT 1 - 5) and input terminals (INPUT 1 - 5) becomes active.
- At this time, transistors of output terminals (OUTPUT 1 - 5) are activated to allow current to flow. When voltage of input terminals (INPUT 1 - 5) corresponding to that switch changes, interface in BCM detects voltage change, and BCM determines that switch is ON.



※1 : LIGHTING SWITCH 1ST POSITION

PKIC4861E

# BCM (BODY CONTROL MODULE)

## Operation Table of BCM and Combination Switches

BCM reads operation status of combination switch using combinations shown in table below.

	COMB SW OUTPUT 1		COMB SW OUTPUT 2		COMB SW OUTPUT 3		COMB SW OUTPUT 4		COMB SW OUTPUT 5	
	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
COMB SW INPUT 1	—	—	FR WIPER HI ON	FR WIPER HI OFF	INT VOLUME 1 ON	INT VOLUME 1 OFF	RR WIPER INT ON	RR WIPER INT OFF	INT VOLUME 2 ON	INT VOLUME 2 OFF
COMB SW INPUT 2	FR WASHER ON	FR WASHER OFF	—	—	RR WASHER ON	RR WASHER OFF	INT VOLUME 3 ON	INT VOLUME 3 OFF	RR WIPER ON	RR WIPER OFF
COMB SW INPUT 3	FR WIPER LOW ON	FR WIPER LOW OFF	FR WIPER INT ON	FR WIPER INT OFF	—	—	—	—	—	—
COMB SW INPUT 4	TURN LH ON	TURN LH OFF	PASSING ON	PASSING OFF	HEAD-LAMP 2 ON	HEAD-LAMP 2 OFF	—	—	—	—
COMB SW INPUT 5	TURN RH ON	TURN RH OFF	HEAD-LAMP 1 ON	HEAD-LAMP 1 OFF	HI BEAM ON	HI BEAM OFF	LIGHTING SW (1st) ON	LIGHTING SW (1st) OFF	—	—

PKIC4963E

**NOTE:**

Headlamp system has a dual circuit.




# BCM (BODY CONTROL MODULE)

## Operation Mode

The combination switch reading function has the operation modes shown below.

1. Normal mode
  - When BCM is not in sleep mode, OUTPUT terminals (1 - 5) each turn ON-OFF every 10 ms.
2. Sleep mode
  - When BCM is in sleep mode BCM enters low power mode. OUTPUT (1 - 5) turn ON-OFF every 60 ms, and only input from light switch system is accepted.



## CAN COMMUNICATION CONTROL

CAN communication allows a high rate of information transmission through the two communication lines (CAN L line, CAN H line) connecting the various control units in the system. Each control unit transmits/receives data but selectively reads required data only. For details of signals that are transmitted/received by BCM via CAN communication, refer to [LAN-48, "CAN System Specification Chart"](#).

# BCM (BODY CONTROL MODULE)

## BCM STATUS CONTROL

BCM changes its status depending on the operation status in order to save power consumption.

1. CAN communication status
  - With ignition switch ON, CAN communicates with other control units normally.
  - Control by BCM is being operated properly.
  - When ignition switch is OFF, switching to sleep mode is possible.
  - Even when ignition switch is OFF, if CAN communication with IPDM E/R and combination meter is active, CAN communication status is active.
2. Sleep transient status
  - This status shuts down CAN communication when ignition switch is turned OFF.
  - It transmits sleep request signal to IPDM E/R and combination meter.
  - Two seconds after CAN communication of all control units stops, sleep transient status switches to CAN communication inactive status.
3. CAN communication inactive status
  - With ignition switch OFF, CAN communication is not active.
  - With ignition switch OFF, control performed only by BCM is active.
  - Three seconds after CAN communication of all control units stops, CAN communication inactive status switches to sleep status.
4. Sleep status
  - BCM is activated with low power mode.
  - CAN communication is not active.
  - When CAN communication operation is detected, it switches to CAN communication status.
  - When a state of the following switches changes, it switches to CAN communication state.
    - Key switch (ACC, ON)
    - Hazard switch
    - Door lock/unlock switch
    - Front door switch (driver side, passenger side)
    - Back door opener switch (coupe models)
    - Trunk lid opener switch (roadster models)
    - Combination switch (passing, lighting switch 1st position)
    - Key fob (lock/unlock signal)
    - Key cylinder switch
  - When control performed only by BCM is required by switch, it shifts to CAN communication inactive mode.
  - Status of combination switch reading function is changed.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

BCS

# BCM (BODY CONTROL MODULE)

## SYSTEMS CONTROLLED BY BCM DIRECTLY

System	Reference
Power door lock system	<a href="#">BL-21, "POWER DOOR LOCK SYSTEM"</a>
Remote keyless entry system	<a href="#">BL-60, "REMOTE KEYLESS ENTRY SYSTEM"</a>
Power window system <sup>NOTE 1</sup>	<a href="#">GW-18, "POWER WINDOW SYSTEM"</a>
Power seat <sup>NOTE 1</sup>	<a href="#">SE-12, "POWER SEAT/FOR COUPE"</a> or <a href="#">SE-15, "POWER SEAT/FOR ROADSTER"</a>
Interior room lamp	<a href="#">LT-135, "INTERIOR ROOM LAMP"</a>
Rear wiper and washer system <sup>NOTE 2</sup>	<a href="#">WW-40, "REAR WIPER AND WASHER SYSTEM"</a>

**NOTE:**

1. Power supply only. No system control.
2. Coupe models

## SYSTEMS CONTROLLED BY BCM AND IPDM E/R

System	Reference
Panic alarm	<a href="#">BL-60, "REMOTE KEYLESS ENTRY SYSTEM"</a>
Theft warning	<a href="#">BL-129, "VEHICLE SECURITY (THEFT WARNING) SYSTEM"</a>
NVIS (NATS)	<a href="#">BL-158, "NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)"</a>
Headlamp (For USA)	<a href="#">LT-9, "HEADLAMP (FOR USA)"</a>
<ul style="list-style-type: none"> <li>● Headlamp (For Canada)</li> <li>● Daytime light system</li> </ul>	<a href="#">LT-37, "HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -"</a>
<ul style="list-style-type: none"> <li>● Parking, license plate and tail lamps</li> <li>● Battery saver control</li> </ul>	<a href="#">LT-110, "PARKING, LICENSE PLATE AND TAIL LAMPS"</a>
Front wiper and washer system	<a href="#">WW-6, "FRONT WIPER AND WASHER SYSTEM"</a>
Rear window defogger	<a href="#">GW-56, "REAR WINDOW DEFOGGER"</a>

## SYSTEMS CONTROLLED BY BCM AND COMBINATION METER

System	Reference
Warning chime	<a href="#">DI-92, "WARNING CHIME"</a>
Turn signal and hazard warning lamps	<a href="#">LT-71, "TURN SIGNAL AND HAZARD WARNING LAMPS"</a>
Low tire pressure warning system	<a href="#">WT-11, "LOW TIRE PRESSURE WARNING SYSTEM"</a>

# BCM (BODY CONTROL MODULE)

## MAJOR COMPONENTS AND CONTROL SYSTEM

System	Input	Output	A
Remote control entry system	<ul style="list-style-type: none"> <li>● Remote keyless entry receiver</li> <li>● Key switch</li> <li>● All-door switch</li> </ul>	<ul style="list-style-type: none"> <li>● All-door locking actuator</li> <li>● Turn signal lamp (LH, RH)</li> </ul>	B
Power door lock system	<ul style="list-style-type: none"> <li>● Power window main switch (door lock and unlock switch)</li> <li>● Power window sub switch (passenger side) (door lock and unlock switch)</li> </ul>	All-door locking actuator	C
Power supply (IGN) to power window	Ignition power supply	Power window system	D
Power supply (BAT) to power window and power seat	Battery power supply	Power window system and power seat	E
Panic alarm	<ul style="list-style-type: none"> <li>● Key switch</li> <li>● Remote keyless entry receiver</li> </ul>	IPDM E/R	F
Theft warning system	<ul style="list-style-type: none"> <li>● All-door switch</li> <li>● Remote keyless entry receiver</li> <li>● Power window main switch (door lock and unlock switch)</li> </ul>	<ul style="list-style-type: none"> <li>● IPDM E/R</li> <li>● Security indicator lamp</li> </ul>	G
Exterior lamp battery saver control	<ul style="list-style-type: none"> <li>● Ignition switch</li> <li>● Combination switch</li> </ul>	IPDM E/R	H
Headlamp	Combination switch	IPDM E/R	I
Daytime light system	<ul style="list-style-type: none"> <li>● Engine status signal</li> <li>● Ignition switch</li> <li>● Combination switch</li> <li>● Parking brake signal</li> </ul>	IPDM E/R	J
Tail lamp	Combination switch	IPDM E/R	J
Turn signal lamp	<ul style="list-style-type: none"> <li>● Combination switch</li> <li>● Ignition switch</li> </ul>	<ul style="list-style-type: none"> <li>● Turn signal lamp</li> <li>● Combination meter</li> </ul>	J
Hazard lamp	Hazard switch	<ul style="list-style-type: none"> <li>● Turn signal lamp</li> <li>● Combination meter</li> </ul>	<b>BCS</b>
Room lamp timer	<ul style="list-style-type: none"> <li>● Key switch</li> <li>● Remote keyless entry receiver</li> <li>● Power window main switch (door lock and unlock switch)</li> <li>● All-door switch</li> </ul>	<ul style="list-style-type: none"> <li>● Interior room lamp</li> <li>● Map lamp</li> <li>● Key hole illumination</li> </ul>	L
Interior lamp battery saver control	<ul style="list-style-type: none"> <li>● Ignition switch</li> <li>● Remote keyless entry receiver</li> <li>● All-door switch</li> </ul>	BCM	M
Key warning chime	<ul style="list-style-type: none"> <li>● Key switch</li> <li>● Front door switch driver side</li> </ul>	Combination meter (warning buzzer)	
Light warning chime	<ul style="list-style-type: none"> <li>● Combination switch</li> <li>● Ignition switch</li> <li>● Front door switch driver side</li> </ul>	Combination meter (warning buzzer)	
Seat belt warning chime	<ul style="list-style-type: none"> <li>● Combination meter [Seat belt buckle (driver side) switch]</li> <li>● Ignition switch</li> </ul>	Combination meter (warning buzzer)	
Front wiper and washer system	<ul style="list-style-type: none"> <li>● Combination switch</li> <li>● Combination meter</li> <li>● Ignition switch</li> </ul>	IPDM E/R	

## BCM (BODY CONTROL MODULE)

System	Input	Output
Rear wiper and washer system <sup>NOTE</sup>	<ul style="list-style-type: none"><li>● Combination switch</li><li>● Ignition switch</li></ul>	Rear wiper motor
Rear window defogger	<ul style="list-style-type: none"><li>● Rear window defogger switch</li><li>● Ignition switch</li></ul>	IPDM E/R
A/C switch signal	Unified meter and A/C amp.	ECM
Blower fan switch signal	Unified meter and A/C amp.	ECM
Low tire pressure warning system	Remote keyless entry receiver	Combination meter

**NOTE:**

Coupe models

### CAN Communication System Description

NKS00090

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicles are equipped with many electronic control units and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### CAN Communication Unit

NKS0009P


Refer to [LAN-48, "CAN System Specification Chart"](#) .

# BCM (BODY CONTROL MODULE)

NKS0009Q


## Schematic COUPE MODELS

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



TKWT4013E

# BCM (BODY CONTROL MODULE)




TKWT4014E

# BCM (BODY CONTROL MODULE)

## ROADSTER MODELS


For identification number JN1AZ36D400001–JN1AZ36D400527 or JN1AZ36A450001–JN1AZ36A455310.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



TKWT4015E

# BCM (BODY CONTROL MODULE)




TKWT4016E

# BCM (BODY CONTROL MODULE)

## ROADSTER MODELS


For identification number JN1AZ36D400528- or JN1AZ36A455311-.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



TKW75622E

# BCM (BODY CONTROL MODULE)



TKWT5623E

# BCM (BODY CONTROL MODULE)

## CONSULT-II Function (BCM)

NKS0009R

CONSULT-II can display each diagnostic item using the diagnostic test mode shown following.

BCM diagnostic test item	Check item, diagnostic test mode	Content
Inspection by part	WORK SUPPORT	Changes setting of each function.
	SELF-DIAG RESULTS	BCM performs self-diagnosis of CAN communication.
	DATA MONITOR	Displays the input data of BCM in real time.
	ACTIVE TEST	Gives a drive signal to a load to check the operation.
	CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
	ECU PART NUMBER	BCM part number can be read.

## CONSULT-II BASIC OPERATION

Refer to [GI-36, "CONSULT-II Start Procedure"](#) .

### ITEMS OF EACH PART

#### NOTE:

CONSULT-II displays systems equipped in the vehicle.

×: Applicable

System and item	CONSULT-II display	Diagnostic test mode (Inspection by part)						
		WORK SUPPORT	SELF-DIAG RESULTS	DATA MONITOR	CAN DIAG SUPPORT MNTR	ACTIVE TEST	ECU PART NUMBER	CONFIGURATION
BCM	BCM	×	×		×		×	× NOTE
Power door lock system	DOOR LOCK	×		×		×		
Rear window defogger	REAR DEFOGGER			×		×		
Warning chime	BUZZER			×		×		
Room lamp timer	INT LAMP	×		×		×		
Remotecontrol entry system	MULTI REMOTE ENT	×		×		×		
Headlamp	HEAD LAMP	×		×		×		
Wiper	WIPER	×		×		×		
Turn signal lamp Hazard lamp	FLASHER			×		×		
Blower fan switch signal A/C switch signal	AIR CONDITONER			×				
Combination switch	COMB SW			×				
NVIS	IMMU			×		×		
Interior lamp battery saver	BATTERY SAVER	×		×		×		
Trunk lid	TRUNK			×		×		
Vehicle security system	THEFT ALM	×		×		×		
Retained power control	RETAINED PWR	×		×		×		
Oil pressure switch	SIGNAL BUFFER			×	× NOTE	×		
Low tire pressure warning system	AIR PRESSURE MONITOR	×	×	×		×		
Panic alarm system	PANIC ALARM					×		

#### NOTE:

This item is displayed, but should not be used.

# BCM (BODY CONTROL MODULE)

## WORK SUPPORT

### Operation Procedure

1. Touch "BCM" on "SELECT TEST ITEM" screen.
2. Touch "WORK SUPPORT" on "SELECT DIAG MODE" screen.
3. Touch item on "SELECT WORK ITEM" screen.
4. Touch "START".
5. Touch "CHANGE SET".
6. The setting will be changed and "RESETTING COMPLETED" will be displayed.
7. Touch "END".

### Display Item List

Item	Description
RESET SETTING VALUE	Return a value set with WORK SUPPORT of each system to a default value in factory shipment.

## CAN Communication Inspection Using CONSULT-II (Self-Diagnosis)

NKS0009S

### 1. SELF-DIAGNOSIS RESULT CHECK

#### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

1. Connect to CONSULT-II, and select "BCM" on "SELECT SYSTEM" screen.
2. Select "BCM control unit" on "SELECT WORK ITEM" screen, and select "SELF-DIAG RESULTS".
3. Check display content in self-diagnostic results.

CONSULT-II display code	Diagnosis item
U1000	INITIAL DIAG
	TRANSMIT DIAG
	ECM
	IPDM E/R
	METER / M&A

#### Contents displayed

No malfunction>>INSPECTION END

Malfunction in CAN communication system>>After printing the monitor items, go to "CAN System". Refer to [LAN-48, "CAN System Specification Chart"](#) .


# BCM (BODY CONTROL MODULE)

NKS0009T


## Removal and Installation of BCM

### REMOVAL

1. Remove the dash side finisher (LH). Refer to [EI-35, "BODY SIDE TRIM"](#) .
2. Disconnect BCM connector.
3. Remove bracket mounting screws to remove BCM and fuse block with bracket.



4. Raise the pawl of fuse block and remove bracket from fuse block to remove BCM.



### INSTALLATION

Installation is the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
BCS  
L  
M

# BCM (BODY CONTROL MODULE)

---