

SECTION **EI**

EXTERIOR & INTERIOR

CONTENTS

SERVICE INFORMATION	2	Removal and Installation	20
PRECAUTIONS	2	SIDE SILL FINISHER	21
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	2	Removal and Installation	21
Precaution for Battery Service	2	WINDSHIELD MOLDING	24
Precaution for Procedure without Cowl Top Cover.....	2	Removal and Installation	24
Precaution for Work	2	REAR WINDOW MOLDING	26
PREPARATION	3	Removal and Installation	26
Special Service Tool	3	REAR SPOILER	27
Commercial Service Tool	3	Removal and Installation	27
SQUEAK AND RATTLE TROUBLE DIAGNOSIS	4	ROOF SIDE MOLDING	28
Work Flow	4	Removal and Installation (for Coupe Models)	28
Generic Squeak and Rattle Troubleshooting	6	Removal and Installation (for Roadster Models)	29
Diagnostic Worksheet	8	DOOR FINISHER	30
CLIP AND FASTENER	10	Removal and Installation	30
Clip and Fastener	10	BODY SIDE TRIM	32
FRONT BUMPER	13	Removal and Installation (for Coupe Models)	32
Removal and Installation	13	Removal and Installation (for Roadster Models)	33
Removal and Installation of Bumper Side Reflector (Left Side)	14	LUGGAGE FLOOR TRIM	36
Removal and Installation of Bumper Side Reflector (Right Side)	14	Removal and Installation (for Coupe Models)	36
Removal and Installation of Bumper Molding (Upper side, Lower)	14	Removal and Installation (for Roadster Models)	38
REAR BUMPER	15	FLOOR TRIM	40
Removal and Installation	15	Removal and Installation	40
COWL TOP	18	HEADLINING	41
Removal and Installation	18	Removal and Installation (for Coupe Models)	41
FENDER PROTECTOR	19	Removal and Installation (for Roadster Models)	42
Removal and Installation	19	BACK DOOR	44
DOOR OUTSIDE MOLDING	20	Removal and Installation (for Coupe Models)	44
		TRUNK ROOM TRIM & TRUNK LID FINISHER	46
		Removal and Installation (for Roadstar Models)	46

PRECAUTIONS

< SERVICE INFORMATION >

SERVICE INFORMATION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000005153319

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SUPPLEMENTAL RESTRAINT SYSTEM" and "SEAT BELTS" of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SUPPLEMENTAL RESTRAINT SYSTEM".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution for Battery Service


INFOID:000000001647084

Before disconnecting the battery, lower both the driver and passenger windows. This will prevent any interference between the window edge and the vehicle when the door is opened/closed. During normal operation, the window slightly raises and lowers automatically to prevent any window to vehicle interference. The automatic window function will not work with the battery disconnected.

Precaution for Procedure without Cowl Top Cover

INFOID:000000002988770

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.



Precaution for Work

INFOID:000000001647086

- After removing and installing the opening/closing parts, be sure to carry out fitting adjustments to check their operation.
- Check the lubrication level, damage, and wear of each part. If necessary, grease or replace it.

PREPARATION



< SERVICE INFORMATION >

PREPARATION

Special Service Tool



INFOID:000000001647087

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
(J-39570) Chassis ear  SIIA0993E	Locating the noise
(J-43980) NISSAN Squeak and Rattle Kit  SIIA0994E	Repairing the cause of noise

Commercial Service Tool

INFOID:000000001647088

Tool name	Description
Engine ear  SIIA0995E	Locating the noise
Remover tool  PIIB7923J	Remove clip, pawl, metal clip


SQUEAK AND RATTLE TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

SQUEAK AND RATTLE TROUBLE DIAGNOSIS

Work Flow

INFOID:000000001647089



CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any customer's comments; refer to [EI-8, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, be sure to diagnose and repair the noise that the customer is concerned about. This can be accomplished by test driving the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak – (Like tennis shoes on a clean floor)
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces = higher pitch noise/softer surfaces = lower pitch noises/edge to surface = chirping
- Creak – (Like walking on an old wooden floor)
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle – (Like shaking a baby rattle)
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock – (Like a knock on a door)
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick – (Like a clock second hand)
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump – (Heavy, muffled knock noise)
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz – (Like a bumble bee)
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending upon the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

DUPLICATE THE NOISE AND TEST DRIVE

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

SQUEAK AND RATTLE TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
 - 2) Tap or push/pull around the area where the noise appears to be coming from.
 - 3) Rev the engine.
 - 4) Use a floor jack to recreate vehicle "twist".
 - 5) At idle, apply engine load (electrical load, half-clutch on M/T models, drive position on A/T models).
 - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
 - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis Ear: J-39570, Engine Ear and mechanics stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - Removing the components in the area that you suspect the noise is coming from.
Do not use too much force when removing clips and fasteners, otherwise clips and fastener can be broken or lost during the repair, resulting in the creation of new noise.
 - Tapping or pushing/pulling the component that you suspect is causing the noise.
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - Feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
 - Placing a piece of paper between components that you suspect are causing the noise.
 - Looking for loose components and contact marks.
Refer to [EI-6, "Generic Squeak and Rattle Troubleshooting"](#).

REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - Separate components by repositioning or loosening and retightening the component, if possible.
 - Insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A Nissan Squeak and Rattle Kit (J-43980) is available through your authorized Nissan Parts Department.

CAUTION:

Do not use excessive force as many components are constructed of plastic and may be damaged.

NOTE:

Always check with the Parts Department for the latest parts information.

The following materials are contained in the Nissan Squeak and Rattle Kit (J-43980). Each item can be ordered separately as needed.

URETHANE PADS [1.5 mm (0.059 in) thick]

Insulates connectors, harness, etc.

76268-9E005: 100 × 135 mm (3.94 × 5.31 in)/76884-71L01: 60 × 85 mm (2.36 × 3.35 in)/76884-71L02: 15 × 25 mm (0.59 × 0.98 in)

INSULATOR (Foam blocks)

Insulates components from contact. Can be used to fill space behind a panel.

73982-9E000: 45 mm (1.77 in) thick, 50 × 50 mm (1.97 × 1.97 in)/73982-50Y00:

10 mm (0.39 in) thick, 50 × 50 mm (1.97 × 1.97 in)

INSULATOR (Light foam block)

80845-71L00: 30 mm (1.18 in) thick, 30 × 50 mm (1.18 × 1.97 in)

FELT CLOTH TAPE

Used to insulate where movement does not occur. Ideal for instrument panel applications.

68370-4B000: 15 × 25 mm (0.59 × 0.98 in) pad/68239-13E00: 5 mm (0.20 in) wide tape roll

The following materials, not found in the kit, can also be used to repair squeaks and rattles.

UHMW (TEFLON) TAPE

SQUEAK AND RATTLE TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

Insulates where slight movement is present. Ideal for instrument panel applications.

SILICONE GREASE

Used in place of UHMW tape that will be visible or not fit. Will only last a few months.

SILICONE SPRAY

Use when grease cannot be applied.

DUCT TAPE

Use to eliminate movement.

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

Generic Squeak and Rattle Troubleshooting

INFOID:000000001647090

Refer to Table of Contents for specific component removal and installation information.

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. The cluster lid A and instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar garnish
4. Instrument panel to windshield
5. Instrument panel mounting pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicon spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

CAUTION:

Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.

CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks from the Nissan Squeak and Rattle Kit (J-43980) to repair the noise.

TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner.

In addition look for:

1. Trunk lid dumpers out of adjustment
2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together
4. A loose license plate or bracket

SQUEAK AND RATTLE TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sun-visor shaft shaking in the holder
3. Front or rear windshield touching headlining and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted under-hood noise include:

1. Any component mounted to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator mounting pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

A
B
C
D
E
F
G
H
EI
J
K
L
M
N
O
P

SQUEAK AND RATTLE TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

Diagnostic Worksheet

INFOID:000000001647091







SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

Dear Nissan Customer:

We are concerned about your satisfaction with your Nissan vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your Nissan right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service advisor or technician to ensure we confirm the noise you are hearing.

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

PIIB8740E

SQUEAK AND RATTLE TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

II. WHEN DOES IT OCCUR? (please check the boxes that apply)

- | | |
|---|--|
| <input type="checkbox"/> anytime | <input type="checkbox"/> after sitting out in the rain |
| <input type="checkbox"/> 1st time in the morning | <input type="checkbox"/> when it is raining or wet |
| <input type="checkbox"/> only when it is cold outside | <input type="checkbox"/> dry or dusty conditions |
| <input type="checkbox"/> only when it is hot outside | <input type="checkbox"/> other: |

III. WHEN DRIVING:

- ☐ through driveways
- ☐ over rough roads
- ☐ over speed bumps
- ☐ only about ____ mph
- ☐ on acceleration
- ☐ coming to a stop
- ☐ on turns: left, right or either (circle)
- ☐ with passengers or cargo
- ☐ other: _____
- ☐ after driving ____ miles or ____ minutes

IV. WHAT TYPE OF NOISE

- ☐ squeak (like tennis shoes on a clean floor)
- ☐ creak (like walking on an old wooden floor)
- ☐ rattle (like shaking a baby rattle)
- ☐ knock (like a knock at the door)
- ☐ tick (like a clock second hand)
- ☐ thump (heavy, muffled knock noise)
- ☐ buzz (like a bumble bee)

TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

	YES	NO	Initials of person performing
Vehicle test driven with customer	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise verified on test drive	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise source located and repaired	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Follow up test drive performed to confirm repair	<input type="checkbox"/>	<input type="checkbox"/>	_____

VIN: _____ Customer Name: _____
W.O.# _____ Date: _____

This form must be attached to Work Order

PIIB8742E

















CLIP AND FASTENER

< SERVICE INFORMATION >

CLIP AND FASTENER

Clip and Fastener
















INFOID:000000001647092

Symbol No.	Shapes	Removal & Installation
C101 		Removal: Remove by bending up with flat-bladed screwdrivers or clip remover. 
C103 		 Removal: Remove with a clip remover.
C203 		Removal: Push center pin to catching position. (Do not remove center pin by hitting it.)  Installation: 
C205 		Removal: Flat-bladed screwdriver  Clip Finisher
C206 		Removal: 

SIIA0315E

CLIP AND FASTENER














< SERVICE INFORMATION >

Symbol No.	Shapes	Removal & Installation
CE103 		Removal: 
CF110 		Removal: 
CF118 		Removal: 
CR103 		Removal: Holder portion of clip must be spread out to remove rod. 
CS101 		Removal: 1. Screw out with a Phillips screwdriver. 2. Remove female portion with flat-bladed screwdriver. 

SIIA0316E

CLIP AND FASTENER

< SERVICE INFORMATION >

Symbol No.	Shapes	Removal & Installation	
CG101 		Removal:  Rotate 45° to remove	Installation: 
CS102 			
CS113 		Removal: Disconnect upper connection of clip with a flat-bladed screwdriver, then remove clip while inserting a flat-bladed screwdriver between body panel and clip. 	
C111 			

SIIA0317E

FRONT BUMPER

< SERVICE INFORMATION >

FRONT BUMPER


Removal and Installation

INFOID:000000001647093

CAUTION:

Bumper fascia is made of resin. Do not apply strong force to it, and be careful to prevent contact with oil.

SEC. 620



- | | | |
|-----------------------------------|---------------------------|-----------------------------------|
| 1. Bumper stay | 2. License plate bracket | 3. Bumper reinforcement |
| 4. Energy absorber | 5. Bumper fascia assembly | 6. Front emblem |
| 7. Bumper upper side molding (RH) | 8. Front bumper center | 9. Bumper upper side molding (LH) |

FRONT BUMPER

< SERVICE INFORMATION >

- | | | |
|--------------------------|---------------------------|-------------------------|
| 10. Bumper lower molding | 11. Bumper side reflector | 12. Bumper side bracket |
| 13. Grommet | 14. Air spoiler | 15. Retainer |



Pawl

REMOVAL

1. Remove clips of bumper fascia upper portion.
2. Remove screw of bumper fascia lower portion.
3. Remove screws of bumper fascia both side.
4. Remove screws and bolts of both right/left fender protectors on front side. Refer to [EI-19](#).
5. Pull out both right/left sides of bumper fascia and remove bumper fascia assembly.
CAUTION:
When removing bumper fascia, 2 workers are required so as to prevent it from dropping.
6. Remove energy absorber.
7. Remove bolts and nuts of bumper reinforcement and remove bumper fascia.
8. Remove clips of bumper shield-sight and remove bumper shield-sight.
9. Remove bolts of bumper stay and remove bumper stay.

INSTALLATION

Install in the reverse order of removal.

NOTE:

After installing, perform fitting adjustment.

	Portion	Clearance
Front bumper - Front fender	A - A	0 - 0.5 mm (0 - 0.020 in)
Front bumper - Head lamp	B - B	5.9 - 8.9 mm (0.232 - 0.350 in)
Hood - Head lamp	C - C	1.7 - 5.3 mm (0.067 - 0.209 in)

Removal and Installation of Bumper Side Reflector (Left Side)

INFOID:000000001647094

REMOVAL

1. Remove the front part of fender protector by removing screws and clips.
2. Remove screw of bumper side reflector (left side).

INSTALLATION

Install in the reverse order of removal.

Removal and Installation of Bumper Side Reflector (Right Side)

INFOID:000000001647095

REMOVAL

1. Remove bumper assembly.
2. Remove screw of bumper side reflector (right side).

INSTALLATION

Install in the reverse order of removal.

Removal and Installation of Bumper Molding (Upper side, Lower)

INFOID:000000001647096

REMOVAL

1. Remove front bumper fascia. Refer to [EI-13. "Removal and Installation"](#).
2. Remove screw of bumper molding (upper side, lower).
3. Disengage the plastic pawls to remove the bumper molding (upper side, lower).

INSTALLATION

Install in the reverse order of removal.

REAR BUMPER

< SERVICE INFORMATION >

REAR BUMPER



Removal and Installation

INFOID:000000001647097

CAUTION:

Bumper fascia is made of resin. Do not apply strong force to it, and be careful to prevent contact with oil.

SEC. 850



PIIB7223E

- | | | |
|---------------------------|------------------------|--------------------|
| 1. Bumper reinforcement | 2. Bumper over rider | 3. Energy absorber |
| 4. Bumper fascia assembly | 5. Bumper clip | 6. Bumper retainer |
| 7. Bumper stay | 8. Closing rear bumper | 9. Clip (A) |


REAR BUMPER

< SERVICE INFORMATION >

- | | | |
|---------------------------------------|-----------|-----------------------|
| 10. Fillet molding (only 19in models) | 11. Rivet | 12. Rear fender panel |
| 13. Double-faced adhesive tape | | |

REMOVAL

1. Remove rear combination lamp assembly. Refer to [LT-117. "Removal and Installation"](#).
2. Remove screw rear combination portion.
3. Remove clips of closing rear bumper.
4. Remove bolt and screw of both edges bumper fascia.
5. Rotate clip (A) in corner of bumper fascia 90 degrees and remove from bracket.
6. Remove clips from lower portion bumper fascia.
7. Pull out upper portion bumper fascia toward rear and disengage from clip.




8. Pull out both edges bumper fascia toward rear and disengage retainer from bracket.
9. Disconnect license lamp and turn signal lamp harness connector and remove bumper fascia assembly.

CAUTION:

When removing bumper fascia, 2 workers are required so as to prevent it from dropping.

10. Remove bumper energy absorber.
11. Remove screws of bumper over rider.
12. Remove nuts and bolts of bumper reinforcement.
13. Remove bumper stay bolts.



INSTALLATION

Install in the reverse order of removal.

NOTE:

After installing, perform fitting adjustment.

	Portion	Clearance
Rear bumper - Rear fender	A - A	0 - 0.5 mm (0 - 0.020 in)
Rear bumper - Back door	B - B	3.9 - 7.1 mm (0.154 - 0.280 in)

Removal and Installation of Bumper Side Brackets and Fillet Molding

REMOVAL

Shave head of rivet with drill [4.0 to 4.5 mm (0.157 to 0.177 in) dia.]

INSTALLATION

Install parts to fascia firmly with hand riveter.


NOTE:

Use the following rivet, when installing of parts.

REAR BUMPER

< SERVICE INFORMATION >

Rivet thickness : 1.2 – 6.4 mm (0.047 – 0.252 in)
Under hole diameter : 4.1 – 4.4 mm (0.161 – 0.173 in)
dia.



A

B

C

D

E

F

G

H

EI

J

K

L

M

N

O

P


COWL TOP

< SERVICE INFORMATION >

COWL TOP

Removal and Installation

INFOID:000000001647098



- | | | |
|------------------------|-------------------------|-------------------------|
| 1. Cowl top cover (RH) | 2. Cap | 3. Cowl top seal rubber |
| 4. Cap | 5. Cowl top cover (LH) | 6. Hoodledge cover (LH) |
| 7. Battery | 8. Hoodledge cover (RH) | |

REMOVAL

1. Remove clips of hoodledge cover (LH/RH).
2. Remove both wiper arms (LH/RH). Refer to [WW-27, "Removal and Installation of Front Wiper Arms, Adjustment of Wiper Arms Stop Location"](#).
3. Remove cowl top seal rubber.
4. Remove clips of cowl top cover (RH) and remove cowl top cover (RH).
5. Remove clips, cap, screws and remove cowl top cover (LH).
6. Remove washer hose from cowl top cover.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

After installing, perform adjustment of wiper arm. Refer to [WW-27, "Removal and Installation of Front Wiper Arms, Adjustment of Wiper Arms Stop Location"](#).


FENDER PROTECTOR

< SERVICE INFORMATION >

FENDER PROTECTOR

Removal and Installation

INFOID:000000001647099



1. Fender protector (front)

2. Fender protector (rear)

REMOVAL

1. Remove screws and clips of fender protector.
2. Remove fender protector front and remove fender protector rear.

INSTALLATION

Install in the reverse order of removal.


DOOR OUTSIDE MOLDING

< SERVICE INFORMATION >

DOOR OUTSIDE MOLDING

Removal and Installation

INFOID:000000001647100



1. Door outside molding

2. Front door panel

3. Glass

REMOVAL

1. Open windows fully.
2. Remove door finisher. Refer to [EI-30, "Removal and Installation"](#).
3. Remove rear end of door outside molding screw.
4. Disconnect pawls on front edge of molding.
5. Disconnect pawls in the order from front side of door panel portion, with clip clamp remover.
6. Remove slide molding rearward side, after disconnecting all pawls.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

- Be careful not to apply excessive force when removing because it is easy to deform parts.
- After removal, visually inspect molding, and if it is deformed, replace it with new molding.


SIDE SILL FINISHER

< SERVICE INFORMATION >

SIDE SILL FINISHER

Removal and Installation

INFOID:000000001647101



REMOVAL

1. Remove body side welt. Refer to [EI-32](#).
2. Remove kicking plate outer. Refer to [EI-32](#).
3. Remove bolts of side sill finisher lower portion.
4. Remove clips of side sill finisher front and rear portion.
5. Remove bolt and nut of reflector mudguard rear.
6. Insert clip clamp remover between panel and side sill finisher, and pull up side sill finisher.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

When installing side sill finisher, check that clips are securely fitted in panel holes on body, and then press them in.


FRONT DEFLECTOR

Removal

SIDE SILL FINISHER

< SERVICE INFORMATION >

Remove screws and clips of front deflector and remove front deflector.




Installation

Install in the reverse order of removal.

FLOOR FAIRING

Removal

Remove bolts and clip of floor fairing and remove floor fairing.




Installation

Install in the reverse order of removal.

FLOOR SIDE FAIRING

Removal

Remove nuts and bolt of floor side fairing and remove floor side fairing.



Installation

Install in the reverse order of removal.

REAR DEFLECTOR

Removal

Remove nuts and bolt of rear deflector and remove rear deflector.

Installation

Install in the reverse order of removal.


REAR DIFFUSER

Removal

SIDE SILL FINISHER

< SERVICE INFORMATION >

Remove bolts and clips of rear diffuser and remove rear diffuser.



Installation

Install in the revers order of removal.

A
B
C
D
E
F
G
H
EI
J
K
L
M
N
O
P


WINDSHIELD MOLDING

< SERVICE INFORMATION >

WINDSHIELD MOLDING

Removal and Installation

INFOID:000000001647102



- | | | |
|---------------------|--------------|--------------------|
| 1. Dam rubber | 2. Fastener | 3. Molding (upper) |
| 4. Windshield glass | 5. Insulator | 6. Spacer |
| 7. Mirror base | | |

REMOVAL

Remove windshield molding. Refer to [GW-12](#).

NOTE:

- Apply protective tape around circumference of windshield.
- Guiding a cutter knife along glass, cut surface of molding.
- Using pliers, draw out all remaining molding left in flanged area of body, and remove it completely from adhering surface on glass.

INSTALLATION

Install windshield molding. Refer to [GW-12](#).

NOTE:

- Align matching marks on body and glass. Install glass to body.
- Press entire surface of glass lightly to fit it completely.

Using a spatula, repair any adhesive overflow or shortage to make surface smooth. Position windshield moldings and allow their adhesion.

CAUTION:

- Be sure to install windshield molding before adhesive hardens.

WINDSHIELD MOLDING

< SERVICE INFORMATION >

- After installing glass, keep door windows open and avoid driving vehicle until adhesive has completely cured.

A
B
C
D
E
F
G
H
EI
J
K
L
M
N
O
P


REAR WINDOW MOLDING

< SERVICE INFORMATION >

REAR WINDOW MOLDING

Removal and Installation

INFOID:000000001647103



- | | | |
|-----------------------------|-----------------------|--------------|
| 1. Back door window molding | 2. Dual lock fastener | 3. Back door |
| 4. Back door window glass | 5. Holder | 6. Adhesive |
| 7. Dam rubber | | |

REMOVAL OF BACK DOOR WINDOW MOLDING

Remove back door window molding. Refer to [GW-15](#).

NOTE:

Apply a strip of protective tape along the contour of back door window glass (molding) to prevent paint surface from being damaged.

INSTALLATION OF BACK DOOR WINDOW MOLDING

Install back door window molding. Refer to [GW-15](#).

NOTE:

- Clean adhesive portion of back door window glass and around circumference with white gasoline.
- Apply dam rubber to all surfaces of glass.
- Attach back door window molding to side face of glass.
- Back door window molding should not overlap on the surface of back door window glass.


REAR SPOILER

< SERVICE INFORMATION >

REAR SPOILER

Removal and Installation

INFOID:000000001647104



1. Rear spoiler

REMOVAL

1. Remove back door finisher lower. Refer to [EI-44, "Removal and Installation \(for Coupe Models\)"](#).
2. Remove nuts of rear spoiler.
3. Remove clip of rear spoiler.
4. Remove double-faced adhesive tapes with wide plastic spatula between back door and rear spoiler.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

- Do not let air between contact surfaces when installing.
- To secure contact, do not wash vehicle within 24 hours after installation.


ROOF SIDE MOLDING

< SERVICE INFORMATION >

ROOF SIDE MOLDING

Removal and Installation (for Coupe Models)

INFOID:000000001647105



1. Front pillar finisher
2. Retainer body side weatherstrip
3. Body side weatherstrip
4. Lock pillar finisher

FRONT PILLAR FINISHER

Removal

1. Remove lock pillar finisher.
2. Remove clip and double-faced adhesive tapes of body side weatherstrip.
3. Remove body side weatherstrip.
4. Remove screw of retainer body side weatherstrip.
5. Remove screw and clip of front pillar finisher.
6. Remove front pillar finisher.

Installation

Install in the reverse order of removal.

LOCK PILLER FINISHER

Removal

Lift and twist lock pillar finisher up from lock pillar disconnect clips.

Installation


Install in the reverse order of removal.

ROOF SIDE MOLDING

< SERVICE INFORMATION >

Removal and Installation (for Roadster Models)

INFOID:000000001647106



- | | | |
|-------------------------------|--------------------------|-----------------|
| 1. Clip (C103) | 2. Clip | 3. Clip (CE103) |
| 4. Body side glass-run rubber | 5. Screw | 6. Retainer |
| 7. Clip (C101) | 8. Front pillar finisher | 9. Grommet |
| 10. Body side weatherstrip | | |

FRONT PILLAR FINISHER

Removal

1. Open soft top.
2. Remove clip and double-faced adhesive tapes of body side glass-run rubber.

NOTE:

Slide body side glass run slightly upward to remove clip on middle portion of glass run rubber side from retainer.

3. Remove body side glass-run rubber.
4. Remove screw of retainer.
5. Remove screw and clips of front pillar finisher.
6. Remove front pillar finisher.

Installation

Install in the reverse order of removal.

BODY SIDE WEATHERSTRIP

Removal

1. Open soft top.
2. Disconnect clips and remove body side weatherstrip.

Installation

Install in the reverse order of removal.


DOOR FINISHER

< SERVICE INFORMATION >

DOOR FINISHER

Removal and Installation

INFOID:000000001647107



- | | | |
|--------------------------------------|--------------------------------------|----------------------------------|
| 1. Power window main switch finisher | 2. Inside handle escutcheon | 3. Driver door finisher assembly |
| 4. Grommet | 5. Speaker grille | 6. Step lamp lens |
| 7. Door panel assembly (LH) | 8. Door grip finisher | 9. Door grip |
| 10. Power window sub switch finisher | 11. Passenger door finisher assembly | |
- Clip △ Pawl □ Metal clip

DRIVER DOOR FINISHER

Removal

1. Remove cap inside handle portion and remove screw.
2. Remove power window main switch finisher.
3. Disconnect harness connector power window main switch.
4. Remove screw of power window main switch portion.
5. Disengage both of the door main harness clip on the rear surface of the door finisher.
6. Disengage part of the bottle holder's illumination harness connector.
7. Pull up door finisher and remove connector inside handle cable and lock knob cable.

Installation

Install in the reverse order of removal.

CAUTION:

To install finisher, check if all clips are matched over holes of panel on vehicle, then push it.

PASSENGER DOOR FINISHER

DOOR FINISHER

< SERVICE INFORMATION >

Removal

- 1. Remove cap inside handle portion and remove screw. A
- 2. Insert tapping flat-bladed screwdriver into edge portion, disconnect pawls, and remove door grip finisher.
- 3. Remove screw of door grip portion. B
- 4. Remove power window sub switch finisher.
- 5. Disconnect harness connector power window sub switch.
- 6. Disengage both of the door main harness clip on the rear surface of the door finisher. C
- 7. Disengage part of the bottle holder's illumination harness connector.
- 8. Remove screw of power window sub switch portion.
- 9. Pull up door finisher and remove connector inside handle cable and lock knob cable. D

Installation

Install in the reverse order of removal.

CAUTION:

To install finisher, check if all clips are matched over holes of panel on vehicle, then push it.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EI

BODY SIDE TRIM

< SERVICE INFORMATION >


BODY SIDE TRIM

Removal and Installation (for Coupe Models)

INFOID:000000001647108

CAUTION:

Wrap the tip of flat-bladed screwdriver with a cloth when removing metal clips from garnishes.



- | | | |
|-------------------------|------------------------|------------------------|
| 1. Rear pillar finisher | 2. Rear side finisher | 3. Body side welt |
| 4. Front pillar garnish | 5. Kicking plate outer | 6. Kicking plate inner |

REAR SIDE FINISHER

Removal

1. Remove kicking plate inner.
2. Remove body side welt.
3. Remove rear side finisher.

Installation

Install in the reverse order of removal.

REAR PILLAR FINISHER

Removal

1. Remove back door weatherstrip. Refer to [BL-92, "Removal and Installation of Back Door Weatherstrip"](#).
2. Remove luggage finisher lower center. Refer to [EI-36, "Removal and Installation \(for Coupe Models\)"](#).
3. Disconnect harness connector at luggage room lamp.
4. Remove luggage side finisher upper. Refer to [EI-36, "Removal and Installation \(for Coupe Models\)"](#).
5. Remove seat belt shoulder anchor. Refer to [SB-4, "Removal and Installation of Seat Belt \(Coupe\)"](#).
6. Remove kicking plate inner.
7. Remove body side welt.
8. Remove rear side finisher.
9. Remove rear pillar finisher.

BODY SIDE TRIM

< SERVICE INFORMATION >

Installation

Install in the reverse order of removal.

A

FRONT PILLAR GARNISH

Removal

B

1. Remove body side welt.
2. Remove front pillar garnish.

Installation

Install in the reverse order of removal.

C

KICKING PLATE

D

Removal

1. Remove kicking plate inner.
2. Remove body side welt.
3. Remove clip of kicking plate outer.
4. Remove kicking plate outer.

E

Installation

Install in the reverse order of removal.

F

BODY SIDE WELT

G

Removal

1. Remove kicking plate inner.
2. Remove body side welt.

H

Installation

Install in the reverse order of removal.

EI

CAUTION:

To install, check if all clips are matched over holes of panel on vehicle, then push on.

Removal and Installation (for Roadster Models)

INFOID:000000001647109

J

CAUTION:

Wrap the tip of flat-bladed screwdriver with a cloth when removing metal clips from garnishes.

K

L

M


N

O

P

BODY SIDE TRIM

< SERVICE INFORMATION >



- | | | |
|------------------------|------------------------|-------------------------|
| 1. Rear side finisher | 2. Body side welt | 3. Front pillar garnish |
| 4. Kicking plate outer | 5. Kicking plate inner | |

REAR SIDE FINISHER

Removal

1. Remove kicking plate inner.
2. Remove body side weatherstrip. Refer to [EI-29, "Removal and Installation \(for Roadster Models\)"](#).
3. Remove body side welt.
4. Remove rear side finisher.

Installation

Install in the reverse order of removal.

FRONT PILLAR GARNISH

Removal

1. Partially remove body side welt.
2. Remove front pillar garnish.

Installation

Install in the reverse order of removal.

KICKING PLATE

Removal

1. Remove kicking plate inner.
2. Remove body side welt.
3. Remove clip of kicking plate outer and remove kicking plate outer.

Installation

Install in the reverse order of removal.

BODY SIDE WELT

BODY SIDE TRIM

< SERVICE INFORMATION >

Removal

1. Remove kicking plate inner.
2. Remove body side welt.

Installation

Install in the reverse order of removal.

CAUTION:

To install, check if all clips are matched over holes of panel on vehicle, then push on.

A

B

C

D

E

F

G

H

EI

J

K

L

M

N

O

P

LUGGAGE FLOOR TRIM


< SERVICE INFORMATION >

LUGGAGE FLOOR TRIM

Removal and Installation (for Coupe Models)

INFOID:000000001647110

SEC. 737•799•849





PIIB7155J

- | | | |
|-------------------------------------|-------------------------------------|-------------------------------------|
| 1. Luggage finisher lower (center) | 2. Luggage side finisher lower (RH) | 3. Luggage side finisher lower (LH) |
| 4. Luggage side finisher upper (RH) | 5. Luggage side finisher upper (LH) | 6. Trunk side box |
| 7. Tool box | 8. Luggage floor carpet | 9. Spare tire cover |

LUGGAGE FLOOR TRIM

< SERVICE INFORMATION >

- | | | |
|--|--|--|
| 10. Strut cover rear | 11. Strut cover upper (RH) | 12. Strut cover upper (center) |
| 13. Strut cover upper (LH) | 14. Strut cover lower (RH) | 15. Strut cover lower (center) |
| 16. Strut cover lower (LH) | 17. Strut cover front | 18. Luggage floor finisher upper (rear) |
| 19. Luggage floor finisher upper (front) | 20. Rear parcel box | 21. Rear parcel escutcheon |
| 22. Luggage floor finisher lower | 23. Rear floor box lid | 24. Luggage floor finisher mask |
| 25. Rear floor box striker | 26. Rear floor box | 27. Rear floor box mat |
| 28. Tray |  Clip |  Pawl |

 Metal clip

LUGGAGE FLOOR TRIM

Removal

1. Remove back door welt. Refer to [EI-44](#).
2. Remove luggage floor carpet.
3. Remove spare tire cover.
4. Remove luggage finisher lower (center).
5. Remove luggage side finisher upper (RH/LH).
6. Remove strut cover upper (RH/LH).
7. Remove strut cover rear.
8. Remove clip of luggage side finisher lower and remove luggage side finisher lower.
9. Remove strut cover front.
10. Remove strut cover upper (center).
11. Remove clip of strut cover lower (RH/LH) and remove strut cover lower.
12. Remove strut cover lower (center).

Installation

Install in the reverse order of removal.

REAR FLOOR BOX

Removal

1. Remove kicking plate inner. Refer to [EI-32](#).
2. Remove body side welt. Refer to [EI-32](#).
3. Remove rear side finisher. Refer to [EI-32](#).
4. Remove console box. Refer to [IP-11](#).
5. Remove screw of rear floor box and remove rear floor box.
6. Remove pins of rear floor box lid and remove rear floor box lid.
7. Remove luggage floor finisher mask.
8. Remove screws of rear floor box lock and remove rear floor box lock.
9. Remove tray.

Installation

Install in the reverse order of removal.

CAUTION:


To install, check if all clips are matched over holes panel on vehicle, then push on.

LUGGAGE FLOOR TRIM

< SERVICE INFORMATION >

Removal and Installation (for Roadster Models)

INFOID:000000001647111



- | | | |
|-------------------------------------|-------------------------------------|-------------------------------------|
| 1. Luggage floor finisher upper | 2. Rear parcel box | 3. Back panel finisher assembly |
| 4. Guard frame protector front (LH) | 5. Storage lid deflector | 6. Guard frame protector front (RH) |
| 7. Luggage floor finisher lower | 8. Rear floor box lid | 9. Luggage floor finisher mask |
| 10. Guard frame protector rear (LH) | 11. Guard frame protector rear (RH) | 12. Rear floor box striker |
| 13. Rear floor box mat | 14. Tray | 15. Rear floor box |

REAR FLOOR BOX

Removal

1. Remove center console finisher. Refer to [IP-11](#).
2. Remove kicking plate inner and partially remove rear of body side welt (RH/LH). Refer to [EI-33, "Removal and Installation \(for Roadster Models\)"](#).
3. Remove rear side finisher. Refer to [EI-33, "Removal and Installation \(for Roadster Models\)"](#).
4. Remove luggage floor finisher lower.
5. Remove rear floor box lid and luggage floor finisher mask from luggage floor finisher lower.

LUGGAGE FLOOR TRIM

< SERVICE INFORMATION >

6. Remove rear floor box mat and tray.
7. Remove screws, and remove rear floor box striker.
8. Loosen mounting screws and remove rear floor box.

Installation

Install in the reverse order of removal.

LUGGAGE FLOOR FINISHER UPPER

Removal

1. Remove kicking plate inner and partially remove rear of body side welt (RH/LH). Refer to [EI-33, "Removal and Installation \(for Roadster Models\)"](#).
2. Remove rear side finisher. Refer to [EI-33, "Removal and Installation \(for Roadster Models\)"](#).
3. Remove luggage floor finisher lower.
4. Remove rear parcel box (RH/LH).
5. Remove luggage floor finisher upper.

Installation

Install in the reverse order of removal.

BACK PANEL FINISHER

Removal

1. Remove kicking plate inner and partially remove rear of body side welt (RH/LH). Refer to [EI-33, "Removal and Installation \(for Roadster Models\)"](#).
2. Remove rear side finisher. Refer to [EI-33, "Removal and Installation \(for Roadster Models\)"](#).
3. Remove cover and shoulder anchor bolt of seat belt (RH/LH). Refer to [SB-6, "Removal and Installation of Seat Belt \(Roadster\)"](#).
4. Remove front guard frame protector (RH/LH).
5. Loosen mounting bolts and remove storage lid deflector.
6. Loosen screws and remove rear guard frame protector (RH/LH).
7. Remove clips, remove back panel finisher assembly.

Installation

Install in the reverse order of removal.

CAUTION:

To install, check if all clips are matched over holes panel on vehicle, then push on.

A
B
C
D
E
F
G
H
EI
J
K
L
M
N
O
P


FLOOR TRIM

< SERVICE INFORMATION >

FLOOR TRIM

Removal and Installation

INFOID:000000001647112




1. Floor carpet assembly

2. Nut

REMOVAL

1. Remove driver seat and passenger seat. Refer to [SE-62](#).
2. Remove center console. Refer to [IP-11](#).
3. Remove instrument side panel (left and right). Refer to [IP-11](#).
4. Remove body side welt. Refer to [EI-32](#).
5. Remove kicking plate inner. Refer to [EI-32](#).
6. Remove screw of footrest and remove plate.
7. Remove clips of footrest and remove footrest.
8. Remove dash side finisher. Refer to [IP-11](#).
9. Remove nut and clips of floor carpet.
10. Remove floor carpet assembly.



INSTALLATION

Install in the reverse order of removal.


HEADLINING

< SERVICE INFORMATION >

HEADLINING

Removal and Installation (for Coupe Models)

INFOID:000000001647113




- | | | |
|---------------------|-----------------------|-------------------|
| 1. Headlining | 2. Dual lock fastener | 3. Sun-visor (RH) |
| 4. Sun-visor holder | 5. Sun-visor (LH) | 6. cap |
| 7. Screw | 8. Map lamp assembly | |
| Pawl | Metal clip | |

REMOVAL

1. Remove back door welt. Refer to [EI-44](#).
2. Remove luggage floor carpet. Refer to [EI-36, "Removal and Installation \(for Coupe Models\)"](#).
3. Remove luggage finisher lower center. Refer to [EI-36, "Removal and Installation \(for Coupe Models\)"](#).
4. Disconnect harness connector at luggage room lamp.
5. Remove luggage side finisher upper. Refer to [EI-36, "Removal and Installation \(for Coupe Models\)"](#).
6. Remove kicking plate inner. Refer to [EI-32, "Removal and Installation \(for Coupe Models\)"](#).
7. Remove body side welt. Refer to [EI-32, "Removal and Installation \(for Coupe Models\)"](#).
8. Remove rear side finisher. Refer to [EI-32, "Removal and Installation \(for Coupe Models\)"](#).
9. Remove seat belt anchor. Refer to [SB-4, "Removal and Installation of Seat Belt \(Coupe\)"](#).
10. Remove rear pillar finisher. Refer to [EI-32, "Removal and Installation \(for Coupe Models\)"](#).
11. Remove front pillar garnish. Refer to [EI-32, "Removal and Installation \(for Coupe Models\)"](#).
12. Disconnect harness connector at map lamp.
13. Remove sun-visor (RH/LH).
14. Remove sun-visors holder (RH/LH).

NOTE:

Insert flat-bladed screw driver to edge, and turn it 90 degrees and remove sun-visor holder.



15. Remove dual lock fastener.

HEADLINING

< SERVICE INFORMATION >

16. Remove clips of headlining rear portion.
17. Remove headlining, turn to 90 degrees and take out from back door.

CAUTION:


- Always remove or install in a pair.
- Cover surroundings with waste to avoid scratches or damages.
- Do not bend headlining too hard.

INSTALLATION

Install in the reverse order of removal.


CAUTION:

- Do not bend headlining when installing.
- When installing the map lamp assembly (new unit) or assist grip assembly (new unit), use tools like drafter or deep socket A to eliminate the gap between the headlining and the above new units while the push on nuts (1).



Removal and Installation (for Roadster Models)

INFOID:000000001647114



- | | | |
|------------------------|----------------|----------------|
| 1. Cap | 2. Screw | 3. Sun-visor |
| 4. Sun-visor holder | 5. Clip (C101) | 6. Clip (C101) |
| 7. Roof front finisher | 8. Map lamp | |

ROOF FRONT FINISHER

Removal

1. Remove cap and screws and disconnect harness connector, then remove sun-visor.


HEADLINING

< SERVICE INFORMATION >

2. Remove sun-visors holder (RH/LH).

NOTE:

Insert flat-bladed screw driver to edge, and turn it 90 degrees and remove sun-visor holder.



3. Remove body side welt and front pillar garnish. Refer to [EI-33, "Removal and Installation \(for Roadster Models\)"](#).
4. Disconnect harness connector and remove roof front finisher.

Installation

Install in the reverse order of removal.

CAUTION:

To install, check if all clips are matched over holes panel on vehicle, then push on.

A
B
C
D
E
F
G
H
EI
J
K
L
M
N
O
P


BACK DOOR

< SERVICE INFORMATION >

BACK DOOR

Removal and Installation (for Coupe Models)

INFOID:000000001647115



- 1. Back door molding
- 4. Back door panel

- 2. Bumper rubber
- 5. Back door welt

- 3. Bumper rubber

BACK DOOR MOLDING

Removal

Remove clips of back door molding and remove back door molding.

Installation

Install in the reverse order of removal.

BACK DOOR WELT

Removal

Remove back door welt.


Installation

Install in the reverse order of removal.

BACK DOOR

< SERVICE INFORMATION >

BACK DOOR FINISHER



1. Back door finisher lower
2. Back door finisher side (LH)
3. Back door finisher side (RH)
4. Back door finisher upper

Removal

1. Remove back door finisher lower.
2. Remove back door finisher upper.
3. Remove back door finisher side (RH/LH).

Installation

Install in the reverse order of removal.


TRUNK ROOM TRIM & TRUNK LID FINISHER

< SERVICE INFORMATION >

TRUNK ROOM TRIM & TRUNK LID FINISHER

Removal and Installation (for Roadstar Models)

INFOID:000000001647116



- | | | |
|-------------------------|-----------------------|------------------------|
| 1. Trunk front finisher | 2. Trunk side box | 3. Trunk rear finisher |
| 4. Tool box | 5. Trunk floor carpet | 6. Spare tire cover |

TRUNK ROOM TRIM

Removal

1. Remove trunk lid weatherstrip. Refer to [BL-101, "Removal and Installation of Trunk Lid Weatherstrip"](#).
2. Remove trunk floor carpet.
3. Remove spare tire cover.
4. Remove trunk lid release lever from trunk rear finisher.
5. Remove clips and remove trunk rear finisher.
6. Remove clips of trunk front finisher and remove trunk front finisher.
7. Remove trunk side box.
8. Remove clips and remove tool box.


Installation

Install in the reverse order of removal.

TRUNK LID FINISHER

TRUNK ROOM TRIM & TRUNK LID FINISHER

< SERVICE INFORMATION >



- | | | |
|-----------------------|---------------------------|---------------------------|
| 1. Bumper rubber | 2. Bumper rubber | 3. Trunk lid molding (RH) |
| 4. Trunk lid finisher | 5. Trunk lid molding (LH) | |

Removal

Remove clips of trunk lid finisher and remove trunk lid finisher.

Installation

Install in the reverse order of removal.

TRUNK LID MOLDING

Removal

1. Remove clips and double-faced adhesive tape of trunk lid molding.
2. Remove trunk lid molding (LH/RH).

Installation

Install in the reverse order of removal.